

MS1,
MS2...MSn
REMOTE
MCU
REGIONAL
DISPATCHER
CLIENT
ANNOUNCE
GROUP CALL
ACKNOWLEDGE
GROUP CALL
MEDIA
BUFFERING
FIND MEMBER
LOCATIONS
START GROUP
ANNOUNCE GROUP CALL
ACKNOWLEDGE GROUP CALL
MEDIA
SETUP GROUP CALL
(VIA SDB)
SETUP IN PROGRESS
(VIA SDB)
SELECTS MEMBER
LIST*
AND PRESSES
PTT
PLAY TALK TONE
USER STARTS
TALKING
BUFFERING
TRAFFIC
CHANNEL
UP

FIG. 5