

UE 20
HNB 10
HNB GW 14
CN 22
1. RRC Connection Est. (TMSI or IMSI, UE Rel, UE Cap, ...)
2. RRC Initial Direct Transfer (e.g., LU Request,...)
3. Check Release, UE Capabilities
4. Optional Identify request
5. UE Registration Req (IMSI, UE Rel, UE Cap,...)
6. Access Control (IMSI, HNB)
7. UE Registration Accept (Context-id,...)
8. Connect (Initial UE Message,...)
9. SCCP CR (Initial UE Message,...)
10. SCCP CC
11. Continue with NAS procedure

FIG. 6



UE 20
HNB 10
HNB GW 14
CN 22
1. RRC Connection Est. (TMSI or IMSI, UE Rel, UE Cap, ...)
2. RRC Initial Direct Transfer (e.g., LU Request,...)
3. Check Release, UE Capabilities
4. UE Registration Req (TMSI or IMSI, Rel, UE Cap,...)
5. Access Control (Always accept)
6. UE Registration Accept (Context-id,...)
7. Connect (Initial UE Message, CSGid...)
8. SCCP CR (Initial UE Message, CSGid...)
9. SCCP CC
10. Optional MM
11. Access Control
12. Continue with NAS procedure

FIG. 7