

FIG. 1




FIG. 2




FIG. 3




FIG. 4




FIG. 5




FIG. 6




FIG. 7




FIG. 8




FIG. 9




FIG. 10





FIG. 11



COIN OR MEDAL INPUT
貨幣又はメダル投入
100

FIG. 12




FIG. 13




FIG. 14




FIG. 15




FIG. 16




FIG. 17




FIG. 18




FIG. 10

- 2 SATELLITE
- 4 ROULETTE WHEEL
- 80 MAIN CONTROL CPU
- 84 WIN DETERMINATION UNIT
- 85 BALL INPUT UNIT
- 86 BALL COLLECTION UNIT

FIG. 11

- 2 SATELLITE
- 5 MEDAL ACCEPTANCE UNIT
- 6 CONTROL SECTION
- 7 IMAGE DISPLAY
- 9 SPEAKER
- 22 BET CONFIRMATION BUTTON
- 23 PAYBACK BUTTON
- 24 HELP BUTTON
- 28 TOUCH PANEL
- 80 MAIN CONTROL CPU
- 89 SATELLITE MAIN BODY
- 91 SATELLITE CONTROL CPU
- 94 HOPPER
- 95 LIQUID CRYSTAL DRIVE CIRCUIT
- 96 SOUND OUTPUT CIRCUIT

FIG. 12

93A BET INFORMATION STORAGE AREA

93B OWNED CREDIT COUNT STORAGE AREA

FIG. 13

S1 START BET PERIOD

S2 INPUT BALL

S3 DOES BET PERIOD EXPIRE?

S4 RECEIVE BET INFORMATION

S5 STOP BALL

S6 PERFORM WIN NUMBER DETERMINATION PROCESSING

S7 UPDATE HISTORY DATA

S8 DETERMINE WHETHER OR NOT PLAYER WIN GAME IN BET CHIP

S9 WIN?

S10 PERFORM AWARD CALCULATION PROCESSING

S11 PERFORM GAME RESULT TRANSMISSION PROCESSING

S12 COLLECT BALL

FIG. 14

S20 FIRST BET SCREEN?

S21 BET PROCESSING ACCORDING TO FIRST BET SCREEN

S22 BET PROCESSING ACCORDING TO SECOND BET SCREEN

S23 TRANSMIT BET INFORMATION

S24 PERFORM GAME RESULT RECEPTION PROCESSING

S25 PERFORM CREDIT PAYOUT PROCESSING

S26 UPDATE HISTORY DISPLAY

FIG. 15

BET PROCESSING ACCORDING TO FIRST BET SCREEN

S30 SWITCH BUTTON ON?

S31 SELECT BET AREA

S32 WIN COUNT BET BUTTON SELECTED?

S33 SEARCH GAME HISTORY DATA

S34 DETERMINE BET COUNT

S35 BET CONFIRMATION BUTTON PRESSED?

S36 DOES BET TIME EXPIRE?

S37 CONFIRM BET

S38 MAKE TRANSITION TO SECOND BET SCREEN

FIG. 16

BET PROCESSING ACCORDING TO SECOND BET SCREEN

S40 SWITCH BUTTON ON?

S41 SELECT BET AREA

S42 WIN COUNT BET BUTTON SELECTED?

S43 SEARCH GAME HISTORY DATA

S44 BET WIDTH SETTING BUTTON PRESSED?

S45 CHANGE BET WIDTH

S46 CONTINUE PREVIOUS BET WIDTH SETTING

S47 DETERMINE BET COUNT

S48 BET CONFIRMATION BUTTON PRESSED?

S49 DOES BET TIME EXPIRE?

S50 CONFIRM BET

S51 MAKE TRANSITION TO FIRST BET SCREEN