FIG. 2




106 IP NETWORK MONITORING DEVICE
103 BUILDING FACILITY DEVICE MANAGING SYSTEM
f: GENERATION AND TRANSMISSION OF STATUS OF IP NETWORK MONITORING DEVICE
a: RESIDENTIAL RECEPTION OF STATUS OF MONITORING DEVICE
g: TRANSMISSION OF OPERATION SIGNAL TO IP NETWORK MONITORING DEVICE
d: RESIDENTIAL RECEPTION OF COMMAND SIGNAL
301
302
MONITORING-DEVICE-STATUS MANAGING UNIT
COORDINATED -PACKET-GENERATION TRANSMITTING/RECEIVING UNIT
401
MANAGEMENT DB
b: HAS THE STATUS OF MONITORING DEVICE BEEN CHANGED?
c: IF CHANGED, INFORMATION UPDATE
e: READ OF STATUS OF IP NETWORK MONITORING DEVICE
201 IP NETWORK DEVICE MANAGING SYSTEM

FIG. 2


106 IP NETWORK MONITORING DEVICE
103 BUILDING FACILITY DEVICE MANAGING SYSTEM
f: GENERATION AND TRANSMISSION OF STATUS OF IP NETWORK MONITORING DEVICE
a: RESIDENTIAL RECEPTION OF STATUS OF MONITORING DEVICE
g: TRANSMISSION OF OPERATION SIGNAL TO IP NETWORK MONITORING DEVICE
d: RESIDENTIAL RECEPTION OF COMMAND SIGNAL
301
302
MONITORING-DEVICE-STATUS MANAGING UNIT
COORDINATED -PACKET-GENERATION TRANSMITTING/RECEIVING UNIT
401
MANAGEMENT DB
b: HAS THE STATUS OF MONITORING DEVICE BEEN CHANGED?
c: IF CHANGED, INFORMATION UPDATE
e: READ OF STATUS OF IP NETWORK MONITORING DEVICE
201 CONNECTION PROGRAM OF BUILDING FACILITY DEVICE MANAGING SYSTEM