


FIG.1




FIG.2




FIG.3




FIG.4



BEGIN
A RL FAILURE IS DETECTED
STEP 500
AN INTIAL ACCESS PROCEDURE FOR OBTAINING ACCESS TO A SELECTED TARGET eNB IS CONDUCTED
STEP 501
AN IE INCLUDING A SOURCE eNB IDENTITY IS TRANSMITTED
STEP 502
RRC CONTEXT FROM TARGET eNB IS RECEIVED
STEP 503
END

FIG.5