




FIG. 1




FIG. 2

FIG. 3





FIG. 4




FIG. 5





FIG. 6







FIG. 8



9
G
E




FIG. 10



APL FIELD SWITCH POWER CONFIGURATION

APL FIELD SWITCH PHC-234-S1

Cascade ☒ Enabled POWER: TRUNK

88

90

92

Port	Power Class	
1	A	Reset To Default
2	B	Reset to Default
3	A	Reset to Default
...		
N	B	Reset to Default

A
B
C
D

72

FIG. 11

94

NETWORK APL FIELD SWITCHES				
APL FIELD SWITCH ID	Number of Ports	Number of Active Ports	Power Source	
PHC-234-S1	N	2	Trunk	Edit
PHC-567-T1	X	2	Auxiliary	Edit
PHE-890-A2	Y	2	Auxiliary	Edit

96

98

FIG. 12




FIG. 13