




FIG. 1




FIG. 2A

2/14




FIG. 2B




FIG. 3




FIG. 4




FIG. 5




FIG. 6

4/14




FIG. 7




FIG. 8

SoftAI CONFIGURATIONS TABLE

	DEFAULT	LTE	CONFIG 1	CONFIG 2	CONFIG 3
WF	WF_1	WF_1		WF_2	WF_3
MA	MA_1	MA_2	MA_2	MA_2	MA_1
FS	FS_1	FS_2	FS_2	F_3	FS_2
PROTCL	P_1	P_2	P_2		P_1
MCS	MCS_1	MCS_2			MCS_2

FIG. 9




FIG. 10




FIG. 11




FIG. 12

8/14





FIG. 13A

9/14



10/14





FIG. 14A

11/14



12/14




FIG. 15




FIG. 16




FIG. 17




FIG. 18




FIG. 19




FIG. 20