




FIG. 1




FIG. 2




FIG. 3




FIG. 4

FIG. 5 illustrates a "Create a new site" form. The form contains the following fields and controls:

- CLLI*** (labeled 502): A text input field.
- Name*** (labeled 504): A text input field.
- Location*** (labeled 506): A text input field.
- Management Subnet***: A dropdown menu (labeled 508) with "Subnet Address" selected.
- Secondary Management Subnet***: A dropdown menu (labeled 510) with "Not Set" selected.
- GMSN Subnet*** (labeled 512): A dropdown menu with "Subnet Address" selected.
- Secondary GMSN Subnet*** (labeled 514): A dropdown menu with "Not Set" selected.
- MAAS Installation*** (labeled 516): A dropdown menu with "Not Set" selected.
- Buttons** (labeled 518): "Close" and "Create Site" buttons.

FIG. 5

600

Create a new Router Group

608 Site*
..... ▾

610

612

614

616

618

620

622

624

626

602

604

606

628 Submit

EAR-1 Hostname	Optic	1st Interface	2nd Interface	3rd Interface
	CW4 ▾			

EAR-2 Hostname	Optic	1st Interface	2nd Interface	3rd Interface
	CW4 ▾			

VAR-1 Hostname	Optic	1st Interface	2nd Interface
	CW4 ▾		

VAR-2 Hostname	Optic	1st Interface	2nd Interface
	CW4 ▾		

PRI-1 Hostname	Optic	1st Interface	2nd Interface
	CW4 ▾		

PRI-2 Hostname	Optic	1st Interface	2nd Interface
	CW4 ▾		

FIG.6

700

Create a new device

702 Site

.....

704 Device Function

.....

706 Device Serial Number

.....

708 Rack

710 Rack Unit

712 Terminal Server Hostname

714 Management Switch Hostname

716

Close

Create Device

FIG.7

402

800

Deployment UI

Logout Admin

Basics

Sites

Site PE's Devices

MAAS Installations

Search:

Show entries

Code	Name	Location	MGMT Subnet (MOSS VRF)	Sec. MGMT Subnet (MOSS VRF)	GMSN Subnets (VLAN 42)	Sec. GMSN Subnets (VLAN 42)	PE Status	Actions
BILLXXX	BILLXXX	BILLXXX	10.102.1.1/24	Not Set	10.102.1.1/24	Not Set	Unconfigured	Scan Site Report Edit Delete
MINERLAB	Mineral Lab 4	Denver, CO	10.102.1.1/24	Not Set	10.102.1.1/24	Not Set	Unconfigured	Scan Site Report Edit Delete

802

804

806

808

Showing 1 to 2 of 2 entries

Previous

Next

FIG.8

402

900

Deployment UI

Logout Admin

Basics

Sites

Site PE's

Devices

MAAS Installations

Search:

Show entries

Site	EAR-1/Optic	EAR-2/Optic	VAR-1/Optic	VAR-2/Optic	PRI-1/Optic	PRI-2/Optic
MINERLAB	mnl-ear-1/CW4	mnl-ear-2/CW4	mnl-var-1/CW4	mnl-var-2/CW4	mnl-priv-20/CW4	mnl-priv-21/CW4

902

904

Showing 1 to 2 of 2 entries

Previous

Next

FIG.9




FIG.10




FIG.11

402

Deployment UI

Logout Admin

Basics Sites Site PE's Devices OS Files Base Config Files Production Config Files

Interface Standards

MAAS Installations

Show 10 entries

Search:

Interface Standard	Device Function	Device Interface	Remote Interface	Remote Function	Set Description From LLDP	Network Ready Requirement	
Minerlab EM001	EM001	xe-0/2/0	xe-0/0/32	QH001	false	true	Edit Delete
Minerlab EM001	EM001	xe-0/2/1	xe-0/0/32	QH002	false	true	Edit Delete
Minerlab EM001	EM001	me0	ANY	ANY	true	true	Edit Delete
Minerlab EM002	EM002	xe-0/2/0	xe-0/0/32	QH003	false	true	Edit Delete
Minerlab EM002	EM002	xe-0/2/1	xe-0/0/32	QH004	false	true	Edit Delete
Minerlab EM002	EM002	me0	ANY	ANY	true	true	Edit Delete
Minerlab QH001	QH001	et-0/0/26	et-0/0/0	QS001	false	true	Edit Delete
Minerlab QH001	QH001	et-0/0/27	et-0/0/1	QS001	false	true	Edit Delete
Minerlab QH001	QH001	et-0/0/28	et-0/0/2	QS001	false	true	Edit Delete
Minerlab QH001	QH001	et-0/0/29	et-0/0/0	QS002	false	true	Edit Delete

Showing 1 to 10 of 290 entries

Previous 1 2 3 4 5 .. 29 [Next](#)

FIG.12

1300

Update device

1302

Site

.....

▼

1304

Device Function

.....

▼

1306

Network Device Standard

.....

1308

Revenue Ports

Reconfigure Revenue Ports

1310

Rack

1312

Rack Unit

1316

Close

Update Device

FIG.13

Revenue Port Configuration

Existing Revenue Port Configurations – Site ID

Configuration	Starting Port	Count
Configuration Type A	0	8

1402

1404

1406

Edit

Delete

Choose Configuration to Add

Search:

Available Interface Port Configurations

Configuration Type A	Add
Configuration Type B	Add
Configuration Type C	Add
Configuration Type D	Add
Configuration Type E	Add
Configuration Type F	Add
Configuration Type G	Add
Configuration Type H	Add

Switch Interface Map

Close

Interface	Configuration	Chassis Number
et-0/0/0:0	Configuration Type A	1
et-0/0/0:1	Configuration Type A	1
et-0/0/0:2	Configuration Type A	1
et-0/0/0:3	Configuration Type A	1
et-0/0/1:0	Configuration Type A	1
et-0/0/1:1	Configuration Type A	1
et-0/0/1:2	Configuration Type A	1
et-0/0/1:3	Configuration Type A	1
et-0/0/2:0	Configuration Type A	2
et-0/0/2:1	Configuration Type A	2
et-0/0/2:2	Configuration Type A	2
et-0/0/2:3	Configuration Type A	2
et-0/0/3:0	Configuration Type A	2
et-0/0/3:1	Configuration Type A	2
et-0/0/3:2	Configuration Type A	2

1408

1410

1400

FIG.14




FIG.15




FIG. 16