

FIG. 1a




FIG. 1b




FIG. 1c




FIG. 2




FIG. 3




FIG. 4




FIG. 5




FIG. 6




FIG. 7




FIG. 8

sending configuration information to a terminal, wherein the configuration information is configured to instruct the terminal to perform a periodic positioning measurement and/or a non-periodic positioning measurement 901

FIG. 9




FIG. 10




FIG. 11




FIG. 12




FIG. 13