




FIG. 1




FIG. 2




FIG. 3

4/13




FIG. 4




FIG. 5




FIG. 6

FIG. 7

6/13




FIG. 8A




FIG. 8B

7/13

System Diagram		Hubs
12/6/2003 2:10PM Device 157 ☐ Locked ☐ On ☐ Off Intensity 100% 60% 0% Office - Floor 1 + Room 1 + Room 2 + Room 3 + Room 4 + Room 5 + Room 6 + Room 7 + Floor 2 + Floor 3 + Floor 4 + Floor 5 + Floor 6 + Floor 7 + Floor 8	Office + Hub 2 + Hub 1 + Hub 4 + Hub 3 + Hub 5 + Hub 6 + Hub 7 + Hub 8 + Hub 9 + Hub 10 + Hub 11 + Hub 12 + Hub 13 + Hub 14 + Hub 15 + Hub 16 + Hub 17	

Device Properties

Device Config

Device Info

☐ On ☒ Off

Device Name: Device 157

Change Icon

History

☐ Locked

OK

Cancel

Help

Mon

Tues

Wed

Thurs

Fri

Sat

Sun

12AM

6AM

12PM

6PM

12AM

For Help, Press F1

Start

No Schedule Defined Press

"Record" To Make New Schedule

Press "Load" To Load Existing One.

NUM

8:31 AM




FIG. 8D





FIG. 8E



The image shows a 'Device Properties' dialog box with a close button (X) in the top right corner. It contains two tabs: 'Device Config' and 'Device Info'. The 'Device Config' tab is selected. Inside this tab, there are four labels and their corresponding values in text boxes:

Label	Value
Install Date:	01.01.2003
Hours In Use:	2433
Life Epectency:	20.09.2003
Last Config Change:	02.01.2003

At the bottom of the dialog box, there are four buttons: 'OK', 'Cancel', 'Apply', and 'Help'.

FIG. 8F




FIG. 9




FIG. 10

12/13

Server Monitor		Interval Of Dates And Time For Searching	
Site Navigation	850	SAVE Changes	852
Name [Hub 1]		From [9/7/2004 10:00:00 AM]	
IP Address [192.68.1.254]		UNDO Changes	Apply
Inner Site Navigation	854	To [9/15/2004 10:00:00 PM]	
Date And Time [9/8/004 11:00:00 AM]			
Lamp Number [1]		Lamp Current [25] A	Main Voltage [128.3] V
		Lamp Voltage [127.8] V	PFC Voltage [128.3] V
		Temperature [120] F	
Parameters In Dynamics			
Lamp Current	856	Lamp Voltage	860
Current A		Voltage V	
4.00		130.2	
3.00		124.5	
2.00		118.8	
1.00		113.1	
0.00		107.5	
0		0	
20		20	
40		40	
60		60	
80		80	
Measure Number		Measure Number	
Main Voltage		PFC Voltage	
Voltage V		Voltage V	
130.9		129.7	
124.7		127.9	
118.6		126.1	
112.4		124.4	
106.3		122.6	
0		0	
20		20	
40		40	
60		60	
80		80	
Measure Number		Measure Number	

Client 2

Site Navigation

Name

Site Name 0

875

Unit1 | Unit2 | Unit3 | Unit4 | Expenses

881

SAVE Changes

UNDO Changes

Interval Of Dates And Time For Searching

877

From

9/7/2004 10:00:00 AM

To

9/15/2004 10:00:00 PM

Apply

Current State

Lamp Current A

Lamp Voltage V

Main Voltage V

Temperature F

Lamp Wattage W

Lamp1

4.5

127.8

128.3

143.5

575.1

Lamp2

4.6

127.8

128.3

143.5

575.1

Lamp3

4.5

127.8

128.3

143.5

575.1

Lamp4

4.7

127.8

128.3

143.5

575.1

880

Lamp Current

Current A

0

20

40

60

80

Measure Number

Lamp Voltage

Voltage V

0

20

40

60

80

Measure Number

Lamp Wattage

Wattage W

0

20

40

60

80

Measure Number

Temperature

Temperature F

0

20

40

60

80

Measure Number

Cost

Cost \$

0

20

40

60

80

Measure Number