

FIG. 1


100

FIG. 2




FIG. 3

120

GENUINE POSITION COORDINATES	TRAVEL STATE OF VEHICLE	POSITION COORDINATES (LONGITUDE AND LATITUDE) OF POSITIONING RESULT
(Ea、Na)	GOING STRAIGHT	(Eb、Nb)
(Ea、Na)	TRAVELING WHILE TURNING RIGHT	(Ec、Nc)
(Ed、Nd)	STOPPED	(Eb、Nb)
⋮	⋮	⋮

FIG. 4

121

CHARGE POINT ID	POSITION COORDINATES (LONGITUDE AND LATITUDE)	FEE (YEN)
B001	(Ef、Nf)	200
B002	(Eg、Ng)	190
B003	(Eh、Nh)	190
⋮	⋮	⋮
⋮	⋮	⋮
⋮	⋮	⋮

FIG. 5




FIG. 6




FIG. 7




FIG. 8




FIG. 9

