

anti-theft mode

Note:

The phone is in the anti-theft mode, and can be unlocked only when a correct anti-theft password is inputted

Buddies, I am the owner of the phone! To return the cellular phone, please dial the cellular phone number: 13800138000!

anti-theft mode

Note:

The phone is in the anti-theft mode, and can be unlocked only when a correct anti-theft password is inputted

Buddies, I am the owner of the phone! To return the cellular phone, please dial the cellular phone number: 13800138000!

FIG. 3

anti-theft mode

Note:

The phone is in the anti-theft mode, and can be unlocked only when a correct anti-theft password is inputted

Please return the cellular phone as quickly as possible! To return the cellular phone, please dial the cellular phone number: 13800138000!

401

anti-theft mode

Note:

The phone is in the anti-theft mode, and can be unlocked only when a correct anti-theft password is inputted

402

403

Please return the cellular phone as quickly as possible! To return the cellular phone, please dial the cellular phone number: 13800138000!

FIG. 4