

108
LOCAL DEVICE
LOCAL DATA
124
102
NETWORK
104
SYNCHRONIZATION DEVICE
REMOTE DEVICE
REMOTE DATA
120
106
110
CENTRAL DEVICE
SYNCHRONIZATION APPLICATION
112
DATABASE
CENTRAL DATA
114
DATABASE
CENTRAL DATA
114
122
122
100

Fig. 1



212
PRINT OUTPUT
PRINTER
210
206
204
TO/FROM NETWORK
NETWORK INTERFACE
CONTROLLER
REMOTE DEVICE INTERFACE
TO/FROM REMOTE DEVICE
202
208
USER INTERFACE
104
USER I/O

Fig. 2



SYNCHRONIZATION DEVICE
SYNCHRONIZATION APPLICATION
PROVIDE SYNCHRONIZATION DEVICE
302
UPDATE CENTRAL DATA
320
COUPLE REMOTE DEVICE TO SYNCHRONIZATION DEVICE
304
RECEIVE REMOTE DATA
306
INITIATE SYNCHRONIZATION
308
VERIFY ACCESS
322
PROMPT FOR SYNCHRONIZATION MODE
310
DETERMINE DATA PRIORITIES
324
SYNCHRONIZE DATA
326
RECEIVE SYNCHRONIZED DATA
312
TRANSMIT SYNCHRONIZED DATA
328
PROMPT FOR PRINTING
314
UPDATE LOCAL DATA
330
SEND SYNCHRONIZED DATA TO PRINTER
316

Fig. 3