


FIG. 1



2/10
FIG. 2A





FIG. 2B



3/10
FIG. 3




FIG. 4


Diagram illustrating the TRACK SHAPE DATABASE (66) structure, showing a table with two columns: DISTANCE FROM STARTING POINT and CHANGE IN RADIUS OF CURVATURE.

DISTANCE FROM STARTING POINT	RADIUS OF CURVATURE
0	RIGHT · R1000
100	STRAIGHT LINE
1000	LEFT · R2000
⋮	⋮

Detailed view of the TRACK SHAPE DATABASE (66) structure, showing a table with two columns: DISTANCE FROM STARTING POINT and CHANGE IN RADIUS OF CURVATURE.

DISTANCE FROM STARTING POINT	CHANGE IN RADIUS OF CURVATURE
0	△△
⋮	⋮
100	□□
1000	△□
⋮	⋮
⋮	⋮

4/10
FIG. 5







FIG. 7



7/10
FIG. 8A







FIG. 8B



8/10
FIG. 9



9/10
FIG. 10



10/10
FIG. 11

