

20
Connecting secondary device to host
22
Redefining user interface element using application
24
Reviewing redefining user interface element
26
Determining support for redefined user interface element
28
Approving transfer for redefined user interface element
30
Incorporating user interface element on secondary device
32

Figure 1



Device Customization Tool
Select a device:
ZEN Vision: M
New
Open...
Save
Save As...
Theme
Mode
Radio
Layout
Startup
Text
Option Menu
Search Bar
Background
Highlight Bar
Scroll Bar
Message Box
Change...
Font color:
Change...
Title bar font color:
Change...
Restore Default
Transfer Preview...
Transfer...
Close
MENU
Videos
Photos
Music
Settings
Recording
FM Radio
Extras
Browse
Now Playing
Voice
MENU
42
40
41
63
61
77
79
69
25
73
60
71
78
320
300
56
44
54
52
50
76
74
72
122
48
58
70
59
46

Figure 2



66
64
64
62
Open
Cancel
Preview
Look in:
Interesting Stuff
My Recent Documents
Desktop
My Documents
My Computer
My Network
File name:
Files of type:
Picture Files (*.bmp;*.gif;*.jpg;*.png)

Figure 3



Device Customization Tool
Select a device:
ZEN Vision: M
New
Open...
Save
Save As...
Theme
Mode
Radio
Layout
Startup
Text
Option Menu
Background
Highlight Bar
Scroll Bar
Message Box
Search Bar
Change...
Change...
Font color:
Vibrant
Close
Transfer...
Transfer Preview...
Restore Default
MENU
Video
Music
Photo
Radio
Settings
42
40
41
63
61
77
79
75
73
71
300
320
78
124
56
54
44
52
50
48
58
70
69

Figure 4




Figure 5



Device Customization Tool
Select a device:
ZEN Vision: M
Theme
Mode
Radio
Layout
Startup
Text
Option Menu
Message Box
Search Bar
Scroll Bar
Highlight Bar
Background
New
Open...
Save
Save As...
Change...
Change...
Thumb
Background
Close
Transfer...
Transfer Preview...
Restore Default
42
40
41
43
61
77
79
69
75
73
71
300
56
44
54
52
50
48
58
70
74
76
78
320
126

Figure 6



Device Customization Tool
Select a device:
ZEN Vision: M
Theme
Mode
Radio
Layout
StatTip
Text
Option Menu
Search Bar
Background
Highlight Bar
Scroll Bar
Message Box
Background color
Font color:
Change...
Change...
Delete This Track ?
New
Open...
Save
Save As...
Close
Transfer...
Transfer Preview...
Restore Default
Yes
No
Delete this Track ?
42
41
40
63
61
77
79
69
75
73
71
300
320
78
128
56
44
54
52
50
48
58
70

Figure 7



Device Customization Tool
Select a device:
ZEN Vision: M
Theme
Mode
Radio
Layout
Startup
Text
Option Menu
Search Bar
Message Box
Scroll Bar
Highlight Bar
Background
Text color
Highlight color
Change...
Change...
New
Open...
Save
Save As...
Close
Transfer...
Transfer Preview...
Restore Default
Dan
40
41
42
44
48
50
52
54
58
63
69
71
73
75
77
78
79
130
300
320

Figure 8



Device Customization Tool
Select a device:
ZEN Vision: M
New...
Open...
Save
Save As...
Theme
Mode
Radio
Layout
Startup
Text
Option Menus
You can change your player to the following functional mode. Under this mode you can also reconfigure the function of each button.
Select a mode
Radio
Video Player
Picture Frame
Shuffle
Party Mode
Audio Recorder
Audio Book Reader
Default
Customize a button
Select a button:
Select a function:
Record
Restore Default
Transfer Preview...
Transfer...
Close
42
40
41
64
75
73
71
300
56
44
54
52
50
48
142
144
140
63
61
77
79

Figure 9



Device Customization Tool
Select a device:
ZEN Vision:M
New
Open...
Save
Save As...
Theme
Mode
Radio
Layout
Startup
Text
Option Menu
You can set the radio presets to the country where you reside. If your favorite station is not in the list you can change the radio frequency and station names in the list box below.
Radio source:
FM
Country Preset:
XXXXXX
1. 103.95 MHz Kiss Radio
2. 77.77 MHz Channel X
3. 48.55 MHz Channel Z
4. 32.33 MHz Top Hits
5. 93.2 MHz Classic Channel
6. 48.4 MHz XYZ
7. 88.8 MHz ABC
8. 101 MHz Yur Station
9. 99.9 MHz Joy
10. 65.7 MHz Happy Hour
11. 57.6 MHz XXX
Restore Default...
Transfer Preview...
Transfer...
Close
42
40
41
63
61
77
79
50
54
44
56
300
71
73
75
69
320
52
154
150
152
48

Figure 1D



Device Customization Tool
Select a device:
ZEN Vision: M
New
Open...
Save
Save As...
Theme
Mode
Radio
Layout
Startup
Text
Option Menu
Recording Screen
Radio Screen
Now Playing Screen
Context Menu
Title Bar
Select the following options to rearrange the Title bar layout:
Align to the top (Default)
Align to the bottom
Change the text layout to right-to-left reading order. Note that this setting will affect all screen layouts.
MENU
Videos
Restore Default
Transfer Preview...
Transfer...
Close
42
40
41
63
69
73
73
71
30
56
44
54
52
50
48
160
166
162
164
170
198
172
174
179
177

Figure 11



Device Customization Tool
Select a device:
ZEN Vision: M
New...
Open...
Save
Save As...
Theme
Mode
Radio
Layout
Startup
Text
Option Menu
Now Playing Screen
Radio Screen
Recording Screen
Title Bar
Context Menu
You can change the location of the context menu according to your preference.
Align to the right (Default)
Align to the left
Menu item 1
Menu item 2
Menu item 3
Menu item 4
Menu item 5
Menu item 6
Normal
Repeat Track
Repeat All
Shuffle
Track Once
Restore Default
Transfer Preview...
Transfer...
Close
42
40
41
50
52
54
44
56
30
71
73
75
69
48
170
184
118
166
178
63
61
77
79

Figure 12



Device Customization Tool
Select a device:
ZEN Vision: M
New
Open...
Save
Save As...
Theme
Mode
Radio
Layout
Startup
Text
Option Menu
Title Bar
Context Menu
Now Playing Screen
Radio Screen
Recording Screen
You can rearrange the location of the items in the screen by drag and drop.
Mode
Audio track information
Status and playback progress
Now playing
Transfer...
Transfer Preview...
Restore Default
Close

Figure 13



Device Customization Tool
Select a device:
ZEN Vision: M
New
Open...
Save...
Save As...
Theme
Mode
Radio
Layout
Startup
Text
Option Menu
Title Bar
Context Menu
Now Playing Screen
Radio Screen
Recording Screen
You can rearrange the location of the items in the screen by drag and drop.
Antenna
Mode
Radio Frequency Information
Preset #
Station Name
Restore Default
Transfer Preview...
Transfer...
Close

Figure 14



Device Customization Tool
Select a device:
ZEN Vision: M
Theme
Mode
Radio
Layout
Startup
Text
Option Menu
Recording Screen
TitleBar
Context Menu
New Playing Screen
Radio Screen
New
Open...
Save
Save As...
You can rearrange the location of the items in the screen by drag and drop.
Microphone
VU Meter
Recording elapse time
Remaining space for recoding
Close
Transfer...
Transfer Preview...
Restore Default
42
43
41
63
61
77
79
69
75
73
71
56
54
52
50
44
46
60
66
70
204
202
200

Figure 15



Device Customization Tool
Select a device:
ZEN Vision: M
New
Open...
Save
Save As...
Theme
Mode
Radio
Layout
Startup
Text
Option Menu
Animation Sequence
You can change the startup animation sequence by replacing one or more pictures below. To reposition the sequence, drag one or more pictures and drop it to the new position.
Change...
Start Preview
Restore Default
Transfer...
Transfer Preview
Close
40
50
52
54
44
48
300
56
71
73
75
69
320
212
214
216
77
79
61
63

Figure 16



Device Customization Tool
Select a device:
ZEN Vision: M
New
Open...
Save
Save As...
Theme
Mode
Radio
Layout
Startup
Text
Option Menu
You can customize the following text strings in the device.
Original
My Text
Music Library
Now Playing
Playlists
Albums
Artists
Genres
All Tracks
Recordings
Bookmarks
DJ
Album of the Day
Random Play All
Most Popular
Rarely Heard
Photos
My Slideshows
Pictures
Videos
Video
TV
FM Radio
Microphone
Extras
My Songs
Play Queue
Playlists
Albums
Artists
Genres
All Songs
Recordings
Bookmarks
DJ
Album of the Day
Random Play All
Most Hip
Rarely Heard
Photos
My Slideshows
Pictures
Videos
Video
TV
My Radio
My Mic
Extras
Restore Default
Transfer Preview
Transfer...
Close
40
44
48
50
52
54
56
61
63
71
73
75
77
79
302
304
306
308
310

Figure 17



Device Customization Tool
Select a device:
ZEN Vision: M
New
Open...
Save
Save As...
Theme
Mode
Radio
Layout
Startup
Text
Option Menu
You can customize the option menu items here.
Option Menu:
Now Playing
Seek To
Set Bookmark
View Details
Lookup Artist
Remove...
Save As Playlist
Play Mode
Purchase this
Volume
Main Menu
— (Separator) —
Add =>
<= Remove
Move Up
Move Down
Restore Default
Transfer Preview...
Transfer...
Close
40
48
50
52
54
56
44
320
322
300
328
330
332
324
326
71
73
75
69
77
79
61
63

Figure 18



Menu
Albums
Artists
Album name
Delete album from Library?
Yes
No
Extras
System
FM Radio
STEREO
FM 103.95 MHz
Preset 1
Kiss Radio
Now Playing
5/32
The Da Vinci Code
Audiobook
Dan Brown
00:20:49
-00:34:32
Now Playing
5/12
Normal
Repeat All
Shuffle
Shuffle Repeat
Track Once
00:02:49
100

Figure 19




Figure 20a




Figure 20b