

602
WED
Sensor
302
Engine (ECM)
Steering Actuator
606
WED
2000
400
Distribution Module
Power And Comms Cable
Battery
Communications Bus
Gyroscopic Stabillizer (Optional)
Sensors
202
Multi Function Display
Software Module
Keypad (Optional)
OPERATIONAL CONSOLE
200

FIG. 1



602
Water Flow From Vessel Movement

FIG. 2



602
Water Flow From Vessel Movement

FIG. 3




FIG. 4




FIG. 5