


FIG. 1 (CONNECTION OF A SINGLE USB DEVICE TO A HOST DEVICE)

(PRIOR ART)




FIG. 2

(CONNECTION OF MULTIPLE USB DEVICES TO A HOST DEVICE)

(PRIOR ART)




FIG. 3
(SINGLE USB DEVICE REPLACED BY ANOTHER DEVICE OF THE SAME MODEL)

(PRIOR ART)



USB DEVICE 40
MEMORY 45
43
MODEL: POSJET 1000
41
SERIAL NUMBER:
SN02000001
42
USB IDENTIFIER:
"POSJET 1000"
48
HOST DEVICE 50
COM3
52
SOFTWARE
APPLICATION
55

FIG. 4



REPLACEMENT USB DEVICE 60
MEMORY 65
43
MODEL: POSJET 1000
61
SERIAL NUMBER:
SN02000025
42
USB IDENTIFIER:
"POSJET 1000"
48
HOST DEVICE 50
COM3
52
SOFTWARE
APPLICATION
55

FIG. 5



USB DEVICE 40
MEMORY 45
43
MODEL: POSJET 1000
41
SERIAL NUMBER:
SN02000001
42
USB IDENTIFIER:
"POSJET 1000"
48
HOST DEVICE 50
COM3
52
SOFTWARE
APPLICATION
55
USB DEVICE 60
MEMORY 65
43
MODEL: POSJET 1000
61
SERIAL NUMBER:
SN02000025
42'
USB IDENTIFIER:
"POSJET 1000A"
48
COM4
53
CONFIGURATION
APPLICATION
58

FIG. 6