

FIG. 1




FIG. 2




FIG. 3




FIG. 4A

?

x

Printer

Printer Name (N):

Printer1

Property (P)

Search Printer (D)...

Print Range

☒ All (A)
 ☐ Current Page (E)
 ☐ Selected Part (S)

☐ Page Designation (G):

Designate page numbers by separating with commas like 1,3,6, or designate page range like 5-12. Designation of pages and sections are also available like p1s1,p1s2 or p1s3-p8s3.

Number of Print Copies

Number of Copies (C):

1

1

2

3

☒ Print with Collation (I)

Scale

Print Target (W):

Document Containing Contents of Changes and Comments

Print Designation (R):

All Pages

Option (O)...

Number of Pages per Sheet (H):

1 Page

Sheet Size Designation (Z):

No Designation for Magnification

OK

Cancel



FIG. 4B

Printer1 Print Setting

Page Setting | Finish | Sheet Feed | Print Quality

Favorite (F): Standard Setting Add (1)... Edit (2)...

Output Method (M): Print




A4 (Magnification: Automatic)

☐ Device Preview (W)
☐ Check Setting (V)

☐ Stamp (K)
 Stamp Name (T)

☐ Designate Magnification (N)
 Magnification (G) 100% (25 to 200)

Page Layout (L): 1 1 in 1 (Standard)

☐ Document Size (S): A4
☐ Output Sheet Size (Z): Same as Document Size
 Number of Copies (C): 1 Copies (1 to 9999)
 Print Orientation (Q): ☒ Portrait ☐ Landscape

☐ Stamp (K)
 Stamp Name (T)

☐ Device Preview (W)
☐ Check Setting (V)

User-designated Sheet (U)... Page Option (E)... Return to Standard (R)

FIG. 5




FIG. 6




FIG. 7A




FIG. 7B




FIG. 8




FIG. 9





FIG. 10

Printer1 "Document1" Print Setting [X]



Device Preview (W)

Check Setting (V)

Print Sheet Size (S): Same as Document Size ▾

Page Layout (L): 1 1 in 1 (Standard) ▾

☐ Designate Magnification (N)
Magnification (G) 100 % (25 to 200)

☐ Stamp (K) Confidential ▾
Edit Stamp (I)...

☐ Print with Binding (H) Detail of Binding (D)...

Binding Orientation (B):
☐ Long-edge Binding (Left) ▾ Binding Margin (E)...

Sheet Feed Method (A):
☐ Print All Pages on Same Sheets ▾

☐ Print on Back Side of Printed Sheet (Q)

Sheet Name (Y): No Designation ▾

Sheet Type (E): Normal Paper ▾

Print Quality (Q):
☐ Fine ☒ Standard ☐ User Setting Setting (I)...

Execute Printing (R) Stop Printing (C)

FIG. 11A




FIG. 11B





FIG. 12



The image shows a printer settings menu for 'Printer1'. On the left is a large, partially visible circular icon. The menu is organized into sections: 'Page Layout' with 'Orientation' (Portrait), 'Duplex Printing' (Print on One Side), and 'Collation' (Collate); 'Paper And Quality' with 'Media Size' (A4); and 'Input Bin' (Automatic). The 'Output Options' section is expanded, showing a list of options: Manual, Cassette 1, Cassette 2, Sheet Type Priority, and Detailed Print Settings. The 'Manual' option is highlighted with a hatched background. A reference number '1301' points to the 'Output Options' list.

Printer1	
Page Layout	
Orientation	Portrait ▾
Duplex Printing	Print on One Side ▾
Collation	Collate ▾
Paper And Quality	
Media Size	A4 ▾
Input Bin	Automatic
Output Options	Manual Cassette 1 Cassette 2 Sheet Type Priority Detailed Print Settings
ColorMode	

1301

FIG. 13

