




Fig. 1




Fig. 2




Fig. 3

SVC Reload via Telco Agent (Part 1 of 2)




Fig. 4a

SVC Reload via Telco Agent (Part 2 of 2)




Fig. 4b

SVU Device and SVU Manager Mutual Authentication (Part 1 of 6)




Fig. 5a

SVU Device and SVU Manager Mutual Authentication (Part 2 of 6)




Fig. 5b

SVU Device and SVU Manager Mutual Authentication (Part 3 of 6)




Fig. 5c

SVU Device and SVU Manager Mutual Authentication (Part 4 of 6)

500




Fig. 5d

SVU Device and SVU Manager Mutual Authentication (Part 5 of 6)

500





Fig. 5e

SVU Device and SVU Manager Mutual Authentication (Part 6 of 6)



SVC Update via SVU (Part 1 of 18)





Fig. 6a

SVC Update via SVU (Part 2 of 18)

600



13/29

611

Fig. 6b

SVC Update via SVU (Part 3 of 18)




Fig. 6c

SVC Update via SVU (Part 4 of 18)

600




Fig. 6d

SVC Update via SVU (Part 5 of 18)

600




Fig. 6e

SVC Update via SVU (Part 6 of 18)




Fig. 6f

SVC Update via SVU (Part 7 of 18)

600




Fig. 6g

SVC Update via SVU (Part 8 of 18)




Fig. 6h

SVC Update via SVU (Part 9 of 18)

600




Fig. 6i

SVC Update via SVU (Part 10 of 18)




Fig. 6j

SVC Update via SVU (Part 11 of 18)

600




Fig. 6k

SVC Update via SVU (Part 12 of 18)




Fig. 6I

SVC Update via SVU (Part 13 of 18)





Fig. 6m



SVC Update via SVU (Part 15 of 18)




Fig. 60

SVC Update via SVU (Part 16 of 18)

600




Fig. 6p

SVC Update via SVU (Part 17 of 18)

600




Fig. 6q

SVC Update via SVU (Part 18 of 18)

600




Fig. 6r