




Fig. 1




Fig. 2




Fig. 3




Fig. 4




Fig. 5




Fig. 6

The diagram shows a table with five columns. Above the table, there are labels with arrows pointing to specific parts: '70' points to the entire table structure, '72' points to the 'Source' header, '74' points to the 'Destination' header, '76' points to the 'Method of Traversal' header, '78' points to the 'Details' header, and '80' points to the 'Cost' header.

Source	Destination	Method of Traversal	Details	Cost
xx01	xx03	Ground	90°, 0°, 1.3m	20s
xx03, gnd	xx03, first	Elevator	ElevatorID:10, first	10s
xx02	xx05	Incline	120°, 20°, 1m	25s

Fig. 7




Fig. 8




Fig. 9





Fig. 10






Fig. 12




Fig. 13a




Fig. 13b




Fig. 14