


Figure 1




Figure 2




Figure 3




Figure 4



Key Pressed
100
Switch OFF, ON, AUTO?
102
OFF
ON
AUTO
104
End
16
Purge Buffer
118
Enable Microphone(s)
Mute Audio Line
120
Switch changed?
NO
106
YES
Start Timer
122
to OFF?
YES
End
110
NO
108
YES
Key Pressed?
124
AUTO
112
NO
YES
Cancel Mute
126
to AUTO
114
NO
Switch Changed?
128
YES
to OFF?
YES
End
132
130
NO
to ON?
134
YES
to ON
136

Figure 5



Microphones
28
35
Buffer
Processor
Timer
39
38
37
Keyboard Driver
Audio System
36
65

Figure 6




Figure 7




Figure 8




Figure 9




Figure 10



Digital Data Connector
20
14
Inverter
606
Primary Coil
604
Secondary Coil
608
23
Rectifier&
Charging Circuit
610
Batteries
612

Figure 11




Figure 12




Figure 13




Figure 14




Figure 15




Figure 16

26 JAN 2007




Figure 17




Figure 18




Figure 19



Figure 20




Figure 21




Figure 22




Figure 23




Figure 24




Figure 25




Figure 26




Figure 27




Figure 28




Figure 30




Figure 29




Figure 31




Figure 32




Figure 33




Figure 34




Figure 35




Figure 36




Figure 37