

FIG. 1






FIG. 2



3/11



4/11

FIG. 4

400

402

HYDRO QTY 416 AUTO PG 1 OF 2

418

P 420 ~ T 422 ~ L

TEMP SYS: XXXX XXXX XXXX

CAPACITIES: STATUS X.XX LO X.XX OF X.XX RF

SELECTION XXXX XXXX XXXX

FILL POINT XXX XXX XXX 404

OPERATION OFF BLO OFF

BLD SELECT OFF BLO

SEL PICK -- SEL SEL

406

ELEC GEARS: POSITION XXXX 408 -- 410 XXXX 411

PRESSURE XXXX 412 -- 414 XXXX 415

TIME ROUND OFF -- ON

SELECTION XXXXX -- XXXXX

OPERATION XXX -- XXX

G1 G2

PUMP SPECS: STATUS XXXX XXXX XXXX XXXX

SELECTION XXXX XXXX XXXX XXXX

FILL POINT AUTO ON OFF AUTO

OPERATION RUN OFF RUN OFF

TIME ROUND XXXX XXXX XXXX XXXX

LIFE XXXXX XXXXX XXXXX XXXXX

MINUTES XXXX XXXX XXXX XXXX

WING PUMP: POSITION -- XXXX --

PRESSURE -- XXXX --

TIME ROUND -- UNLKD --

AUTO EVENT MESSAGE POS XX XXX XX TIME XX : XX : XX

PREV PAGE NEXT PAGE

5/11

FIG. 5

400 504 500

ESRP AUTO PG 1 OF 2

513 LEFT WING 516 511 518 RIGHT WING 514

515 X Y 516 518 X Y 520

XXX.X XXX.X X₁ XXX.X XXX.X

XXX.X XXX.X 506 X₂ XXX.X XXX.X

504 508 XXX.X XXX.X 509 C/T 510 XXX.X XXX.X 512

502 XXX.X XXX.X D_{POS} XXX.X XXX.X

XXX.X XXX.X D_{T4} XXX.X XXX.X

XXX.X XXX.X H₁₅ XXX.X XXX.X

XXX.X XXX.X H₂₇ XXX.X XXX.X

XXX.X XXX.X H₄ XXX.X XXX.X

XXX.X XXX.X THT XXX.X XXX.X

XXX.X XXX.X TJT XXX.X XXX.X

XXX.X XXX.X BTV XXX.X XXX.X

XXX.X XXX.X MBV XXX.X XXX.X

XXX.X XXX.X QSSS XXX.X XXX.X

XXX.X XXX.X QTEMP XXX.X XXX.X

XXX.X XXX.X ABT FCC XXX.X XXX.X

XXX.X XXX.X LBT FCC XXX.X XXX.X

XXX.X XXX.X SSS XXX.X XXX.X

XXX.X XXX.X SUB T XXX.X XXX.X

XXX.X XXX.X SUB P XXX.X XXX.X

XXX.X XXX.X SUB BLT XXX.X XXX.X

XXX.X XXX.X BLUE BLT XXX.X XXX.X

XXX.X XXX.X OUT GF 1 XXX.X XXX.X

XXX.X XXX.X OUT GF 2 XXX.X XXX.X

XXX.X XXX.X HTC 1 XXX.X XXX.X

XXX.X XXX.X HTC 2 XXX.X XXX.X

XXX.X XXX.X HTC 3 XXX.X XXX.X

XXX.X XXX.X HTC 4 XXX.X XXX.X

XXX.X XXX.X TART XXX.X XXX.X

AUTO EVENT MESSAGE POS XX XXX XX TIME XX:XX:XX

PREV PAGE NEXT PAGE

6/11

FIG. 6

400

600

610 [QUANTITY]

AUTO PG 1 OF 2

604

US STANDARD UNITS

TOP DENSITY XXX.X

TOP VOLUME XXXXX

TOP QUANTITY X.XX

606

608

LEFT SUB		CENTER SUB		RIGHT SUB	
XXX.X	VOL	XXX.X	VOL	XXX.X	
XXXXX	DEN	XXXXX	DEN	XXXXX	
X.XXX	QUAN	X.XXX	QUAN	X.XXX	
FN BAN		FN BAN		FN BAN	
XXX.XXx	1	XXX.XXx	1	XXX.XXx	
XXX.XXx	2	XXX.XXx	2	XXX.XXx	
XXX.XXx	3	XXX.XXx	3	XXX.XXx	
XXX.XXx	4	XXX.XXx	4	XXX.XXx	
XXX.XXx	5	XXX.XXx	5	XXX.XXx	
XXX.XXx	6	XXX.XXx	6	XXX.XXx	
XXX.XXx	7	XXX.XXx	7	XXX.XXx	
XXX.XXx	8	XXX.XXx	8	XXX.XXx	
XXX.XXx	9	XXX.XXx	9	XXX.XXx	
XXX.XXx	10	--	10	XXX.XXx	
XXX.XXx	11	--	11	XXX.XXx	
XXX.XXx	12	--	12	XXX.XXx	
XXX.XXx	13	--	13	XXX.XXx	
XXX.XXx	14	--	14	XXX.XXx	
XXX.XXx	FNT X	XXX.XXx	FNT X	XXX.XXx	
--	FNT Y	XXX.XXx	FNT Y	--	
XXXX	SET ZTP	XXXXX	SET ZTP	XXXX	
XXXc	SET TEMP	XXXc	SET TEMP	XXXc	

602

AUTO EVENT MESSAGE

POS XX XXX XX

TIME XX : XX : XX

PREV PAGE

NEXT PAGE

7/11

FIG. 7





FIG. 8



9/11




FIG. 9

10/11




FIG. 10

11/11

FIG. 11

