

100
103
104
105
TARGET AGENT
MASTER TARGET AGENT
EBTDS/ ECT.
109
COMMAND LINE
102
101
111
SCRIPT INTERPRETER
CORE
GUI
SUN WORKSTATION
106
112
108
107
HFI MODEL
ADI EMULATOR

FIG-1



100
109
COMMAND LINE
GUI
108
102
SCRIPT INTERPRETER
SUN WORKSTATION
106
101
CORE
103
TARGET AGENT
104
MASTER TARGET AGENT
105
DISTRIBUTED PROCESSOR
110
HIFI MODEL
SIMULATION MODULE

FIG-1