


Figure 1




Figure 2



Toggle switch 22 on media player 20
50
Connecting first end 26 of cable 24 to port 30 on media player 20
52
Connecting second end 28 of cable 24 to port 32 on computer 34
54
Firmware detects connection of media player 20 to computer 34
56
Current is drawn into media player 20
58

Figure 3



Toggle switch 22 on media player 20
60
Volume level during playback of content in media player 20 lowered to predetermined level
62
Toggle switch 22 on media player 20
64
Volume level during playback of content in media player 20 automatically reverts to original level after predetermined length of time
68
Volume level during playback of content in media player 20 reverts to original level
66

Figure 4