




FIG. 1




FIG. 2





FIG. 3






FIG. 5




FIG. 6




FIG. 7




FIG. 8




FIG. 9




FIG. 10




FIG. 11




FIG. 12




FIG. 13

14→





FIG. 14




FIGURE 15




FIGURE 16




FIGURE 17




FIGURE 18

Ex. 3b - Gauge Error after Removal/Attachment at Varying INCREASING Pressures




FIGURE 19




FIGURE 20

**Ex. 4b - Replacement instruments - pre-charged
at 200 psi - Swap at 200 psi**




FIGURE 21

**Ex. 4c - Replacement instrument pre-charged at 0
psi - Swap at 200 psi**




FIGURE 22




FIGURE 23




FIGURE 24




FIGURE 25




FIGURE 26