

FIG. 1






FIG. 2**FIG. 3**

FIG. 4




FIG. 5




FIG. 6

LWM2M Access control 2									
Device 3									
Instance 0									
Manufacturer ?	/3/0/0	Read	Write	Execute	Observe	Unobserve	Leshan Demo Device		
Model Number ?	/3/0/1	Read	Write	Execute	Observe	Unobserve	Model 500		
Serial Number ?	/3/0/2	Read	Write	Execute	Observe	Unobserve	LT-500-000-0001		
Firmware Version ?	/3/0/3	Read	Write	Execute	Observe	Unobserve	1.0.0		
Reboot ?	/3/0/4	Read	Write	Execute	Observe	Unobserve			
Factory Reset ?	/3/0/5	Read	Write	Execute	Observe	Unobserve			
Available Power Sources ?	/3/0/6	Read	Write	Execute	Observe	Unobserve			
Power Source Voltage ?	/3/0/7	Read	Write	Execute	Observe	Unobserve			
Power Source Current ?	/3/0/8	Read	Write	Execute	Observe	Unobserve			
Battery Level ?	/3/0/9	Read	Write	Execute	Observe	Unobserve	11%		
Memory Free ?	/3/0/10	Read	Write	Execute	Observe	Unobserve	210793KB		
Error Code ?	/3/0/11	Read	Write	Execute	Observe	Unobserve			
Reset Error Code ?	/3/0/12	Read	Write	Execute	Observe	Unobserve			
Current Time ?	/3/0/13	Read	Write	Execute	Observe	Unobserve	Jun 21, 2017 7:08:27 AM		
UTC Offset ?	/3/0/14	Read	Write	Execute	Observe	Unobserve	+09		
Timezone ?	/3/0/15	Read	Write	Execute	Observe	Unobserve	Asia/Tokyo		
Supported Binding and Modes ?	/3/0/16	Read	Write	Execute	Observe	Unobserve	U		

600