




FIGURE 1




FIGURE 2

300 

3/8

314			
302		304	306
Sensor A		Actuator B	Sensor C
308 Fault Code 1	> 135 RPM	-	> 65° C
310 Fault Code 2	-	> 1000 V	< 55° C
312 Fault Code 3	> 100 RPM	> 750 V	> 60° C

FIGURE 3




FIGURE 4




FIGURE 5

6/8




FIGURE 6




FIGURE 7

8/8




FIGURE 8