




[図1]



[図2]



[図3]




[図4]


待機位置のメイン候補		
ID	位置	優先度
001	(X1,Y1)	高
002	(X2,Y2)	中
003	(X3,Y3)	中
004	(X4,Y4)	低

待機位置のサブ候補		
ID	位置	内容
011	(X5,Y5)	充電位置
012	(X6,Y6)	搬送発生位置
013	(X7,Y7)	通過低頻度位置


[図5]




[図6]



[図7]



[図8]



[図9]

