
10
NCR CAP
30
NCR CAP?
12
NO
YES
DISPENSE WITH NCR CAP
14
CR CAP OR CP CAP?
16
CR CAP
CP CAP
CR ELEMENT
50
ASSEMBLE CR ELEMENT WITH NCR CAP
18
CP ELEMENT
70
ASSEMBLE CP ELEMENT WITH NCR CAP
22
DISPENSE WITH CR CAP
20
DISPENSE WITH CP CAP
24
CUSTOMER USES KEY?
21
NO
YES
CUSTOMER MUST USE KEY SCREW CP CAP ON/OFF
25
CUSTOMER SCREWS CR CAP ON/OFF W/O KEY
21a
CUSTOMER SCREWS CR CAP ON/OFF WITH KEY
21b
KEY
90
KEY
90

FIG. 1



FIG. 2



FIG. 3



FIG. 4



FIG. 4A



FIG. 4C



FIG. 4B



FIG. 5



FIG. 5A


56
58
52
64
57
50
53, 54
64
53, 54
54, 55
64
68
58
64
CLOSE TIGHTLY
OPEN PUSH DOWN & TURN

FIG. 6


60
58
54, 55
64
53, 54
57
56
58
68
60

FIG. 7



FIG. 8



FIG. 9



FIG. 9A



FIG. 9B



FIG. 10



FIG. 10A



FIG. 11



FIG. 12



FIG. 13



FIG. 13A



FIG. 14



FIG. 15



FIG. 16



FIG. 17



FIG. 18



FIG. 17A


110
NCR CAP
130
NCR CAP?
112
NO
YES
DISPENSE WITH NCR CAP
114
CR CAP OR CP CAP?
116
CR CAP
CP CAP
CR ELEMENT
150
ASSEMBLE CR ELEMENT WITH NCR CAP
118
CP ELEMENT
170
ASSEMBLE CP ELEMENT WITH NCR CAP
122
NCR MODE OR CR MODE
119
NCR MODE OR CP MODE
123
NCR MODE
CR MODE
CP MODE
CONVERT TO NCR MODE
119a
CONVERT TO CR MODE
119b
CONVERT TO NCR MODE
123a
CONVERT TO CP MODE
123b
DISPENSE WITH CR CAP IN NCR MODE
120a
DISPENSE WITH CR CAP IN CR MODE
120b
DISPENSE WITH CP CAP IN NCR MODE
124a
DISPENSE WITH CR CAP IN CR MODE
124b
CUSTOMER USES KEY?
121
NO
YES
CUSTOMER SCREWS CR CAP ON/OFF W/O KEY
121a
CUSTOMER SCREWS CR CAP ON/OFF WITH KEY
121b
KEY
190
KEY
190
CUSTOMER MUST USE KEY TO SCREW CP CAP ON/OFF

FIG. 19



FIG. 20



FIG. 21



FIG. 21B



FIG. 21A



FIG. 22



FIG. 23



FIG. 23A



FIG. 24



FIG. 25



FIG. 25A