




FIG. 1




FIG. 2

The screenshot shows a mobile application interface titled "Add A Vehicle". The interface includes the following elements:

- Header:** A dark bar with a back arrow on the left and the title "Add A Vehicle" in the center.
- Form Fields:**
 - Car Model:** Labeled "Car Model", with the placeholder text "Please select a model (optional)" and a right-pointing arrow.
 - Query City:** Labeled "Query City", with the placeholder text "Please select one or more cities" and a right-pointing arrow.
 - License Plate Number:** Labeled "License Plate Number", with a dropdown menu showing "JIN" and a checkmark, followed by the placeholder text "Please enter license plate number".
 - Engine Number:** Labeled "Engine Number", with the placeholder text "Please enter engine number" and a question mark icon.
 - Vehicle Identification Number:** Labeled "Vehicle Identification Number", with the placeholder text "Please enter vehicle identification number" and a question mark icon.
- Note Section:** Labeled "Note", with the placeholder text "Please enter a nickname of the car (optional)". Below this is a grid of buttons containing Chinese license plate characters.

License Plate Character Grid:

JIN	HU	JE	SU	AU	LU	GIN	GI	YU
TUN	YUE	LIO	GEE	HAE	WAN	UR	SAN	GAN
MIN	SEN	GAN	LIN	MON	GEN	GUA	YUN	GUE
CHO	CIN	SEN	TAN					

FIG. 3




FIG. 4




FIG. 5




FIG. 6

The image shows a mobile application interface for adding a hand gesture. At the top is a dark header bar with a back arrow icon on the left and the title "Add A Hand Gesture" in the center. Below the header, the background is a medium gray. The first section contains two lines of white text: "Use a finger to slide any pattern" and "But do not slide a patter of high complexity". A horizontal separator line follows. The next section features a white dialog box with rounded corners. Inside the dialog, the text "Whether there is a need to replace an input password by sliding the pattern" is centered. Below this text are two buttons: "No Need" on the left and "Need" on the right. Below the dialog box, there is a gray rectangular button with the text "Please slide in this region". The bottom portion of the screen is a solid dark gray area.

< Add A Hand Gesture

Use a finger to slide any pattern
But do not slide a patter of high complexity

Whether there is a need to replace an input password by sliding the pattern

No Need Need

Please slide in this region

FIG. 7




FIG. 8




FIG. 9




FIG. 10