FIG.16

DROP CONTROL SIGNAL	DISCHARGE DRIVE SIGNAL	DISCHARGE DROP AMOUNT
MN0	P13	0 pl (FINE DRIVE)
MN1	P11	3 pl (SMALL DROP)
MN2	P11,~~P12~~P13,P14	11 pl (LARGE DROP)
MN3	~~P13~~P12	below 2 pl (VERY SMALL DROP)

FIG.18

DROP CONTROL SIGNAL	DISCHARGE DRIVE SIGNAL	DISCHARGE DROP AMOUNT
MN0	P13	0 pl (FINE DRIVE)
MN1	P11	3 pl (SMALL DROP)
MN2	P11,P12,P13,P14	15 pl (LARGE DROP)
MN3	~~P13~~P12	below 2 pl (VERY SMALL DROP)