


FIG. 1


FIG. 2

FIG. 3

300

LAN SELECTION

301
☒ WIRED LAN

302
☐ WIRELESS LAN

303
☐ WIRED LAN (MAIN) + WIRELESS LAN (SUB)

OK 304


FIG. 4

FIG. 5

501




FIG. 6

600

PRIORITY INTERFACE SETTING

601 ☒ MAIN LINE

602 ☐ SUB-LINE

OK

FIG. 7




FIG. 8

801




FIG. 9

900

TO-BE-TRANSMITTED BEACON SETTING

901 ☒ AIR PRINT BEACON

902 ☐ VENDOR UNIQUE BEACON

903

The figure shows a rectangular window titled "TO-BE-TRANSMITTED BEACON SETTING". Inside the window, there are two options, each with a checkbox and a label. The first option, labeled "901", is "AIR PRINT BEACON" with a checked checkbox. The second option, labeled "902", is "VENDOR UNIQUE BEACON" with an unchecked checkbox. At the bottom center of the window is a button labeled "OK", which is pointed to by the label "903". The entire window is pointed to by the label "900".