

Drawings


[FIG. 1]



[FIG. 2]



TURBO CHARGER(120)
EXHAUST GAS PIPE
OUTSIDE AIR
FILTER
COMPRESSOR
TURBINE
CLEANING UNIT(130)
EXHAUST GAS RECEIVER(110)
CLEANING WATER CIRCULATION TANK
ABSORBENT LIQUID STORAGE TANK
SCAVENGE AIR COOLING MODULE
ABSORBENT LIQUID SPRAY PUMP
BASIC NEUTRALIZING AGENT
CLEANING WATER REPLENISHING PUMP
FRESH WATER
CLEANING WATER COOLING UNIT
SCAVENGE AIR RECEIVER(150)
CO_2 ABSORBING UNIT
COOLING WATER
BUFFER TANK
pH
CLEANING WATER CIRCULATION PUMP
CO_2 ABSORPTION ZONE
WATER TREATMENT UNIT
OUTBOARD DISCHARGE
CLEANING WATER DRAIN TANK
SLUDGE TANK
ABSORBENT LIQUID TANK
CO_2 ABSORBING UNIT(140)


[FIG. 3]


EXHAUST GAS PIPE
120
OUTSIDE AIR
126
125
123
122
121
130
EXHAUST GAS RECEIVER(110)
124
124a
124b
SCAVENGE AIR RECEIVER(150)


[FIG. 4]

[FIG. 3]



EXHAUST GAS PIPE
120
OUTSIDE AIR
126
125
123
122
121
130
EXHAUST GAS RECEIVER(110)
124
124a
124b
SCAVENGE AIR RECEIVER(150)


120
130
132a
133a
132,133
132b
134a
COOLING WATER
131
BASIC NEUTRALIZING AGENT
131c
131b
FRESH WATER
131a
134f
134
140
134e
134b
pH
134c
134d
140
135d
135a
135c
OUTBOARD DISCHARGE
135b
135


[FIG. 4]


120
130
132a
133a
132b
132,133
134a
COOLING WATER
131
BASIC NEUTRALIZING AGENT
131c
131b
FRESH WATER
131a
140
134f
134
134e
134b
pH
134c
134d
140
135d
135a
135c
OUTBOARD DISCHARGE
135b
135

[FIG. 5]


130
133
120
141
146
142
143a
143
147
144
148
145
145a
147
COOLING WATER
135a
OUTBOARD DISCHARGE
135b
149

[FIG. 6]


EXHAUST GAS PIPE
162
OUTSIDE AIR
161
123
122
130
110
150
160
148
145