




FIG. 1




FIG. 2




FIG. 3A




FIG. 3B




FIG. 3C




FIG. 3D




FIG. 4A

RECEIVE, AT A TARGET OBJECT OF A CLIENT TERMINAL, A CALL NUMBER AND A CALL NUMBER DESCRIPTION ASSOCIATED WITH A CALL REQUEST, THE CALL REQUEST BEING SENT FROM AN INITIATOR TO A SERVER, CAUSING THE TARGET OBJECT TO DISPLAY THE CALL NUMBER DESCRIPTION ON AN INCOMING CALL INTERFACE CORRESPONDING TO THE CALL NUMBER ON THE CLIENT TERMINAL
402B

FIG. 4B




FIG. 4C




FIG. 5




FIG. 6




FIG. 7




FIG. 8




FIG. 9



FIG. 10




FIG. 11




FIG. 12




FIG. 13




FIG. 14




FIG. 15




FIG. 16




FIG. 17




FIG. 18




FIG. 19




FIG. 20