FIG. 1



10
IMAGING UNIT
11
INPUT UNIT
POWER SWITCH,
MODE SELECTION
SWITCH, PICTBRIDGE
12
19
CONTROLLER
18
USB INTERFACE
20
21
USB DEVICE
DISPLAY UNIT
13
SIGNAL PROCESSING UNIT
14
15
MEMORY CARD CONTROLLER
17
RECORDING AND PLAYBACK UNIT
RECORDING AND PLAYBACK MEDIUM
MEMORY CARD
16

FIG. 2



13
PC CONNECTION
PRINTER CONNECTION

FIG. 3



12
TAPE IMAGING
MEMORY IMAGING
PLAYBACK
POWER
OFF
ON
(REBOUNDING)
MODE

FIG. 4



TAPE IMAGING MODE
STANDBY 0:15:45:23
13
AUTOMATIC POWER-OFF FUNCTION
ON
OFF
OK
22
23

FIG. 5



13
120MIN
SP
W
T
0:00:00
12MIN
25
24
FUNCTION

FIG. 6




STANDBY MODE
TIME
0min
5min
AUTOMATIC POWER-OFF: "OFF"
POWER
NEVER POWER-OFF
AUTOMATIC POWER-OFF: "ON"
・IF LEAVE IT
POWER
POWER-OFF
・IF TOUCHED TO TOUCH PANEL ON THE WAY
POWER
5min
POWER-OFF
IF TOUCHED, IT EXTENDS FOR 5MIN FROM THAT TIME

FIG. 7


START
INITIALIZE TIMER COUNTER (e.g., 5 min)
ST11
ST12
CHOOSE AUTOMATIC POWER-OFF IN MENU?
NO
YES
ST13
DISCONNECTED TO OTHER DEVICE, ETC. OR PROCEED TO AUTOMATIC POWER-OFF?
YES
NO
ST14
OPERATE TOUCH PANEL OR KEYS?
YES
NO
ST15
TIMER COUNTER IS 0?
YES
NO
ST16
COUNTDOWN PROCESSING OF TIMER COUNTER
ST17
ISSUE POWER-OFF REQUEST
END

F I G. 8




FIG. 9

