FIG. 1




FIG. 2



64×64 SKIP?
YES
Mb64_type = =SKIP
mb64_skip_flag = =1
NO
DIVISION 32×32 BLOCK?
YES
DETERMINE CODING MODE AMONG 64×64, 64×32 AND 32×64
CODING IN ACCORDANCE WITH DETERMINED CODING MODE
NO
32×32 SKIP?
YES
Mb32_type = =SKIP
mb32_skip_flag = =1
NO
DIVISION 16×16 BLOCK?
YES
DETERMINE CODING MODE AMONG 32×32, 32×16 AND 16×32
CODING IN ACCORDANCE WITH DETERMINED CODING MODE
NO
16×16 SKIP?
YES
Mb16_type = =SKIP
mb16_skip_flag = =1
NO
DETERMINE CODING MODE AMONG 16×16 AND SUB-BLOCKS
CODING IN ACCORDANCE WITH DETERMINED CODING MODE

FIG. 3



CONTROL DATA
QUANTIZED TRANSFORM COEFFICIENTS
ENTROPY CODER
130
INTRA-PREDICTION MODE
MOTION INFORMATION
160
170
180
185
INVERSE QUANTIZATION /TRANSFORM UNIT
DEBLOCKING FILTER
PICTURE STORAGE
CODER CONTROL
TRANSFORM/ QUANTIZATION UNIT
120
140
INTRA PREDICTOR
MOTION COMPENSATOR
MOTION ESTIMATOR
155
190
150
110
CODING MODE DETERMINER

FIG. 4




FIG. 5




FIG. 6




FIG. 7

