
FIG. 5


HOST
Memory Device
TRANSMIT INSTRUCTION
INSTRUCTION LOADING MODE
STORE INSTRUCTION
TRANSMIT OPERATION REQUEST
EXECUTING MODE
PROCESS OPERATION
TRANSMIT OPERATION RESULT
TRANSMIT OPERATION REQUEST/INSTRUCTION
EXECUTING AND UPDATING MODE
PROCESS OPERATION
UPDATE INSTRUCTION
TRANSMIT OPERATION RESULT
TRANSMIT OPERATION REQUEST
EXECUTING MODE
PROCESS OPERATION
TRANSMIT OPERATION RESULT