

Eye-Hook
Bore Brush
Winch
Pulling Cable
Safety Latch Hook
Retractable Cable
Gun Barrel Adapter For Gun Barrel Without Muzzle Brake
Pulling Cable Attached with Safety Latch Hook
Gun Barrel Adapter For Gun Barrel Without Muzzle Brake
Battery Cable with cable clips

Figure 1



Winch
Pulling Cable
Universal Adapter Assembly
Safety Latch Hook
Gun Barrel Adapter For Gun Barrel Without Muzzle Brake
Winch
Gun Barrel Adapter For Gun Barrel with Muzzle Brake
Pulling Cable
Safety Latch Hook
Universal Adapter Assembly

Figure 2



Safety Latch Hook
Safety Latch Hook
Pulling Cable
Retractor Cable

Figure 3



Gun Barrel without muzzle brake
Universal Adapter Assembly
Gun Barrel Adapter For Barrel Without Muzzle Brake
Mounted on Gun Barrel without muzzle brake

Figure 4



Gun Barrel Adapter for Barrel With Muzzle Brake
Universal Adapter Assembly
muzzle brake
Gun Barrel
Mounted on muzzle brake

Figure 5



1
Gun Barrel Adapter for Barrel with Muzzle Brake
Remote Switch
Winch
Pulling Cable
Breech Block
Guide Retractor Cable into barrel towards the front of the barel
Retractor cable
Gun Barrel
Muzzle Brake
12V
12V battery
2
Secure Retractor Cable Safety Latch Hook to Pulling Cable Safety Latch Hook
Remote Switch
Winch
Breech Block
Retractor cable
Gun Barrel
Muzzle Brake
12V
12V battery
3
Release lever catch on the winch to allow the pulling cable to be pulled manually by the Retractor Cable towards the breech block
Remote Switch
Winch
Breech Block
Manually pull the Retractor cable by hand to bring the Pulling cable Safety Latch hook to the end of the barrel at breech block
Retractor cable
Gun Barrel
Muzzle Brake
12V
12V battery

Figure 6a



4
Remote Switch
Winch
Breech Block
Attach Pulling Cable Safety Latch Hook on Bore Brush
Bore Brush
Gun Barrel
Muzzle Brake
Attach Retractor Cable Safety Latch Hook to the other side of Bore Brush
12V
12V battery
Retractor cable
5
Remote Switch
Winch
Gun Barrel Adapter for Barrel with Muzzle Brake
Pulling Cable
Breech Block
Guide Bore Brush into Barrel
Gun Barrel
Muzzle Brake
Retracting cable
Bore Brush
12V
12V battery
6
Switch ON automatic winch to pull Bore brush towards the front of the barrel
Remote Switch
Pulling Cable
Muzzle Brake
Gun Barrel
Bore Brush
Retractor Cable
12V
12V battery

Figure 6b




Figure 7






Figure 8



Cleaning Process For Gun Barrel With Muzzle Brake

Figure 9



Cleaning Process For Gun Barrel Without Muzzle Brake

Figure 9a