


FIG. 1




FIG. 2



Compressed
Air Source
40
42
Manifold
26
30
52
28
10
Rotor
50
44

FIG. 3




FIG. 4A




FIG. 4B




FIG. 5



100
Heat one or more rotors
102
Install rotor stage
104
Install and locate airflow nozzle
106
Urge airflow through nozzle to cool rotor
Rotor assembly complete ?
N
Y
Stop

FIG. 6