
Fig. 1
(Prior Art)






Fig. 2

Fig. 3




Fig. 4




15
59
29
41
27
39
37
8
8
21
121
123
120
35
84
81
87
5
5
85
109
80
33
28
82
117
83
31
75
71
86
69
61

Fig. 5


117
27
80
81
87
111
84
99
99
109
109
85
93
87
117




105
99
107
103
109
110
97
111
95
96
93

Fig. 6

Fig. 7


17
43
45
37
Controller
CPU/Memory Data Convert Module
Spool
49
Cable Length Tracker
51
TOFD Rotation Motor
89
TOFD Rotational Encoder
91
73
Video Rotational Motor
121
109
117
Pulse Echo (32)
TOFD (4)
Shear Wave (4)
Video Encoder
79



127
125
121
35
120
122
129
131
28
123

Fig. 8




Fig. 9




Fig. 10




Fig. 11




Fig. 1




Fig. 2



71
69
79
67
81
81
69
68

Fig. 4



61
63
65
63
75
25
67
7
7
W
82
105
87
67
59
67
67
67
83
85
73
85
73
W
57
22
51
23
55

Fig. 3




Fig. 5




Fig. 6



73
22
59
55
67
59
73

Fig. 7



33
35
Video
Controller
Linear Motor
49
Linear Encoder
47
Rotation Motor
51
Rotational Encoder
53
31
Computer
73
75
69
98
MPI Fluid
V
97
67
69
Brush Unit
86
88
67

Fig. 8





Fig. 9

Fig. 10


101
22
59
73
73
67
59
101



33
35
Video
Controller
Linear Motor
49
Rotation Motor
51
Linear Encoder
47
Rotational Encoder
53
31
Computer
91
75
98
69
MPI Fluid
V
97
67
73
69
Brush Unit
88
67
101
69
Yoke
103
67
86

Fig. 11

Fig. 12

Abbreviated External Magnetic Field Procedure

Step 1: Prepare inspection apparatus

Step 2: Load the inspection apparatus and set linear encoder

Step 3: Advance inspection apparatus down inner diameter of the pipe and locate center of weld with onboard video device

Step 4: Position wire wheel brushes over the weld

Step 5: Actuate cylinder rods to position wire wheel brush in contact with the weld

Step 6: Actuate pneumatic motors to rotate wire wheel brushes

Step 7: Rotate head unit back and forth until weld area is clean

Step 8: Position MPI medium dispensers adjacent the weld and apply MPI medium through an MPI supply system

Step 9: Position video cameras adjacent the weld

Step 10: Activate MPI magnetic unit to establish magnetic field and magnetize inspection area

Step 11: Activate artificial light source

Step 12: Rotate head unit to position video cameras along the inner diameter of the weld area

Step 13: View, record, and store the video output of the reach of the video cameras

Step 14: Calculate weld offset

Step 15: Repeat steps 3 to 14 on next weld until pipe inspection complete

Step 16: Actuate the linear motor to retrieve the inspection apparatus

Fig. 13

Abbreviated Internal Magnetic Field Procedure

Step 1: Prepare inspection apparatus

Step 2: Load the inspection apparatus and set linear encoder

Step 3: Advance inspection apparatus down inner diameter of the pipe and locate center of weld with onboard video device

Step 4: Position wire wheel brushes over the weld

Step 5: Actuate cylinder rods to position wire wheel brush in contact with the weld

Step 6: Actuate pneumatic motors to rotate wire wheel brushes

Step 7: Rotate head unit back and forth until weld area is clean

Step 8: Position magnetic yoke adjacent the weld

Step 9: Actuate cylinder rods to position magnetic yoke radially and activate

Step 10: Position MPI medium dispensers as necessary and apply MPI medium through an MPI supply system

Step 11: Activate artificial light source, as necessary

Step 12: View, record, and store the video output of the each of the video cameras

Step 13: Rotate head unit and repeat steps 8 to 11 until weld inspection complete

Step 14: Repeat steps 3 to 12 on next weld until pipe inspection complete

Step 15: Actuate the linear motor to retrieve the inspection apparatus