

TITLE OF THE INVENTION

A METHOD, SYSTEM, APPARATUS, AND COMPUTER PROGRAM
PRODUCT FOR CONTROLLING AND BROWSING VIRTUAL BOOK

CROSS REFERENCE TO RELATED PATENT DOCUMENT

(0001) This application claims priority to U.S. provisional application 60/410,278 filed on September 13, 2002. This application is related to U.S. Pat. No. 5,909,207; U.S. Pat. No. 6,064,384; U.S. Pat. No. 6,407,757; U.S. Pat. No. 6,340,980; copending U.S. patent application Ser. No. 09/617,043 filed 7/14/2000; copending and allowed U.S. patent application Ser. No. 09/686,902 filed 10/12/2000; copending and allowed U.S. patent application Ser. No. 09/686,965 filed 10/12/2000; copending U.S. patent application Ser. No. 60/318,638 filed 9/13/2001; copending U.S. patent application Ser. No. 10/029,718 filed 1/23/2001; copending U.S. patent application Ser. No. 10/029,868 filed 12/13/2001; copending U.S. patent application Ser. No. 10/142,996 filed 5/13/2002; copending U.S. patent application Ser. No. 10/142,858 filed 5/13/2002; copending U.S. patent application Ser. No. 10/143,005 filed 5/13/2002; copending U.S. patent application Ser. No. 60/365,186 filed 3/19/2002; and copending U.S. patent application Ser. No. 60/367,765 filed 3/28/2002 the entire contents of each of these applications being incorporated herein by reference.

BACKGROUND OF THE INVENTION

Field of the Invention

(0002) The present invention relates to a hardware and software system including a controller that can be operatively combined with several methods of display on a display screen under software and hardware control for the purpose of browsing through data stored in a memory device. This facilitates the browsing of the data stored in a memory device in such a way that it allows a rapid view of what contents are present and the organization of the material in the data, as well as rapid access to the items in the data involved. Specifically the present invention relates to controllers that have specialized functions for effecting various actions on the data displayed on the display screen in such a way that users can rapidly browse through the data involved.

Description of the Prior Art

(0003) Currently, the method for viewing documents stored in a virtual is through a virtual monitor screen. For documents that are longer/larger than can be contained within one screen, a means is provided to scroll the document up and down or to jump to a particular point in the document (through the use of, for example, a "mouse" coupled with scroll bars at the edges of the document displayed on the screen or through the use of hypertext links).

(0004) However, most people do not find this a particularly convenient way to view a document, as compared with a book. That this is true is evidenced in the fact that despite the fact that the virtual has been in increasing use, there is not only no corresponding reduction in paper use, but an increase in paper quantity is required to print what is conveniently stored in a virtual that can be seemingly easily and flexibly manipulated for viewing. Sometimes the printed version of the information involved is necessary, like in the case of printing a picture on a sheet of paper to be pasted on some surface (e.g., a wall), or in the case of the convenience of having a relatively light, hardy paperback book for reading in almost any possible situation and location, but there are times when a reader is quite happy to sit at a desk in front of a desktop virtual or handle a notebook virtual away from the desk, and yet the reader would still prefer a printed version of the document in a hand-held format. This is especially true in the case of looking through manuals, including software manuals, to understand how to operate a device or software application. The irony is that virtual software packages usually come with thick and heavy manuals containing information which can easily be stored on a light-weight CD-ROM, and even if the manuals are sometimes dispensed in the form of a CD-ROM, more often than not people would print them out into a hard-copy format in order to facilitate reading.

(0005) What is involved when one interacts with the printed material in a book is a subtle and complicated process. To start with, material in a book is presented in a sequential order, with a continuity of material from page to page, and there is also a hierarchical structure in the material presented (as the material is organized into chapters, sections, subsections, etc.) because ideas in the material are related to each other in some kind of conceptual hierarchy. The human perceptual system inputs data in a sequential manner, and after a book is read from the beginning to the end in a sequential fashion, the brain then recreates the conceptual hierarchy after viewing the

material involved. However, very often one does not read a book (or input the material involved) from the beginning to the end because (a) one wants to have an overview of the material present; (b) one is searching for something of interest to him/her; or (c) one is interested in reading only portions of the book (in the case of, say, reading the manual to understand how to operate something). In these cases, one browses through the subject book to find the material of unique interest to that reader. (0006) Two basic things are achieved in the browsing process. First, the browser has a glimpse of *what* are the contents of the book document. Second, the browser has an idea of approximately *where* the items of interest are so that the browser can (a) return to look for them later when needed, and (b) have an understanding of the relationships between the material currently being viewed and other material (i.e., an understanding of the hierarchical structure involved). When browsing a book document, many finger-operations are required of the browser in order to flip through the pages and, together with the inherent sequential order imposed by the pages, very quickly allow the browser to have an understanding of the nature, location and organization of the material involved.

(0007) In the process of browsing through a book, one can perform the following operations:

- (a) flip through the pages at varying speeds depending on the level of detail at which one wishes to view the material in the book;
- (b) jump to the approximate location of the item of interest;
- (c) change the direction of flipping (forward or backward) very rapidly because
 - (i) one would like to compare and contrast material on different pages,
 - (ii) after jumping to an approximate location of some items of interest one would like to find their exact locations, or
 - (iii) one is unsure of where the item of interest is and is in the process of searching for it; and
- (d) mark the locations of some pages of interest that one may want to later return.

(0008) All these operations are performed very rapidly with the fingers interacting with the flipping pages and with minimal unnecessary movements of the fingers and hands. Interestingly, a book/magazine with soft and flexible pages is harder to handle because more finger and hand movements are needed to browse through it, while books with stiff pages can be browsed with almost no movement of the hand.

(0009) In currently available methods of browsing through documents stored in a virtual, e.g., the use of a mouse combined with scroll bars and buttons on the virtual screen, more movements of the hands are necessary to effect the various operations described above. Also, fine control of the hand or fingers (depending on whether the mouse uses hand movement to move the cursor on the screen or finger movement like in the case of a track ball) is necessary to position the cursor on the screen at the required places. The process is both lengthy and clumsy. The lengthiness of the process taxes the human short term memory's ability to remember items encountered in the recent past for the purpose of establishing the relationships between items and the clumsiness of the process creates distraction and interferes with the short term memory process, a well known effect in perceptual psychology.

(00010) Because material in a book is organized into pages, it also enhances the ability of the reader to better remember the location of various portions of the material involved. Also, unlike the process of scrolling through a document on a screen like what is normally done in a word-processor, wherein the contents become a blur and reading is impossible, when one moves through the material in a book through *flipping*, one is still able to read at least the approximate contents, if not the details. It is due to these features that a person browsing through a book can acquire a good understanding of its contents, the location of specific items and organization of the material.

(00011) It is because of the reasons set forth above, people still prefer to read a book in their hands, rather than a document image displayed on a virtual screen using currently available methods.

(00012) U.S. Pat. No. 5,467,102 (Kuno et al.) discloses a device for document viewing that consists of two display screens. One of the purposes of using two display screens is to allow the user to display two different pages from the document so that they can be read side-by-side (e.g., a diagram and its textual explanation). Another purpose is to allow a large picture to be displayed simultaneously on both pages. The Kuno et al. device allows users to change the speed of movement through the document through a pressure sensor -- the more pressure applied, the faster the pages in the document are moved through. The Kuno et al. device also allows the document to be viewed in the forward or backward direction by pressing on a forward sensor area or a reverse sensor area respectively. One can also select a page to jump to by pressing on an icon displayed on the screen. However the Kuno et al. device

still does not provide the same convenience as browsing through a book, primarily because when switching between the operations for different controls -- the speed of movement through the document, the change of direction of viewing, and the jumping to different parts of the document -- there are a lot more hand and finger movements than is the case in manipulating a physical book. Moreover, the Kuno et al. device is a specialized, relatively costly device with sensors and hardware built onto two display screens, whereas the present inventor recognizes that a lower cost and more practical device would be one that adds modularly to the existing virtual system.

(00013) Currently, there are also virtual mice that can eliminate the above-mentioned problem of positioning cursor on the virtual screen with a conventional mouse (i.e., fine control of the hand or fingers is needed). These mice allow the user to specify "hot locations" on the screen on which the cursor "homes onto" with less fine control than conventional mice. Furthermore, a subset of these mice can generate "vertical only" or "horizontal only" movement of the cursor so that the scrolling process requires less fine control of the muscle than is required with a conventional mouse. These mice eliminate some, but not all, of the problems associated with the conventional methods of virtual input as far as virtual-based document browsing is concerned.

(00014) In U.S. Patent No. 5,417,575 (1995) McTaggart discloses an electronic book that comprises laminated sheets bound together in the form of a book. On each of these sheets, printed material is arranged on the top layer and below that layer is an electronic backdrop containing thin light-emitting diodes (LED's) and pressure sensitive switches affixed onto a backing sheet. The LED's generate visual signals that can be seen through the top layer for the purpose of highlighting parts of the printed material. The pressure switches, positioned under certain items in the printed material, are for the purpose of sensing the user's selection of those items. A speaker is also provided on the book to generate audio signals for explaining the text or giving the user audio feedback. Contact or photo-sensitive switches are also embedded in the pages to allow the electronic circuits to know which pages are currently being viewed, so that the appropriate audio and visual signals can be generated. Even though this apparatus is in a form that allows a person to handle it like handling a typical book, with visual and audio enhancements of the printed material as well as facilities that accept the user's feedback, it is basically a hard-wired device that is not reprogrammable and different hardware has to be configured for books with different

contents. No provision is available for downloading document files from a virtual for display on the electronic book nor is the electronic book able to display any arbitrary document file. This device is hence not suitable for browsing through documents stored in a virtual.

(00015) U.S. Pat. No. 5,909,207 (Ho) discloses a virtual-based system that allows users to view and manipulate documents in the form of an electronic virtual book that addresses the above problems in browsing information in the electronic medium. This virtual book system simulates the paper book very closely and has two major components. One is the representation of the paper book on the virtual screen, complete with realistic flipping pages and thickness representation. The other is the use of a browsing device that allows

1. rapid change of direction of flipping,
2. rapid change of speed of flipping,
3. selection and jumping to any desired page, and
4. bookmarking of the pages.

(00016) The browsing device allows one to use the fingers to manipulate the pages in the book much in the same way as in the case of the paper book. Therefore, the virtual manipulation of the pages together with the book image on the screen constitutes a virtual book system. This virtual book system improves on the methods used in current electronic means of information browsing in a very significant way such that the ease of browsing information can approach that obtainable with a paper book. This allows users to be able to quickly browse through a large number of pages (perhaps thousands of pages) of information and obtain the idea of the structure and contents involved and hence a good overview of the entire collection of material in the "virtual book". Other than being able to have a good idea of the structure and contents of the material involved, the process of browsing through the material presented in the form of a virtual book much like in the case of the paper book also facilitates subsequent searches for items in the material.

(00017) In U.S. Pat. No. 5,909,207 (Ho) the virtual book browsing device basically consists of a pressure and position sensor. The pressure the finger exerts on the pressure sensor controls the speed of flipping through the pages of the virtual book. The movement of the finger on the position sensor on the browsing device in the virtual book system corresponds to the movement of the finger on the thickness of

the paper book to select a page to jump to. The combination of the pressure and position sensor therefore allows one to rapidly browse through the virtual book.

(00018) However, the method of presenting and browsing information described in U.S. Pat. No. 5,909,207 (Ho) can be improved further by putting together the various components of the system into an integrated system with simple, one-button operations for most of the desired functions. This will greatly improve the consumer use of the system.

(00019) Therefore, the inventor has identified there exists a need for a specialized system for presenting the virtual book system for a consumer-oriented market. In particular, there is a need for a specialized system for presenting the virtual book system that can be interfaced to a computer, a regular or widescreen television (TV), or a regular or widescreen high definition television (HDTV). There is also a need to interface a virtual book system with a CD-R, CD-RW, a DVD, and a similar optical/non-optical portable large volume storage disk or non-disk medium.

SUMMARY OF THE INVENTION

(00020) In view of the aforementioned short-comings of presently available schemes for providing consumers with a one-button, simple operations for effecting various desired actions on a virtual book system, such as controlling and browsing a virtual book, one objective of the present invention is to provide a memory and control device to provide one button operations for data transfer and display operations.

(00021) Another objective of the present invention is to provide a controller that works with the memory and control device for the purpose of effectively and rapidly control and browse a virtual book on a virtual book system.

(00022) Yet another objective of the invention is that the positioning and design of the controls for the operations performed by the fingers on the controller are such that they allow minimal movements of the fingers, thus maximizing the ease of browsing through the displayed virtual book. The dexterity of the human fingers is to be fully exploited for these controls.

(00023) Each of these objectives include the objective to display on a computer, a regular or widescreen television (TV), or a regular or widescreen high definition television (HDTV) and/or to interface with a CD-R, CD-RW, a DVD, and a similar optical/non-optical portable large volume storage disk or non-disk medium.

BRIEF DESCRIPTION OF THE DRAWINGS

(00024) A more complete appreciation of the invention and many of the attendant advantages thereof will be readily obtained as the same becomes better understood by reference to the following detailed description when considered in connection with the accompanying drawings, wherein:

(00025) FIG. 1A is a top perspective view of the virtual book displayed on the display screen that is used to display information from a memory and control device.

(00026) FIG. 1B is a top perspective view of the virtual book displayed on the display screen in the process of jumping to a number of pages ahead in the book.

(00027) FIG. 1C is a top perspective view of the virtual book displayed on the display screen in the process of flipping to the next page.

(00028) FIG. 1D is a top perspective view of the virtual book displayed on the display screen in the process of flipping many pages simultaneously.

(00029) FIG. 1E is a top perspective view of the exemplary virtual book displayed on the display screen during the process of selecting a page where the thickness is expanded to allow finer resolution during page selection;

(00030) FIG. 2 is a front perspective view of a virtual book display and control system in which there are three main components: a display screen, a memory and control device and a controller.

(00031) FIG. 3A is a top perspective view of a virtual book showing the basic flipping process.

(00032) FIG. 3B is a top perspective views of a few virtual books showing the process of jumping to a selected page.

(00033) FIG. 4A is a top perspective view of a virtual book at the beginning of some complex flipping processed.

(00034) FIG. 4B is a top perspective view of a virtual book showing the change of direction of all the flipping pages.

(00035) FIG. 4C is a top perspective view of a virtual book showing the change of direction of a trailing page.

(00036) FIG. 4D is a top perspective view of a virtual book showing the change of direction of a group of trailing pages.

(00037) FIG. 4E is a top perspective view of a virtual book showing the opening up of a region in the flipping pages.

(00038) FIG. **4F** is a top perspective view of a virtual book showing the change of direction of the trailing page in a right subgroup of flipping pages.

(00039) FIG. **4G** is a top perspective view of a virtual book showing the change of direction of a number of trailing pages in a right subgroup of flipping pages.

(00040) FIG. **4H** is a top perspective view of a virtual book showing the change of direction of a number of trailing pages in a left subgroup of flipping pages,

(00041) FIG. **4I** is a top perspective view of a virtual book showing the freezing of flipping actions of the pages in the midst of flipping across the virtual book.

(00042) FIG. **5A** is a top perspective view of a virtual book showing a collection of flipping pages followed by a series of single flipping pages.

(00043) FIG. **5B** is a top perspective view of a virtual book showing more than one collection of flipping pages together with a number of single flipping pages.

(00044) FIG. **6A** is a top perspective view of a virtual book showing a right-hand page being picked up.

(00045) FIG. **6B** is a top perspective view of a virtual book showing a picked-up page being held and flipped about.

(00046) FIG. **7** is a top perspective view of a virtual book showing a picked-up page being held while other pages return to their respective resting positions on the left and right sides of the virtual book.

(00047) FIG. **8** is a top perspective view of a virtual book showing a collection of pages being held and flipped about.

(00048) FIG. **9** is a top perspective view of a virtual book showing a number of single pages and collections of pages being held and flipped about.

(00049) FIG. **10A** is a top perspective view of a virtual book showing a single page being held while a number of other flipping pages are collected onto it.

(00050) FIG. **10B** is a top perspective view of a virtual book showing the effect of holding a collection of a number of pages and flipping it about.

(00051) FIG. **10C** is a top perspective view of a virtual book showing the effect of releasing a number of pages from a collection of pages.

(00052) FIG. **11A** is a top perspective view of a virtual book showing a collection of pages being held and forming a sub-book together with the right side thickness of the virtual book while flipping and browsing actions are carried out on a number of pages between them.

- (00053) FIG. **11B** is a top perspective view of a virtual book showing two collections of pages being held forming a sub-book between them while flipping and browsing actions are carried out on a number of pages between them.
- (00054) FIG. **12** is a list of the basic and complex flipping actions.
- (00055) FIG. **13** is a top perspective view of a controller that controls the virtual book and other displayed items on a display screen.
- (00056) FIG. **14** is a front perspective view of a memory and control device that sends signals to display and control images displayed on a display screen.
- (00057) FIG. **15** is a interface displayed on a display screen for the selection and manipulation of images displayed on the display screen.
- (00058) FIG. **16** is a front perspective view of a virtual book display and control system in which there are three main components: a display screen, a memory and control device and a controller, as well as a menu displayed on the display screen.
- (00059) FIG. **17** is the top level menu of a virtual book system showing selections for viewing from various memory sources and for activating memory to memory copy.
- (00060) FIG. **18** is the menu for selecting folders on memory sources to operate on.
- (00061) FIG. **19** is another menu for selecting folders on memory sources to operate on.
- (00062) FIG. **20** is a menu for setting system parameters.
- (00063) FIG. **21** is a front perspective view of a virtual book displayed on a display screen of the main system.
- (00064) FIG. **22** is a menu superimposed on the front perspective view of a virtual book displayed on a display screen of the main system, showing various selections including the writing of a virtual book onto a memory medium.
- (00065) FIG. **23** is a front perspective view of a virtual book displayed on a display screen of the main system with a jump cursor being indicated.

DESCRIPTION OF THE PREFERRED EMBODIMENTS

- (00066) Referring now to the drawings, wherein like reference numerals designate identical or corresponding parts throughout the several views, and more particularly to FIG. **1A** thereof which depicts one embodiment of the virtual book interface. Basically, the information is displayed on two pages as in an opened book.

At this stage, a number of pages have been browsed through and collected in the “virtual book” **100**. The amount of material before and after the current pages (the pages in view) is shown as varying thicknesses on the left and right sides (**101** and **102**), respectively (as well as the left and right bottom edges (**103** and **104**)), of the book. On the left and right thicknesses (**101** and **102**) are shown a number of bookmarks (**105 – 107**) that bookmark some of the pages that have been viewed earlier. There are three types of bookmarks on these thicknesses. They are page-bookmarks **105**, annotation bookmarks **106**, and finger bookmarks **107**. On the bottom thicknesses (**103** and **104**) are shown a number of keyword bookmarks **108**. An Internet URL (Universal Resource Locator) field **109** above the virtual book **100** allows URL addresses to be entered.

(00067) In order to allow the user to select any desired page, jump cursors **110** and **111** are provided on the left and right thickness (**101** and **102**). The user, using a mouse or other control, can move the left or right jump cursors (**110** and **111** respectively) up and down the left or right thicknesses (**101** and **102** respectively). The page number may appear on the tag of the jump cursor to display the page selected by the jump cursor. When the user has decided to jump to a certain page using the jump cursor to select that page, he/she can use the mouse or other input device to activate the jump.

(00068) FIG. **1B** depicts the process by which a certain selected page in the virtual book **100** is jumped to. This jump may have been either activated by the selection of a bookmark (e.g. page-bookmark **105**) or by the jump cursor (e.g., jump cursor **110** or **111**). The thickness **112** between the page originally in view **113** and the page jumped to **114** is shown to move across the virtual screen in continuous animation, much like in the case of the physical book.

(00069) FIG. **1C** depicts a process by which one page **120** in the virtual book **100** is being flipped. The page **120** can be shown to bend and move across the virtual screen to reveal the underlying page **121**.

(00070) FIG. **1D** depicts a process by which, because of increased speed of moving through the virtual book **100** by flipping the pages, more than one page (**122 – 125**) is shown to be moving across the virtual screen at the same time. The user can select to freeze all the pages in motion.

(00071) FIG. **1E** depicts a special jump cursor mode in which the thickness of the page in the region of the jump cursor (**110** or **111**) is selected to enter a mode of fine

adjustment. Due to the resolution of the screen, if the thickness of the page (**101** or **102**) is used to represent, say, a large number of pages while the thickness representation on the virtual screen may only have a limited number of pixels, the movement of the jump cursor (**110** or **111**) over the thickness (**101** or **102** respectively) in pixel-incremented steps may not allow the user to select some of the pages. Therefore, a fine adjustment mode is necessary. One embodiment is to right click on the jump cursor (say jump cursor **111**), and the thickness region around the jump cursor **111** is “expanded” and represented as a rectangle **150**. The thickness represented in the rectangle **150** represents a subset of the pages represented by the full thickness **102**, around the page currently pointed to by the jump cursor **111**. When the jump cursor **111** is moved up and down the thickness within the rectangle **150**, it can access the pages to a finer level than on the original thickness **102**. Further “enlargements” of the thickness **102** is also possible that leads to even finer access of the pages on the thickness **102**.

(00072) FIG. 2 depicts an embodiment of a system **200** targeted toward a general consumer market. The system **200** consists of a display screen **201**, a memory and control device **202**, and a controller **203**. The display screen **201** can be a computer screen, a TV screen or any other kind of display screen. The device **200** can be a computer-based system or any other kind of system that generates on command a virtual book interface on the display screen **201** to display information in the virtual book format **204**. The controller **203** can be a mouse, a keyboard, a custom (wireless or wire-connected) remote controller, or any other kind of input device that generates the necessary signals to the device **202** to generate the necessary images in the display screen (e.g., a TV or DVD remote controller).

(00073) FIG. 3A depicts the basic flipping mechanisms of a virtual book **1000** on a computer screen. A left page **1010** and a right page **1011** are stationary while three pages **1020**, **1021**, and **1022** are being flipped across from the right side to the left side simultaneously. The faster the movement through the book, the more pages are flipped simultaneously and vice versa. (At the minimum, one page can be flipping across.) The speed of movement through the virtual book **1000** is also proportional to the speed of movement of each flipping page while it flips from the right to the left side of the virtual book **1000** or vice versa. When the flipping pages **1020**, **1021**, and **1022** reach the left side of the virtual book **1000**, they are collected there, forming part of the left side of the virtual book **1000**. The thicknesses **1005** and **1006** on both sides

of the virtual book change accordingly as a result of disappearance of pages from or accumulation of pages on the corresponding side.

(00074) FIG. **3B** depicts the basic jumping mechanism as a result of either an activation of a jump cursor **1030** on the right side thickness **1006** or a bookmark **1035** on the right side thickness **1006**. A collection of pages between the current right-hand page **1011** and the page **1045** to jump to is shown to flip across from the right side to the left side of the virtual book **1000**. A thickness **1040** proportional to the number of pages in between the right-hand page **1011** and the page **1045** to jump to is shown moving across the virtual book **1000** accordingly.

(00075) FIGS. **4 - 11** depict more complex flipping actions of the pages as a result of receiving browsing control commands to be described in detail later.

(00076) FIG. **4A** shows a number of pages (**1110-1113**, etc.) being flipped from the right side of a virtual book **1100** to the left side of the virtual book **1100**. (Pages **1114** and **1115** are still resting on the right side of the virtual book **1100**). Starting from this flipping state of all the pages (**1110-1113**, etc.) in FIG. **4A**, FIG. **4B** shows the flipping direction of all the pages (**1110-1113**, etc.) being reversed and changed in the midst of flipping. Starting from the flipping state of all the pages (**1110-1113**, etc.) in FIG. **4A**, FIG. **4C** shows the direction of the trailing page **1113** being reversed and changed in mid-flip while the other pages (**1110-1112**) continue to flip to the left side of the virtual book **1100**.

(00077) Starting from the flipping state of all the four pages (**1110-1113**) in the virtual book **1100** in FIG. **4A** and a few more pages (**1114** and **1115**) being launched in the same direction (from right to left) subsequently, FIG. **4D** shows the direction of flipping of a group of trailing pages (**1113**, **1114**, and **1115**) being reversed and changed to going from left to right while the other pages (**1110**, **1111**, and **1112**) continue to flip from right to left. The region **1120** between the two sets of pages (**1110-1112** on the one hand and **1113-1115** on the other) begin to “open up” and as the two sets of pages continue to flip further in opposite directions, in FIG. **4E** it is shown that the region **1121** between them (pages **1110-1112** on the one hand and pages **1113-1115** on the other) opens up further.

(00078) Starting from the flipping state of all the pages (**1110-1115**) in the virtual book **1100** in FIG. **4E**, in which some of the pages (**1110-1112**) are flipping from right to left and some of the pages (**1113-1115**) are flipping from left to right, when a certain browsing control command is given, as shown in FIG. **4F**, the direction of

flipping of the trailing page of the group of pages (1113-1115) on the right side - page 1113 – is reversed and changed to flipping from right to left while pages 1114 and 1115 continue to flip from left to right and the region 1123 between the page 1113 and the page 1114 begins to open up.

(00079) Starting from the flipping state of all the pages (1110-1115) in the virtual book 1100 in FIG. 4E, in which some of the pages (1110-1112) are flipping from right to left and some of the pages (1113-1115) are flipping from left to right, when a certain browsing control command is given, as shown in FIG. 4G, the direction of flipping of a group of trailing pages (1113 and 1114) of the group of pages (1113-1115) on the right side are reversed and changed to flipping from right to left, thus creating a region 1124 that opens up gradually.

(00080) Starting from the flipping state of all the pages (1110-1115) in the virtual book 1100 in FIG. 4E, in which some of the pages (1110-1112) are flipping from right to left and some of the pages (1113-1115) are flipping from left to right, when a certain browsing control command is given, as shown in FIG. 4H, the direction of flipping of a group of trailing pages (1111 and 1112) of the group of pages (1110-1112) on the left side are reversed and changed to flipping from left to right, thus creating a region 1125 that opens up gradually.

(00081) FIG. 4I shows that starting from the flipping configuration of the virtual book 1100 in FIG. 4A., say, or any of the flipping configuration of the virtual book 1100 in FIGS. 4B-4H, all the pages are made to stop flipping and “freeze” in mid-flip.

(00082) After the pages enter this frozen state, they can be “unfrozen”. There are 4 situations after “unfreezing”: 1. pages are unfrozen and then individual pages continue to flip in the directions prior to freezing; 2. pages are unfrozen and all pages flip in the same direction; 3. pages are unfrozen and some pages flip in the direction right to left to rest on the left side and some flip in the direction left to right to rest on the right side of the book; 4. pages are unfrozen and subgroups of pages flip in different directions.

(00083) FIG. 5A shows firstly a collection of pages 1212 is being flipped from right to left as a result of, say, a jump operation due to either a bookmark or a jump cursor activation such as that depicted in FIG. 3B, and then that it is followed by a number of trailing single flipping pages 1213-1215 that are launched subsequently.

(00084) Starting from the flipping configuration of FIG. 5A, say, in which a collection of pages 1212 being flipped is followed by a number of flipping single pages (1213-1215), a further launching of a collection of pages 1216 is activated as depicted in FIG. 5B as a result of a jump operation due to either a bookmark or a jump cursor activation such as that depicted in FIG. 3B. Subsequent to this, the further launching of any combination of single and/or collection of flipping pages is possible. Subsequent changes of direction of flipping and other movement effects including the freezing in mid-flip of all or some subgroups of this combination of single and/or collection of flipping pages in ways similar to those described for single flipping pages in FIGS. 4B-4I are possible. That is, the collections of pages such as 1212 and 1216 would behave like the single pages in FIGS. 4B-4I.

(00085) FIGS. 6A and 6B depict a **hold-and-flip method** of manipulating a flipping page. Starting from a configuration in which a page is initially at rest, say on the right-hand side of a virtual book 1300, such as page 1306 shown in FIG. 6A, a pointer 1310 picks up the page 1306 from its resting position on the right-hand side of the virtual book 1300, and then the page is flipped by the pointer 1310 as depicted in FIG. 6B either in the direction right to left or left to right. This way, both sides of page 1306 can be inspected repeatedly as many times as it is desired.

(00086) In another method of entering the "hold-and-flip" mode, FIG. 7 depicts a pointer 1410 picking up a flipping page 1404 in the midst of a flipping action, which might be a flipping page in one of those flipping configurations depicted in FIGS. 4A to 4H or a page in a frozen state such as depicted in FIG. 4I. Thereafter, all the pages 1401-1403 to the left of it and all the pages 1405-1407 to the right of it fall away and end up resting on the left side and the right side of the virtual book 1400 respectively. This picked-up page can then be flipped about and inspected in the hold-and-flip mode.

(00087) FIG. 8 depicts the picking up of a collection of pages 1503 in a virtual book 1500 and the subsequent flipping-about action. This is the hold-and-flip method of manipulating a collection of flipping pages instead of just a single page. The collection of pages 1503 can be picked up from its resting state from, say, the right side of the virtual book 1500 or from the midst of a flipping action, say, in a configuration such as that depicted in FIG. 5B in which a number of collections of flipping pages are shown to be in flipping action.

(00088) FIG. 9 depicts the simultaneous hold-and-flip action applying to more than one single page (e.g., 1603 and 1604) and/or collection of pages (e.g., 1605). A number of pointers (1610-1612) are involved in the holding and flipping action.

(00089) FIG. 10A and 10B depict a **hold-and-collect method** of manipulating pages in a virtual book 1700. A page 1705 in the virtual book 1700 is first picked up by a pointer 1710 (either when the page 1705 is at rest on the right or left side of the virtual book 1700 or when it is in the midst of some flipping action). And then, pages 1720-1725 to its left and/or right sides, whether they are initially in the midst of some flipping action or at rest on the left and/or right side of the virtual book 1700, are all “collected” onto the page 1705, resulting in a collection of pages 1706 as shown in FIG. 10B. This entire collection 1706 can then be flipped about as depicted in FIG. 10B.

(00090) FIG. 10C depicts a number of pages 1730-1733 being released from a collection of pages 1707 being held in mid-flip by a pointer 1710.

(00091) FIG. 11A depicts a **hold-and-browse method** of manipulating pages in a virtual book 1800. A single page and/or a collection of pages 1801 is first picked up by a pointer 1810. And then, this collection of pages 1801 and the right side thickness 1803 become a new “sub book” between which all kinds of browsing and flipping actions can take place for a number of pages (such as pages 1805-1808).

(00092) FIG. 11B depicts another hold-and-browse method of manipulating pages in a virtual book 1800 involving two collections (1801 and 1804) of pages. The two collections of pages 1801 and 1804 are being picked up by two pointers 1810 and 1811 respectively. These two collections of pages 1810 and 1811 then become a “sub book” between which all kinds of browsing and flipping actions can take place for a number of pages (such as pages 1805-1808). In general, any two pages and/or collection of pages can be made into a “sub book” between which the usual browsing and flipping action of a number of pages can take place.

(00093) FIG. 12 summarizes all the basic and complex flipping actions described above.

(00094) All of the complex flipping actions depicted in FIGS 3-11 can be controlled by a mouse, one of the browsing controllers described in U.S. Pat. No. 5,909,207 (Ho), and one of these browsing controllers in conjunction with a mouse and/or other pointing and control methods. Specifically, the flipping actions can be controlled by a controller as depicted in FIG. 13.

(00095) The controller **3001** depicted in FIG. **13** combines several functions into a single controller. The remote controller **3001**

1. controls the virtual book's **204** flipping action;
2. selects to display one or more menus to be displayed on the display screen **201**;
3. selects the items on the displayed menu displayed on the display screen **201**, and
4. effects certain actions such as the ejection of a DVD drive or the deletion of certain selected memory on the memory and control device **202**.

(00096) The STANDBY button **3010** on the controller (computer) turns on or turns off the display screen **201** and/or some other circuitries in the memory and control device **202**. The CLOSE button **3011** closes a menu or a virtual book **204** on the display screen **201**, returns from a full-screen zoom (to be described below), or returns from thickness or bookmark selection mode (to be described below).

(00097) The ZOOM-LEFT and ZOOM-RIGHT buttons (**3012** and **3013**) enlarge the left hand or right hand page respectively to full screen mode. The UP and DOWN buttons (**3014** and **3018**) are for the upward and downward selection movement on a menu or on the bookmarks (**105-107**) displayed on the sides of the virtual book **204**. (That is, in the absence of a mouse, the method to select, say, the various bookmarks would be first to select to enter the bookmark mode (e.g., by pressing button **3024** to be described below), and then use the UP and DOWN buttons (**3014** and **3018**) to highlight the various vertically placed bookmarks, and when a certain one is desired, the pressing of an "OK" button (**3017**, to be described below) would select it.)

(00098) The LEFT and RIGHT buttons (**3015** and **3016**) are for the leftward and rightward selection movement on a menu, on the bookmarks, on the thicknesses (**101** and **102**), or on the left and right pages. If no menu, bookmarks, thickness or other mode is entered, the LEFT and RIGHT buttons (**3015** and **3016**) are for the flipping of the pages to the left or right respectively. The OK button **3017** is for the confirmation of any selected option. The LEFT THICKNESS and RIGHT THICKNESS buttons (**3019** and **3020**) are for the selection of the left and right thicknesses (**101** and **102**) respectively on the virtual book (**100** or **204**). The BOOKMARK button **3021** is for selecting to enter the bookmark mode. In the bookmark mode, one can either select to add a bookmark to or remove a bookmark from a page or select to jump to a

bookmarked page. The process is as follows. First the BOOKMARK button **3021** is pressed. The system then enters the bookmark mode. Then, suppose there are already a number of bookmarks (e.g., bookmarks **105-107** in FIG 1A) present on the virtual book (**100** or **204**), the user can use the LEFT button **3015** to highlight indicate that he would like to select one of the bookmarks on the left thickness **101**, and then use the UP and DOWN buttons (**3014** and **3018**) to select the particular bookmark that he desires. When the desired bookmark is selected, the pressing of the OK button **3017** will cause the virtual book **204** to flip to the bookmarked page, complete with thickness animation such as that shown in FIG. 1B.

(00099) The use of the LEFT and RIGHT THICKNESS buttons (**3019** and **3020**) are as follows. First, the user uses the buttons (**3019** and **3020**) to select the left or right thickness (**101** and **102** respectively) on the virtual book (**100** or **204**). A jump cursor (**110** or **111**) will appear on the thickness indicating the position selected on the thickness. (The position selected on the thickness corresponds to a point in the virtual book **204**.) To change the selected position on the thickness, the user uses the LEFT and RIGHT buttons to move the jump cursor (**110** or **111** on virtual book **100**) left or right until the desired position is reached. Then, with the pressing of the OK button **3017**, the virtual book **204** will flip to the desired page, complete with thickness animation such as that shown in FIG. 1B.

(000100) The MENU button **3022**, when pressed, displays a menu on the display screen **201** for the purpose of triggering a variety of actions. The AUTOFLIP button **3023**, when pressed, causes the virtual book **204** to enter the auto-flipping mode in which the pages are automatically flipped without the need for the pressing of any flipping button. The FLIPTO button **3024** allows the user to select to flip to a number of desired pages. On pressing of the button **3024**, a menu will appear on the display screen **201** and the user can select to flip to the front cover, back cover, or any desired page based on, say, the page number.

(000101) The COPY button **3025**, when pressed, causes the contents of the memory on the memory and control device **202** to be copied onto another medium (such as a writable CD) inserted into the memory and control device **202**. The EJECT button **3027**, when pressed, causes the DVD, CD or other kinds of memory drive to be ejected from the memory and control device **202**. The DELETE button **3026**, when pressed, causes the memory in the memory and control device **202** to be deleted.

(000102) FIG. 14 shows the front face of an embodiment **4001** of the memory and control device **202**. The memory and control device **4001** consists of a memory drive **4002** and a memory card slot **4003**. The button **4004** is the power on/off button and the indicator light **4005** indicates whether the memory and control device **4001** has been turned on or off. The memory card slot **4003** allows a memory card, such as that removed from a digital camera after a certain number of pictures have been stored inside, to be inserted and read. The CD drive **4002** allows either a blank writable CD/DVD, a pre-recorded CD/DVD or other similar memory medium to be inserted to be written to or read from. The pressing of the COPY button **4006**, say, can transfer all the data from the memory card in the memory card slot **4003** to the medium in the memory drive **4002**. The indicator light **4007**, when lit, indicates that the transfer is in progress. The DELETE button **4008**, when pressed, causes the memory card in the memory slot **4003** to be deleted. The indicator light **4009**, when lit, indicates that the deletion is in progress. The eject button **4010**, when pressed, causes the memory drive **4002** to be ejected. The indicator light **4011**, when lit, indicates that the ejection is in progress.

(000103) The memory drive **4002** and memory card slot **4003** described above are only particular embodiments. In general, these can be any kind of drive for reading and writing to any kind of memory medium and there can be more than two of these.

(000104) When the memory and control device **202** begins operation and before any memory medium is inserted, the display screen (**5001**, FIG. 15) is blank (other than showing, say, a frame **5002** as shown in FIG. 15, to indicate that the memory and control device **202** is turned on). When a memory card is inserted into the memory card slot **4003**, if there is data on the card, say, placed into three separate folders/files, the screen **5001** will show three separate folders/files **5010**, **5011**, and **5012** with graphic/textual indication that they are from the medium in the memory card slot **4003**. When a medium is inserted into the memory drive **4002**, icons representing the folders/files in the medium (**5020**, **5021**, **5022**) are also shown on the display screen **5001**.

(000105) With the folders/files on the screen, the user can use the UP/DOWN and LEFT/RIGHT buttons (**3014**, **3018**, **3015** and **3016**) to select the folder/file desired. When the desired folder/file is selected, pressing the OK button **3017** will cause a virtual book **204** to be displayed on the display screen **201** containing the contents of the selected folder/file.

(000106) The information displayed on the display screen **204** and controlled by the controller **203** can come from the memory medium within the memory and control device **202** or from the Internet, through either a wire or wireless connection, or from other devices.

(000107) More buttons can be added to the controller **203** to effect the other complex flipping actions such as those listed in FIG. **12** and depicted in FIGS. **3-11**. These buttons can also be used to effect fine control of searching for the page to jump to by using a fine-control thickness region **150** as shown in FIG. **1E** and described above.

(000108) The memory and control device **202** (FIG. **2**) or **4001** (FIG. **14**), other than deriving its data from a memory card inserted in its memory card slot **4003** (FIG. **14**), can also derive the data to be shown on the screen **201** (FIG. **2**) as a virtual book **204** from a CD or other memory media inserted into its memory drive **4002** (FIG. **14**) or from a connection to the Internet, wireless or otherwise.

(000109) FIG. **16** depicts a system **1600** and a process in which a virtual book viewed on the screen can be transferred onto a CD or other kinds of memory medium **1605**. In the process of viewing a virtual book **1604** on the screen **1601** using the memory and control device **1602**, a button **1606** on the controller **1603** is pressed and a menu **1607** is popped up and a selection **1608** can be made to transfer the entire virtual book **1604** onto a CD or other media **1605**. This process is different from that described above for transferring data directly onto the CD or other media **1605** using the COPY button **3025** (FIG. **13**) or the COPY button **4006** (FIG. **14**). In the above cases, the files are transferred as they are. In the process here depicted in FIG. **16**, a virtual book **1604** is created and transferred onto the medium **1605** (CD or other media). What this means is, a recipient of the medium **1605** can insert the medium **1605** onto a computer, another memory and control device **1602**, or other device that can read the medium **1605**, and automatically the same virtual book **1604** will appear on the associated screen (e.g., **1601**). In order to achieve this, one method is to transferred a viewer software along with the contents of the virtual book **1604** onto the medium **1605** so that it can re-create the virtual book **1604** on the associated screen (e.g., **1601**) when the medium **1605** is read by whatever reading device.

(000110) Other than using a selection **1608** on a menu **1607** to activate the above virtual book transfer process, one can also use a specialized button **1609** on the controller **1603**.

(000111) The controller **3001** depicted in FIG. **13**, other than controlling the basic flipping actions depicted in FIG. **1** can also be used to control all the complex flipping actions depicted in FIGS. **3 – 12**. This can be achieved by the buttons depicted in FIG. **13** on the controller **3001** or additional buttons added to the controller **3001**. These buttons can be used by themselves or in combination with other buttons to launch these complex flipping actions (FIGS. **3 – 12**).

(000112) Instead of using a controller (**3001** in FIG. **13** or **203** in FIG. **2**) to control all the basic flipping actions depicted in FIG. **1** and the complex flipping actions depicted in FIGS. **3 – 12** of a virtual book **204** displayed on a screen **201** (FIG. **2**), a computer mouse or other control/input device can also be used.

(000113) FIG. **17 - 22** show one embodiment of a series of menus that appear on the screen **201** (FIG. **2**) for effecting various actions on the system **200**.

(000114) FIG. **17** depicts the menu **1701** when the system **200** is first started. The selections include View Memory Card **1702**, View CD Contents **1703**, Memory Card to CD Copy **1704** and Options **1705**.

(000115) FIG. **18** shows the display on the screen **201** with a menu **1801** when View Memory Card **1702** in FIG. **17** is selected. It shows that there are three folders **1802**, **1803**, and **1804** on the memory card **4003** (FIG. **14**) and the currently selected folder is **1802** CAN001. The Preview **1805** shows a part of the contents of the selected folder **1802** CAN001.

(000116) FIG. **19** shows the display on the screen **201** with a menu **1901** when View CD Contents **1703** in FIG. **17** is selected. It shows that there are three folders **1902**, **1903**, and **1904** on the memory drive (e.g., CD Drive) **4002** (FIG. **14**) and the currently selected folder is **1902** London. The Preview **1905** shows a part of the contents of the selected folder **1902** London.

(000117) On the menu **1701** in FIG. **17**, if the item Memory Card to CD Copy **1704** is selected, all the contents of the memory card **4003** will be copied into the CD (or other writable medium) in the memory drive **4002**. This effect can also be achieved by pressing the COPY button **4006** on the memory and control device **4001** (FIG. **14**). In general, the source of data to be copied onto a CD (or other writable medium) in the memory drive **4002** can come from either the memory card **4003** or other memory medium connected to the memory and control device **4001** through a USB or other connection or. The source of data can also come from the Internet through a connection to the Internet.

(000118) On the menu **1701** in FIG. **17**, if the item Options **1705** is selected, the Options menu **2001** (FIG. **20**) will appear in which one can select to set various parameters such as Sound Effects, Album Music, Album Theme, Memory Card, Compact Disc, and Autoplay Interval.

(000119) On the menu **1801** depicted in FIG. **18**, if the current selected folder is, say, **1802** CAN001, and the OK button **3017** on the controller **3001** (FIG. **13**) is pressed, a photo album/virtual book **2101** based on the contents of the folder **1802** CAN001 is created as shown in FIG. **21**.

(000120) On the menu **1901** depicted in FIG. **19**, if the current selected folder is, say, **1902** London, and the OK button **3017** on the controller **3001** (FIG. **13**) is pressed, a photo album/virtual book **2101** based on the contents of the folder **1802** CAN001 is created as shown in FIG. **21**.

(000121) As one is viewing the photo album/virtual book **2101** (FIG. **21**), and the MENU button **3022** on the controller **3001** (FIG. **13**) is pressed, a menu **2202** appears on the screen on top of the photo album/virtual book **2101** as depicted in FIG. **22**. There are effects that can be applied to the photos or the contents on the left and right pages. The actions such as Delete, Rotate, and other editing functions can be applied to the left page contents using the Left Page selection **2203** and similarly for the contents on the right page using the Right Page selection **2204**. There are other Album Options **2205** that can be selected including Sound Effects, Album Music, etc. The Burn Album to CD option **2206** in this menu **2202** allows the entire photo album/virtual book to be burned onto the medium (e.g., a Compact Disc, CD) in the memory drive **4002** (FIG. **14**). When the Burn Album to CD command **2206** is activated, one method of the photo album/virtual book transfer to the memory medium (e.g., a CD) in the memory drive **4002** is such that should someone later insert the memory medium (e.g., the CD) into a memory drive either in a computer system, in another one of the system **200** (FIG. **2**) or other systems configured to read from the memory medium, an entire photo album/virtual book will appear on the screen of any of these systems showing the same contents organized in the same manner as that shown on the screen **201** (i.e., the virtual book **2101**). To achieve this, it normally entails the writing of a viewer software onto the memory medium together with the contents to be transferred onto the medium or CD. To make the viewing experience seamless, this viewer software can be made to auto-launch when the medium or CD is inserted into the memory drive of the recipient system.

(000122) When the user is on the menu **2001** (FIG. **20**), he/she can elect to change the Album Music **2002** or Album Theme **2003**. When any of these items is selected, they will be prompted to insert a memory medium into the memory card **4003** or the memory drive **4002** (FIG. **14**) which contains either music or picture files. They can select one or more of these files to change the Album Music (the music that is played and accompanies the viewing of a photo album/virtual book **2101**) or the Album Theme (which may include front cover, page, back cover, and other graphics on the photo album or virtual book).

(000123) When the user is using the controller **3001** (FIG. **13**) and the button Thickness Right **3020** is pressed while viewing a virtual book **2101** (FIG. **23**), a jump cursor **2302** appears on the right side thickness **2301** as shown in FIG. **23**. Now, if the user presses the LEFT **3015** or RIGHT **3016** button (FIG. **13**), the jump cursor will move to the left or right respectively to select a desired page. A number **2303** associated with the jump cursor **2302** may be displayed to show the page number of the selected page. The jump cursor may be later used for jumping to the selected/desired page. For example, when the jump cursor is positioned on a particular selected page and when the OK **3017** button (FIG. **13**) is pressed, the virtual book **2101** will be flipped to the selected page, with a representation of the pages skipped over in the form of an animation of a thick collection of pages moving across the screen as depicted in FIG. **1B**, the thickness of the collection of pages being proportional to the number of pages skipped over. Correspondingly, a jump cursor can be displayed on the left thickness **2305** of the virtual book **2101** and controlled and used similarly.

(000124) All the control inputs in FIGS. **22**, such as the one-button Burn Album to CD option **2206** on the menu **2202**, all the actions on the left page **2203**, on the right page **2204** and the other Album Options **2204** on the menu **2202**, all the selections View Memory Card **1702**, View CD Contents **1703**, Memory Card to CD Copy **1704** and Options **1705** on menu **1701** (FIG. **17**), all the selections on menus **1801**, **1901**, and **2001** in FIGS. **18 – 20**, and all the basic and complex flipping actions listed in FIG. **12** can also be made available as specialized buttons on the memory and control device **202** or on the remote controller **203** (FIG. **2**).

(000125) The memory media on the memory and control device **4001** (FIG. **14**) such as the memory card **4003** and the memory drive **4002** that the system **200** (FIG. **2**) write to or read from can also be resident in another physical device outside the

memory control device 4001 and connected to the memory and control device 4001 through wired connection, wireless connections, or through the Internet.

(000126) Each of these embodiments may be configured to display the virtual book or comparable information on a computer, a regular or widescreen television (TV), or a regular or widescreen high definition television (HDTV) and/or to interface with a CD-R, CD-RW, a DVD, or a similar optical/non-optical portable large volume storage disk or non-disk medium.

(000127) While particular embodiments of the present invention have been illustrated and described, it will be appreciated that numerous changes and modifications will occur to those skilled in the art, and it is intended that the appended claims cover all those changes and modifications which fall within the spirit and scope of the present invention.

WHAT IS CLAIMED:

1. A method for controlling and browsing a virtual book, comprising:
displaying information on two pages of an electronic book;
displaying a left and a right side book thickness, said left and right side book thicknesses corresponding to a respective amount information within said electronic book before and after said displayed information; and
displaying one or more pages flipping, individually or in tandem, across said electronic book.
2. The method of claim 1, further comprising:
displaying one of a page-bookmark, an annotation bookmark, a finger bookmark, and a keyword bookmark;
displaying an Internet Universal Resource Locator field.
3. The method of claim 1, further comprising:
displaying one of a left and a right jump cursor.
4. The method of claim 1, further comprising:
controlling said display with a control device.
5. The method of claim 4, said control device comprising at least one of:
a computer;
a keyboard;
a mouse; and
a remote control device.
6. The method of claim 3, further comprising:
displaying a page number, said page number corresponding to a page selected by said one of a left and a right jump cursor.
7. The method of claim 3, further comprising:

jumping to a selected page by one of selecting one of said page-bookmark, said annotation bookmark, said finger bookmark, and said keyword bookmark and activating one of said left and said right jump cursor.

8. The method of claim 7, further comprising:
displaying one or more pages flipping, individually or in tandem, to said selected page; and
adjusting the left and right side thickness to correspond to a jump to said selected page.

9. The method of claim 1, further comprising:
adjusting a speed of displayed movement through said electronic book; and
displaying an increased number of pages flipped, said increased number corresponding to the adjusted speed.

10. The method of claim 8, further comprising:
freezing one or more flipping pages in a partially flipped position.

11. The method of claim 9, further comprising:
controllably flipping said frozen one or more pages.

12. The method of claim 1, further comprising:
displaying one of a coarse and fine thickness indication.

13. The method of claim 1, further comprising:
displaying a stationary left and right page while displaying additionally pages being flipped across from a first side to a second side simultaneously, said additional pages being located between said stationary left and right page.

14. The method of claim 1, further comprising:
adjusting a book browsing speed;
displaying more or less pages simultaneously flipping in correspondence to said adjusted book browsing speed; and

adjusting the left and right side thickness in proportion to the direction of page flipping and said book browsing speed.

15. The method of claim 7, further comprising:

displaying a first collection of pages flipping between a current page and a jumped-to-page, a thickness of said first collection of pages being proportional to a number of pages between the current page and the jumped-to-page.

16. The method of claim 1, further comprising:

displaying a plurality of pages simultaneously flipping in a first direction;
stopping the flipping of one or all of the plurality of pages simultaneously flipping; and

displaying said stopped one or all pages flipping in an opposite direction from said first direction while displaying a remainder of said plurality of pages simultaneously flipping in said first direction.

17. The method of claim 16, further comprising:

stopping the flipping of a subset of said one or all of the plurality of pages simultaneously flipping; and

displaying said stopped subset of said one or all pages flipping in said first direction while displaying a remainder of said subset simultaneously flipping in said opposite direction direction.

18. The method of claim 17, further comprising:

stopping the flipping of a subset of said remainder of said plurality of pages;
and

displaying said stopped subset of said remainder of said plurality of pages flipping in said opposite direction while displaying a remainder of said remainder of said plurality of pages simultaneously flipping in said first direction.

19. The method of claim 10, further comprising:

unfreezing some or all of said one or more frozen pages.

20. The method of claim 19, further comprising one of:

displaying unfrozen pages flipping in a direction equal to a pre-freezing flipping direction;

displaying unfrozen pages flipping in a direction opposite to a pre-freezing flipping direction; and

displaying a first subset of unfrozen pages flipping in a direction equal to a pre-freezing flipping direction while displaying a second subset of unfrozen pages flipping in a direction opposite to a pre-freezing flipping direction.

21. The method of claim 8, further comprising:

jumping to a second selected page by one of selecting another one of said page-bookmark, said annotation bookmark, said finger bookmark, and said keyword bookmark and activating one of said left and a right jump cursor;

displaying a second collection of pages flipping between said current page and a second jumped-to-page, a thickness of said second collection of pages being proportional to a number of pages between a trailing edge page and the second jumped-to-page,

said jumping to a second selected page occurring while displaying a first collection of pages flipping between a current page and jumped-to-page.

22. The method of claim 4, further comprising:

holding said one or more flipping pages stationary on said display; and

moving said held one or more pages across the screen by controlling a position control component of a control device.

23. The method of claim 4, further comprising:

picking up a first page or a first collection of pages from one of said right side thickness and said left side thickness;

collecting onto the picked-up first page or the picked-up first collection of pages a collection of additional pages into a first book subsection; and

holding or flipping said first book subsection.

24. The method of claim 23, further comprising:

dropping at least one page from said first book subsection.

25. The method of claim 4, further comprising:
picking up a first collection of pages from one of said right side thickness and said left side thickness; and one of
holding or flipping said first collection of pages.

26. The method of claim 25, further comprising:
dropping at least one page from said first collection of pages.

27. The method of claim 23, further comprising:
picking up a second single page or a second collection of pages with said control device to form a second book subsection;
forming a sub-book with said first and second book subsections.

28. The method of claim 27, further comprising:
dropping at least one page from at least one of said first and second collection of pages.

29. The method of claim 4, further comprising:
displaying a menu.

30. The method of claim 4, further comprising:
one of
viewing contents of a memory card,
viewing contents of a CD or DVD,
viewing contents of one or more storage medium,
copying contents from the memory card to the CD or DVD,
copying contents from the CD or DVD to the memory card,
copying contents from a first storage medium to a second storage medium,
copying contents from the control device to the memory card, the one or more storage medium, or the CD or DVD,
copying contents from one of the memory card, one or more storage medium, CD or DVD to the control device, and

applying optional features to one of an image, text, an audio object, a video object, a multimedia object, a page, and the virtual book.

31. The method of claim 30, further comprising:
viewing said contents of the memory card, the one or more storage medium, or the CD or DVD as thumbnails, as a slide show, or as a flipping book.

32. The method of claim 31, further comprising:
selecting a folder to be previewed.

33. The method of claim 30, further comprising:
copying said contents of the one of a memory card, the CD or DVD, and the one or more storage medium into a writable medium, said writable medium connected to said control device directly or via a network.

34. The method of claim 30, further comprising:
copying one of images, text, audio files, video files, and multimedia objects from at least one of the Internet and an intranet.

35. The method of claim 30, said step of setting parameters comprising:
selecting one of a sound effect, an album music, an album theme, a memory card, a compact disc, and an autoplay interval.

36. The method of claim 30, further comprising:
applying visual effects to an image.

37. The method of claim 30, further comprising:
one of deleting, rotating, and editing an image on a page.

38. The method of claim 30, further comprising:
one of applying sound effects and applying music to one of an image and a page.

39. The method of claim 30, further comprising:

copying an entire virtual book to a writable medium, said writable medium connected to said control device directly or via a network.

40. The method of claim 30, wherein at least one of said steps of viewing contents of a memory card, viewing contents of one or more storage medium, viewing contents of a CD or DVD, copying contents from the memory card to the CD or DVD, copying contents from the CD or DVD to the memory card, copying contents from a first storage medium to a second storage medium, copying contents from the control device to the memory card, the one or more storage medium, or the CD or DVD, copying said contents from the memory card, the one or more storage medium, or the CD or DVD to the control device, and applying optional features to an image, text, an audio object, a video object, a multimedia object, a page, or the virtual book comprises:

one-button operations.

41. The method of claim 30, said step of copying contents from the control device to the memory card, the one or more storage medium, or the CD or DVD comprises:

installing viewing software on the respective memory card, one or more storage medium, CD or DVD from said control device.

42. A system for displaying and editing an electronic book, comprising;
a display screen;
a memory and control device; and
a controller.

43. The system of claim 42, wherein said display screen comprises one of:
a computer screen,
a TV screen.

44. The system of claim 43, wherein said TV screen comprises one of a:
an analog display screen;
a digital display screen;
a wide-aspect display screen;

a non-wide-aspect display screen;
an NTSC display screen; and
a PAL display screen or any other kind of display screen.

45. The system of claim 42, wherein the controller comprises one of:
a mouse;
a keyboard, and
a wired or wireless remote controller.

46. The system of claim 42, wherein at least one of said controller and said memory and control device comprises at least one of:

a STANDBY button;
a CLOSE button;
a ZOOM-LEFT button;
a ZOOM-RIGHT button
an UP button;
a DOWN button;
an OK button;
a LEFT button;
a RIGHT button;
a LEFT THICKNESS button;
a RIGHT THICKNESS button;
a BOOKMARK button;
a MENU button;
an AUTOFLIP button;
a FLIPTO button;
a COPY button;
an EJECT button; and
a DELETE button.

47. The system of claim 46, wherein at least one of said buttons operates in concert with a displayed menu.

48. The system of claim 42, wherein at least one of said controller and said memory and control device is configured to initiate at least one of

- a direction of movement command;
- a speed of movement command;
- a select-to-jump-to-a-specified-point-in-a-document command;
- a jump-to-a-specified-point-in-a-document command;
- a permanent-bookmarking command;
- a finger-bookmarking command;
- a launch-a-single-flipping-page command;
- a-launch-multiple-flipping-pages-at-a-specific-interval command;
- a reverse-direction-of-a-single-last-trailing-page command;
- a reverse-direction-of-multiple-last-trailing-pages command;
- a reverse-direction-of-a-selected-group-of-flipping-pages command;
- a freeze-at-least-one-flipping-pages-in-mid-flip command;
- an-unfreeze-frozen-pages-and-let-pages-continue-to-flip-in-directions-prior to-freezing command;
- an unfreeze-frozen-pages-and-let-pages-all-flip-in-a-same-direction command;
- an unfreeze-frozen-pages-and-some-pages-flip-to-a-left-side-and-some-to-a-right-side-of-book command;
- an unfreeze-frozen-pages-and-let-a-subgroup-of-pages-flip-in-different-directions command;
- a jump-and-make-a-thick-collection-of-pages-flip-together command;
- a launch-flipping-pages-while-a-thick-collection-of-pages-is-flipping command;
- a launch-at-least-one-other-thick-collections-of-pages-while-other-pages-are-flipping command;
- a select-to-hold-a-page command;
- a move-a-held-single-page-in-a-selected-direction-at-a-selected-speed command;
- a select-to-hold-a-thick-collection-of-pages command;
- a move-a-held-single-thick-collection-of-pages-in-a-selected-direction-and-at-a-selected-speed command;
- a select-to-hold-at-least-one-of-at-least-two-pages-and-a-thick-collection-of-pages command;

a move-at-least-one-of-a-held-pages-and-a-thick-collection-of-pages-in-a-selected-direction-and-at-a-selected-speed command;

a hold-a-single-page-in-mid-flip-and-collect-other-pages-that-flip-onto-the-single-page-in-mid-flip command;

a hold-a-single-thick-collection-of-pages-in-mid-flip-and-collect-other-pages-that-flip-onto-the-single-thick-collection-of-pages-in-mid-flip command;

a hold-at-least-one-of-a-single-page-and-a-thick-collection-of-pages-in-mid-flip-and-execute-at-least-one-of-the-set-of-page-flipping-commands-between-the-at-least-one-of-a-single-page-and-a-thick-collection-of-pages-in-mid-flip-and-a-thickness-of-a-side-of-a-book-command; and

a hold-at-least-one-of-two-pages-and-a-thick-collection-of-pages-in-mid-flip-and-execute-at-least-one-of-the-set-of-page-flipping-commands-between-the-at-least-one-of-two-pages-and-a-thick-collection-of-pages-in-mid-flip command.

49. The method of claim 48, wherein at least one of said commands is executed via a menu.

50. The system of Claim 42, wherein said memory and control device comprises:

a computer.

51. The system of Claim 42, wherein said memory and control device comprises at least one of:

a memory integrated with said computer;

a portable memory module;

a memory card;

a memory stick; and

a compact disk.

52. The system of claim 42, further comprising one of:

a CD-R;

a CD-RW;

a DVD;

a portable optical large volume storage disk;

a portable large volume non-optical storage medium; and
a storage medium resident in said memory and control device or connected to the memory and control device through a wired or wireless connection or through the Internet.

53. An apparatus configured to perform at least one of the methods recited in Claims 1-41.

54. A computer program product configured to host instructions corresponding to at least one the methods recited in Claims 1-41.