

REPLACED SHEETS		SG
☒	Description : paged to paged ...121...	May 22, 1995
☒	Claim(s) : paged to paged ...9...	D 17337 EP/T1
☒	Drawing(s) : paged ...43 to paged ...13/13...	
☒	Abstract : paged to paged	

1

9604356-7

IPO's copy

DESCRIPTIONRecoating of Stereolithographic LayersBackground of the Invention

This invention relates generally to an improved stereolithography method and system for the production of three-dimensional objects.

5 In recent years, "stereolithography" systems, such as those described in U.S. Patent No. 4,575,330 entitled "APPARATUS FOR PRODUCTION OF THREE-DIMENSIONAL OBJECTS BY STEREOGRAPHY" have come into use. Basically, stereolithography is a method for automatically building
10 complex three-dimensional plastic parts by successively curing a plurality of thin layers of polymerizable liquid on top of each other until all of the thin layers are joined together to form a whole part. Each polymerized layer is in essence a thin cross section of the desired
15 three-dimensional object. With this technology, the parts are literally grown in a vat of liquid plastic. This method of fabrication is extremely powerful for quickly reducing design ideas to physical form and for making prototypes. Moreover, complex parts can be made quickly
20 without tooling. Because the system uses a computer to generate the cross section of patterns, the system can be readily linked to CAD/CAM systems.

Presently preferred polymers are cured by ultraviolet (UV) light and their curing is fast enough to make them
25 practical model building materials. The liquid that is not polymerized when a part is made is still usable and remains in the vat as successive parts are made. An ultraviolet laser generates a small intense spot of UV which is moved across the liquid surface with a
30 galvanometer mirror X-Y scanner in a predetermined pattern. The scanner is driven by computer generated vectors or the like. Precise complex patterns can be rapidly produced with this technique.

This Sheet Has Been Replaced



The stereolithography system includes a laser scanner, a vat or tank for containing the polymerizable liquid, and an object support platform, which is capable of being raised and lowered in the tank, and a controlling
5 computer. The system is programmed to automatically make a plastic part by forming one thin cross section at a time and building the desired three-dimensional object up layer by layer.

In typical stereolithographic procedures, a thin
10 layer of viscous curable plastic liquid is applied to a surface which may be a previously cured layer and, after sufficient time has elapsed for the thin layer of polymerizable liquid to smooth out by gravity, a computer controlled beam of radiation is moved across the thin
15 liquid layer to sufficiently cure the plastic liquid so that subsequent layers can be applied thereto. The waiting period for the thin layer to level varies depending on several factors such as viscosity of the polymerizable liquid, the layer thickness, and the like.

20 Typically, the cured layer, which is supported on a vertically movable object support platform, is dipped below the surface of a bath of the viscous polymerizable liquid a distance equal to the desired layer thickness so that the liquid plastic can flow over the cured layer.
25 When the surface levels, the layer is ready for curing by radiation.

For further details of stereolithography, reference is made to U.S. Patent 4,575,330 and the following pending U.S. patent applications which are incorporated herein by
30 reference in their entirety, including appendices attached thereto or material incorporated therein by reference, as if fully set forth:

U.S. Patent Application Serial No. 339,246,
filed April 17, 1989, entitled "STEREOLITHOGRAPHIC
35 CURL REDUCTION";

U.S. Patent Application Serial No. 331,664,
filed March 31, 1989, entitled "METHOD AND APPARATUS



FOR PRODUCTION OF HIGH RESOLUTION THREE-DIMENSIONAL
OBJECTS BY STEREOGRAPHY";

5 U.S. Patent Application Serial No. 183,015,
filed April 18, 1988, entitled "METHOD AND APPARATUS
FOR PRODUCTION OF THREE-DIMENSIONAL OBJECTS BY
STEREOGRAPHY";

10 U.S. Patent Application Serial No. 182,801,
filed April 18, 1988, entitled "METHOD AND APPARATUS
FOR PRODUCTION OF THREE-DIMENSIONAL OBJECTS BY
STEREOGRAPHY";

U.S. Patent Application Serial No. 268,429,
filed November 8, 1988, entitled "METHOD FOR CURING
PARTIALLY POLYMERIZED PARTS";

15 U.S. Patent Application Serial No. 268,428,
filed November 8, 1988, entitled "METHOD FOR
FINISHING PARTIALLY POLYMERIZED PARTS";

U.S. Patent Application Serial No. 268,408,
filed November 8, 1988, entitled "METHOD FOR DRAINING
PARTIALLY POLYMERIZED PARTS";

20 U.S. Patent Application Serial No. 268,816,
filed November 8, 1988, entitled "APPARATUS AND
METHOD FOR PROFILING A BEAM";

25 U.S. Patent Application Serial No. 268,907,
filed November 8, 1988, entitled "APPARATUS AND
METHOD FOR CORRECTING FOR DRIFT IN PRODUCTION OF
OBJECTS BY STEREOGRAPHY";

30 U.S. Patent Application Serial No. 268,837,
filed November 8, 1988, entitled "APPARATUS AND
METHOD FOR CALIBRATING AND NORMALIZING A
STEREOGRAPHIC APPARATUS";

U.S. Patent Application Serial No. 249,399,
filed September 26, 1988, entitled "METHOD AND
APPARATUS FOR PRODUCTION OF THREE-DIMENSIONAL OBJECTS
BY STEREOGRAPHY";

35 U.S. Patent Application Serial No. 365,444,
filed June 12, 1989, entitled "INTEGRATED
STEREOGRAPHY"; and

This Sheet Has Been Replaced



U.S. Patent Application Serial No. 265,039,
filed October 31, 1988, entitled "APPARATUS AND
METHOD FOR MEASURING AND CONTROLLING THE LEVEL OF A
FLUID".

5 What has been needed and heretofore unavailable is a
means to reduce the cycle time for forming each layer of
plastic. The present invention satisfies that need.

 This invention also relates generally to apparatus
and methods for measuring and controlling the level of a
10 fluid, and, in particular, to apparatus and methods for
measuring and controlling the level of the working fluid
in a stereolithographic apparatus.

 Many scientific experiments and industrial
applications require the measurement of the level of a
15 fluid. The term "level of a fluid" as used here means the
height of the surface of a fluid in a gravitational field
or other accelerated frame of reference. This surface may
be the top or even the bottom of the fluid (if the fluid
is floating on another fluid). The fluid may be the
20 ocean, the gasoline in the tank of an automobile or a
liquid chemical in a test tube, among many possibilities.
Various means have been adopted over the years to measure
the levels of such fluids, including dip sticks, lines
painted on the side of pilings, marks on the side of test
25 tubes, floats, and the like. A need exists, however, for
an apparatus which can very precisely and reliably measure
the level of a fluid. Apparatus of this sort is
particularly useful in industrial applications and can be
coupled with a level maintenance means such as a plunger,
30 a diaphragm or controls for a pump in order to maintain
the level of the fluid at any desired height.

 In particular, stereolithographic machines require
very precise control of the level of a working fluid.
U.S. Patent No. 4,575,330 to Charles W. Hull, mentioned
35 earlier, discloses apparatus for production of three
dimensional objects by stereolithography. The working
fluid used in stereolithographic apparatus is usually a



photopolymer liquid curable by the application of ultraviolet (U.V.) light. As noted in U.S. Patent No. 4,575,330, the level of the working fluid in the preferred embodiment must be maintained at a constant level so that the beam of U.V. light will remain sharply in focus on a fixed plane.

The overall intensity and intensity profile ("beam profile") of the beam of U.V. light at the surface of the liquid photopolymer will determine, in cooperation with other factors (such as the characteristics of the liquid photopolymer and the length of time the beam remains in a single spot), the depth and profile of the photopolymer that is cured or polymerized by exposure to the beam. The beam profile will vary with the level of the liquid photopolymer, because the beam is focussed to have a known profile at a predetermined level of the liquid photopolymer. If the liquid photopolymer has a level different from the predetermined one, the difference in the beam profile will change the width of the cured photopolymer and its depth from the depth and width planned.

Furthermore, if the level of the liquid photopolymer is higher than the predetermined level, the depth of the cured photopolymer may not be sufficient to reach to and adhere with the previously cured layer, with detrimental consequences for the structural integrity of the object being formed. If the level is lower, then the new layer will be thinner than planned, which is detrimental to the accuracy of reproduction of the object.

The level of the liquid photopolymer must be maintained despite the shrinkage caused by curing the liquid photopolymer, heating, evaporation, and the like. In early versions of stereolithographic apparatus, this level was maintained by providing a spillway. The level of the liquid photopolymer rose to and slightly above (because of surface tension) the spillway. A spillway, however, does not control the level of the liquid photopolymer with sufficient precision to make possible the



finer resolution of parts made by stereolithographic apparatus. Accordingly, a need exists for a more precise means of measuring the level of a fluid.

Summary of the Invention

~~Briefly, and in general terms, the present invention~~
provides a new and improved stereolithography system for generating a three-dimensional object by forming successive, thin, cross-sectional laminae of that object at the face of a polymerizable liquid which is cured in
10 response to appropriate radiation stimulation. The present invention is particularly directed to an improved stereolithography method and system for reducing the cycle time for each layer formed by this procedure.

In accordance with the present invention, a layer of
15 polymerizable liquid is first applied to a surface on an object support platform. Excess polymerizable liquid is struck off the layer by drawing a blade across the surface of the layer to provide a smooth layer of the desired thickness. Curing media such as radiation is directed to
20 the upper or working surface of the smoothed layer in a preselected pattern to thereby sufficiently cure the layer so that subsequent layers can be applied and cured in the same manner to form the desired three-dimensional object.

In a presently preferred embodiment, an object
25 support platform, having a surface on which the layers are applied, is provided and is adapted to be raised and lowered in a bath of the polymerizable liquid in a vat or tank. The platform is lowered into the bath so that a surface thereon, which may be the last-cured layer, is
30 beneath the upper surface of the polymerizable liquid bath a distance generally greater than the desired thickness of the layer. The platform is then raised so that the viscous polymerizable liquid on the surface is above the upper surface of the bath. A horizontally moving doctor
35 blade strikes off excess polymerizable liquid so that a liquid layer of polymer of the desired thickness is



From EP-A-0 250 121 a stereolithographic apparatus is known wherein a modulated and deflected beam from a light source impinges on a layer of a liquid resin lying in a particular solidification plane. The liquid resin is located in a container which is typically supported on a container positioning mechanism and associated with a resin supply apparatus and a layer fixing mechanism. Each time a layer is solidified by the deflected light beam, the container positioning mechanism is lowered such that the solidification plane, which is fixed, lies at successively higher locations with respect to the container. Through a feed line connected to the resin supply apparatus an amount of liquid resin is supplied sufficient to provide for a coating on previously solidified layers having the desired layer thickness.

From the US-A-4 247 508 a laser sinter apparatus is known in which fusible particles are employed to form layers. Each particle layer is selectively fused by a laser beam, to fuse an area which defines the respective portion of the article in the layer. After one layer is selectively fused, another layer will be added to the top thereof and selectively fused thereafter, such that the particle will be built up in layers, the fused portion of one layer fusing onto a portion of the prior layer. The apparatus used comprises a container having a bottom which is movable vertically within the walls of the container. An upper window is provided having a thickness which defines the thickness of each layer. Initially, the bottom of the container will be located at the level of the lower edge of the window. An amount of fusible particles will be located in the window on the bottom and then wiped by a wiping member to a thinner layer, level with the top of the window. After the layer has been selectively fused by the laser beam, the bottom is moved downward a distance corresponding to the thickness of the window and a second layer of




particles is deposited on the first layer. This process is repeated until the solid article is formed.

5 From prior art document JP-A-61-114 818 a stereolithographic apparatus is known wherein an optical thermo-setting resin is gradually supplied into a resin container and selectively hardened by a laser beam. The used system comprises a resin container in which a smoothing member is placed, the length of which is equal to either the length or width of the
10 container. The smoothing member is horizontally moved across the surface of the liquid resin which has been supplied to the container from a separate resin supply mechanism. The smoothing member has been added in order to reduce the period of time necessary to obtain a flat resin surface. The resin is supplied from the resin supply mechanism for recoating previously cured layers. Due to the high viscosity of
15 the resin, this recoating time is considerable long increasing the production time of the three-dimensional part to be produced.

In view of the above-discussed drawbacks of the prior art, it is the
20 object of the present invention to overcome them.

This Sheet Has Been Replaced





- 6C -

~~finer resolution of parts made by stereolithographic apparatus. Accordingly, a need exists for a more precise means of measuring the level of a fluid.~~

Summary of the Invention

5 ~~Briefly, and in general terms,~~ the present invention provides a new and improved stereolithography system for generating a three-dimensional object by forming successive, thin, cross-sectional laminae of that object at the face of a polymerizable liquid which is cured in
10 response to appropriate radiation stimulation. The present invention is particularly directed to an improved stereolithography method and system for reducing the cycle time for each layer formed by this procedure.

 In accordance with the present invention, a layer of
15 polymerizable liquid is first applied to a surface on an object support platform. Excess polymerizable liquid is struck off the layer by drawing a blade across the surface of the layer to provide a smooth layer of the desired thickness. Curing media such as radiation is directed to
20 the upper or working surface of the smoothed layer in a preselected pattern to thereby sufficiently cure the layer so that subsequent layers can be applied and cured in the same manner to form the desired three-dimensional object.

 In a presently preferred embodiment, an object
25 support platform, having a surface on which the layers are applied, is provided and is adapted to be raised and lowered in a bath of the polymerizable liquid in a vat or tank. The platform is lowered into the bath so that a surface thereon, which may be the last-cured layer, is
30 beneath the upper surface of the polymerizable liquid bath a distance generally greater than the desired thickness of the layer. The platform is then raised so that the viscous polymerizable liquid on the surface is above the upper surface of the bath. A horizontally moving doctor
35 blade strikes off excess polymerizable liquid so that a liquid layer of polymer of the desired thickness is

formed. The platform is then lowered so that the upper surface of the smoothed layer of the polymerized liquid is at essentially the same level as the bath. Curing radiation is then directed to the smoothed layer in a graphic pattern thereon to cure the thin liquid layer so that one or more subsequent layer of the polymerizable liquid can be applied thereon. The object support platform with the partially cured solid layer thereon is then lowered further away from the surface of the bath so that polymerizable liquid can flow onto the solid layer and the cycle repeated.

The process continues with the formation of a plurality of successively formed layers with these layers bonded together until the desired three-dimensional object has been formed. The final product of the stereolithography must have sufficient strength for subsequent handling. Usually, the object is given a final cure after forming.

Care should be exercised during the procedures to ensure that the level of polymerizable liquid in the bath is maintained at a constant level, particularly when the leveled layer of polymerizable liquid is lowered into the bath and cured by radiation, because the liquid in the bath in essence forms the boundaries of leveled layers of liquid. In a presently preferred embodiment, the bath level is sensed in a suitable manner, one level compared to the desired level, and in response to any differences therein a piston or plunger in the bath is raised or lowered in the bath to control the level at the desired set point.

The three-dimensional object is formed one horizontal layer at a time by moving a radiation beam such as ultraviolet light from a helium-cadmium laser across the surface of the photon-curable resin, solidifying the liquid where it strikes. Absorption in the resin prevents the laser light from penetrating deeply and allows a thin layer to be formed.





The present invention also provides a new and improved apparatus for measuring the level of a fluid, comprising a means for generating a beam of electromagnetic radiation and a sensor that varies an electrical signal in response to changes in the position of the electromagnetic beam impinging on the sensor. The beam sensor is mounted at a distance perpendicular to the level of the fluid. The beam is directed along a first optical path (the term "optical path" is used although the beam need not be of visible light) toward the surface of the fluid, at an angle with respect to the surface of the fluid, so that a detectable portion of the beam is reflected from the surface of the fluid along a second optical path to the sensor. Changes in the level of the fluid will change the point at which the beam impinges on the sensor and will thus cause variations in the electrical signal from the sensor. This signal may be used to control devices which in turn control the level of the fluid, such as pumps, diaphragms, or plungers.

The surface of the fluid is presumed to be flat or to remain at the same angle with respect to the beam even though the height of the surface of the fluid may vary. Accordingly, the angle at which the beam is reflected from the surface of the fluid will not vary. If the surface is not flat, the beam may not be reflected or may reflect at unpredictable angles. If waves or turbulence are expected, then a mirrored float which is weighted to prevent yawing, pitching, and rolling may be placed on the surface of the fluid to reflect the beam.

In a preferred embodiment, the means for generating a beam of electromagnetic radiation is a laser and the sensor is a plurality of linked photocells displaced from the surface of the fluid along a direction perpendicular to the surface of the fluid. The radiation from the laser preferably should not alter the state of the fluid. Electronic circuits are provided to compare the electrical output of each of the photocells and thus detect movements

in the position of the beam as it impinges upon the photocells. When the level of the fluid changes, the beam will no longer impinge on the photocells at the same place. One photocell will receive more of the beam than
 5 before and another less than before. This will change the electrical output from each of the photocells affected. A comparison circuit will detect this difference and drive either an instrument displaying the level of the fluid or a device for changing the level of the fluid (such as a
 10 plunger) or both.

The apparatus for measuring the level of the fluid of the present invention is swift, reliable, and very sensitive. It is capable of very precisely determining the level of the fluid and consequently maintaining that
 15 level very precisely. At the present, apparatus for measuring the level of a fluid made according to the invention can measure (and maintain) the level of a fluid to at least within plus ^{0.0427 mm} or minus (0.5 mil (plus or minus .0005 inches)).

20 In sum, the stereolithography method and system of the present invention provides for a considerable reduction in cycle time for each layer formed, improvements in dimensional accuracy, and increases in green strength and final cured strength. Moreover, the
 25 level measuring and controlling apparatus of the present invention satisfies a long existing need for a system capable of rapidly, reliably, and accurately measuring the level of a fluid.

The above and other objects and advantages of this
 30 invention will be apparent from the following more detailed description when taken in conjunction with the accompanying drawings of illustrative embodiments.

Brief Description of the Drawings

FIG. 1 is a cross-sectional view of a
 35 stereolithography system embodying features of the invention;

This Sheet Has Been Replaced



FIG. 2 is a perspective view of the system shown in FIG. 1 further illustrating the embodiment shown in FIG. 1;

FIGS. 3-6 are simplified cross-sectional views of the tank shown in FIG. 1 at various stages of the stereolithography procedure;

FIG. 7 is a perspective view of a three-dimensional object which has been made in accordance with the present invention;

FIG. 8 is a perspective view of a portion of a stereolithographic apparatus with a preferred embodiment of the fluid level measuring apparatus of the present invention mounted thereon;

FIG. 9 is a side elevational view of the preferred embodiment of the invention;

FIG. 10 is a side elevational view of the optical paths taken by the laser beam of the preferred embodiment of the invention under conditions of changing fluid level and angle of incidence;

FIG. 11 is a front elevational view of a bi-cell photo sensor used in the preferred embodiment of the invention;

FIG. 12 is a block diagram of the electronics associated with the bi-cell photosensor of the preferred embodiment of the invention;

FIG. 13 illustrates the trapped volume problem;

FIG. 14 illustrates threaded, retractable pins for setting the blade gap;

FIG. 15 provides a close-up view of the pin mounted in the blade;

FIG. 16 illustrates a cross-section of a blade having an angle of attack in the direction of blade movement;

FIGS. 17-19 illustrate alternative cross-sectional shapes for the blade of FIG. 16;

FIG. 20 illustrates an alternative shape for a level-detecting float;





FIG. 21 illustrates a level detecting apparatus including a float;

FIG. 22 is a diagram of the optical detector of the apparatus of FIG. 21; and

5 FIG. 23 is a flowchart of the recoating software used in the SLA-250.

Detailed Description of the Invention

FIGS. 1 and 2 schematically illustrate the stereolithography system for forming three-dimensional
10 objects which embodies features of the invention. As shown in these drawings, tank or vat 10 is provided to contain a bath 11 of polymerizable fluid. An object support platform 12 is disposed within the tank 10 and is adapted by frame elements 13 and 14 to be raised and
15 lowered within the tank by a motor (not shown). The platform 12 has a horizontal surface 15 on which the three-dimensional objects are formed in accordance with the invention. The tank 10 has a trough 16 in the upper portion of one sidewall of tank 10 and a plunger or piston
20 17 is disposed within the trough to be raised and lowered by motor 18 to control the level of the upper surface 20 of polymerizable liquid within the tank 10.

The level of the upper surface 20 of the bath 11 is detected by means of a radiation source 21 such as an HeNe
25 laser, which is directed toward the upper surface 20 at an angle and radiation sensor 22 which may be a bi-celled detector. The position of the sensor 22 is adjusted to be at a complementary angle with respect to the upper surface 20 so as to receive the radiation from the HeNe laser. A
30 control system 23 is provided to control the movement of the plunger 17 by motor 18.

A computer controlled radiation source 24 is disposed above the bath 11 to direct curing media, such as ultraviolet radiation or other types of curing radiation,
35 in a predetermined pattern across the upper surface 20 of the bath 11 in order to cure the polymerizable liquid in



the layer above the platform where such radiation impacts thereon. The movement and operation of the radiation source 24 and raising and lowering of the object support platform 12 are integral parts of the computer control 25 of the system as will be further described hereinafter.

A doctor blade 26 is mounted on the top of the tank 10 and is adapted to move horizontally across the top of the tank. A blade support 27 is slidably mounted on rails 30 and 31 disposed along one side of the tank 10. A threaded drive shaft 32 passes through a threaded passageway (not shown) in the blade support 27 and rotation thereof by motor 33 moves the blade support 27 and thus the blade 26 horizontally across the top of the tank 10.

The operation of the stereolithography system shown in FIGS. 1 and 2 is best shown in the sequence of FIGS. 3-6. Starting with FIG. 3 the stereolithography procedure is initiated with the object support platform 12 being positioned within the bath 11 of polymerizable liquid so that the horizontal surface 15 thereon is located a short distance from the upper surface 20 of the bath. This distance is greater than the desired thickness of the layer of polymerizable liquid to be cured. The layer of polymerizable liquid immediately above the surface 15 will form the first solid layer of the three-dimensional object when cured.

The next step in the process is shown in FIG. 4. The object support platform 12 is raised so that the layer 34 of polymerizable liquid on the surface 15 is held above the upper surface 20 of the bath 11. The polymerizable liquid is relatively viscous fluid so the liquid does not immediately run off the edges of the surface 15 on platform 12 when the layer is raised out of the bath. Doctor blade 26 is moved horizontally so that the lower edge 35 thereof strikes off excess polymerizable liquid from the layer 34 and thereby smooths the upper or working surface 36. Suitable blade speeds are empirically

determined to provide a desired level to the working surface 34⁶. Moreover, one or more passes by the doctor blade 26 may be needed at a particular speed to provide a smooth level surface 34. Typical blade speeds may range from about one to ten inches per second. When low viscosity polymerizable liquids are used, peripheral dams may be employed to contain the liquid until it is polymerized.

After the working surface 36 of layer 34 is leveled by the doctor blade 26, the object support platform 12 is lowered into the bath 11 as shown in FIG. 5 so that the smoothed working surface 36 of the layer 34 is level with or in the same horizontal plane as the upper surface 20 of the bath 11. The polymerizable fluid of the bath 11 which surrounds the layer 34 forms an interface 37 which is in essence a wall which supports the outer periphery of layer 36. Any disruptions of the working surface 34⁶ or the upper surface 20 of the bath 11 caused by the submersion of object support platform 12 and the layer 34 into the bath 11 are relatively minor and quickly subside.

The computer controlled radiation source 24 is actuated after a short delay to eliminate any disruptions in the upper surface to direct curing media, preferably UV radiation or other suitable radiation, over the working surface 36 of the layer 34 in a predetermined pattern to cure the polymerizable liquid onto which the radiation impacts. The layer 34 is sufficiently cured so that it has the necessary green strength to support additional layers which are subsequently applied in a similar manner and to facilitate handling of the formed object after stereolithography but before final cure.

After irradiation of layer 34, the object support platform 12 is further lowered as shown in FIG. 6 so that the polymerizable liquid from the bath 11 flows over the previously cured layer 34 to form a new layer 38 to thereby initiate another cycle of the process.





A series of polymerized layers are built up in the aforesaid manner, as shown in FIG. 1, with each layer being in effect a thin cross section of the desired three-dimensional object 40. The thickness of the individual layers can vary depending upon the composition and viscosity of the polymerizable liquid and the nature and intensity of the curing radiation media. However, typical thicknesses ^{about 0.127 mm to about 0.254 mm} range from (about 0.005 to about 0.01 inch). The final three-dimensional object 40 which is formed by the afore-described stereolithography system is removed from the tank 10 and then subjected to further treatment to complete the curing of uncured material which remains within the bound surfaces of the three-dimensional object. Surface finishing, such as sanding and the like, may also be applied as needed.

A wide variety of polymerizable liquids can be utilized with the present invention as well as a wide range of curing media. However, photon polymerizable liquids, such as acrylics, are presently preferred along with UV radiation to cure them. Preferably, the viscosity of the polymerizable liquid should exceed 100 centipoise and preferably range from about 1000 to about 6000 centipoise.

Example

An example of a preferred embodiment of the present invention, a computer controlled stereolithography system developed by the present assignee and schematically shown in FIGS. 1 and 2 was utilized to form the three-dimensional object shown in FIG. 7. The base of the ^{24 x 24 cm} object was (8.25 X 8.25 inches), the maximum height was approximately 4 inches and the minimum height was about 1 inch. The wall thicknesses were approximately 0.25 inch. The polymerizable resin employed was a relatively viscous resin from Desoto Chemical Company identified as 4112-65 resin. The temperature of the bath thereof was maintained at approximately 30°C. The thickness of each layer



applied was approximately 0.02 inch. The following procedures embodying the features of the present invention were followed for each layer applied. The object support platform of the stereolithography system was lowered into the bath of 4112-65 resin to allow the liquid resin to flow onto the surface thereon to form an initial layer of polymerizable liquid which was thicker than desired. The platform was then raised so that the initial layer thereon was raised above the bath. A blade traveling at approximately 1 inch per second struck off approximately ^{2.54 mm} (0.1 inch) of polymerizable liquid in one pass, leaving about ^{0.508 mm} (0.02 inch) of polymerizable liquid on the support surface on the platform. The platform was then lowered so that the smoothed working surface of the layer was level with the upper surface of the bath. The layer was subjected to ultraviolet radiation from an HeCd laser providing radiation at a wavelength of about 325 nanometers at about 15 milliwatts of power. The total time for each layer cycle was approximately 35 seconds. The time to make such a part with prior methods would have been approximately 165 seconds per layer cycle. The total time saved by utilizing the embodiments of the present invention in this example was approximately 7.5 hours.

Referring now to Figure 8 in the drawings, an advantageous embodiment of the leveling aspect of the present invention is shown attached to a stereolithographic apparatus 10 in order to measure the level of the working fluid 20 (a U.V. curable photopolymer such as DeSoto #65) in resin vat 30. The stereolithographic apparatus depicted in Figure 8, apart from the addition of the preferred embodiment of the invention and related equipment, has the basic format shown in U.S. Patent No. 4,575,330 (earlier incorporated by reference) and found in the commercial stereolithographic apparatus sold by 3D Systems, Inc. under the acronym "SLA-1."

The stereolithographic apparatus 10 has a side tank 40 added to it which communicates with resin vat 30 by



means of a passage 50 in wall 60 of the resin vat 30. The dimensions of the side tank are ^{17.18 cm}(7 inches) by ^{10.16 cm}(4 inches) in the preferred embodiment of the invention. The working fluid 20 fills the resin vat 30 and the side tank 40. The
5 working fluid is free to flow from the side tank to the resin vat and vice versa. The level of the working fluid in the resin vat (and thus in the side tank) must be precisely controlled to a preset level in order to carry out stereolithographic production of parts (objects made
10 by stereolithography are called "parts"). The apparatus of the present invention, in the form of the preferred embodiment shown, accomplishes this purpose.

A helium neon laser 100 is mounted on resin vat 30 below and to the side of the side tank 40. The laser is
15 aligned so that its output beam is emitted straight up along the side tank. A Uniphase 1508 laser has been found to be successful in the preferred embodiment of the present invention. The Uniphase 1508 laser was chosen because of its low cost, compactness, and low power
20 requirements. The light emitted from this laser will not polymerize the working fluid.

The output beam 110 of the helium neon laser is directed upwards to a mirror 120 (a Rolyn Optics #60.21) mounted on a bracket above the side tank. This deflects
25 the beam along first optical path 112 onto the surface 70 of the working fluid in the side tank 40, as may be best seen in Figure 9. The beam strikes the surface of the working fluid at angle β with respect to the surface 70 (the angle of incidence equals 90° minus β). Angle β has
30 a value at which a detectable component of the beam will be reflected along a second optical path 114. A varying range of angles will meet this latter requirement, depending upon the character of the fluid and the laser light, and the dimensions of the tank. In the preferred
35 embodiment described here, this angle is 15° .

The apparatus described herein measures the level of the resin in the side tank as opposed to the vat. This is



advantageous, since bubbles or other surface disruptions may form in the main vat as the part or support passes through the resin surface at each cycle of part building. These bubbles or other surface disruptions, if struck by the beam, could cause the beam to reflect from the resin surface at an erroneous angle. Other surface disruptions may form over the top of an immersed part that could cause an erroneous beam deflection, which disruptions could take a long time to level out. These include resin bulges, or areas where too much resin has been pushed off by the blade during recoating because of blade drag. These problems may be particularly acute in the case of certain part geometries having trapped volumes, or large, flat, horizontal surfaces, which geometries will be discussed in more detail farther on. By measuring the level of resin in a side tank, the above problems are minimized or eliminated.

After reflection from the surface 70 of the working fluid, the beam returns up along second optical path 114 at the same angle with respect to the surface of the fluid at which the beam impinged on the surface 70 of the fluid. The beam then shines on the bi-cell photo detector 130 mounted on plunger housing 85 on the other side of the side tank 40 from the mirror 120. The mirror is adjusted so that the beam impinges on the bi-cell detector 130 when the level of the working fluid is at the desired height. The mirror is not moved or turned once it has been adjusted to reflect the beam off the surface of the working fluid to the bi-cell photodetector when the level of the working fluid is at the desired height.

A satisfactory bi-cell photodetector, shown in Figure 11, is made by Silicon Detector Corporation and is known by their number SD113-24-21-021. Other brands and sizes of bi-cell photodetectors would be satisfactory. Linear position sensitive detectors ("PSD"), such as the Hamamatsu two-dimensional PSD (S1544) or two-dimensional lateral cell (S1B52) would be acceptable and might be



preferable when the apparatus is intended to measure and display a quantity of output in terms of units of length. The bi-cell photodetector comprises two side-by-side photocells 140. The bi-cell photodetector 130 is mounted
5 on the plunger housing 85 so that the photocells 140 are one above the other and both photocells are above the level of the working fluid. The photodetector may be inclined so that it intercepts second optical path 114 at a right angle, as is best seen in Figures 9 and 12. This
10 ensures that the profile of the beam at the photodetector is a circle, not an oval, if the beam originally had a circular profile.

When the level of the fluid rises or falls due to shrinkage from curing, heating, and the like, the beam
15 will strike the surface 70 at a different point. Accordingly, the beam will strike the bi-cell photodetector at a different point. This effect on the beam is shown in phantom in Figure 9, where a lower level 80 of the working fluid reflects the beam along second
20 optical path 150 to impinge at a lower point with respect to the bi-cell photodetectors. The working fluid level change is exaggerated to illustrate this effect; the preferred embodiment of the invention measures the level of the working fluid in order to maintain that level at a
25 predetermined height. Level changes are small because such level changes are quickly corrected as described below.

A given change in the level of the working fluid will cause the same displacement in the point at which the beam
30 impinges on the bi-cell photodetector, regardless of the value of β . Figure 10 illustrates the result of a change in the working fluid level from level 82 to higher level 84. The difference between levels 82 and 84 is the vertical distance d . Two different beams are shown
35 arriving along first optical paths 151 and 152, and meeting the surface of the fluid at angles β_1 and β_2 , respectively. The second optical paths 153 and 154 (for



the first level 82) are set to impinge on perpendicular P at the same point Y_1 . When the level of the working fluid rises to level 84, the beams follow second optical paths 155 and 156, respectively. Simple trigonometric
5 calculations reveal that both second optical paths 155 and 156 will meet perpendicular P at the same point Y_2 and that the vertical distance between Y_1 and Y_2 is twice the value of d , the vertical change in level of the working fluid. Accordingly, varying β will not affect the accuracy of the
10 method of measuring the level of a fluid according to the invention. The value of β to be chosen depends mainly on which angle will obtain satisfactory reflection of the beam within the constraints of the apparatus.

The working fluid level change will result in a
15 change in the electrical signal emitted by the bi-cell photodetector. The photocells 140 in the bi-cell photodetector are separated by slit 160 (see Figure 11) which is narrow, less than a mil thick. The output of both of the photocells will be equal when the bi-cell
20 photodetector is not illuminated by the laser or when the laser beam is exactly centered on the slit 160 between the photocells 140. The outputs become unequal when the beam moves so that it impinges on one of the cells more than the other. Comparison of unequal outputs by a comparison
25 circuit, as described below, will result in a signal being sent to the stepper motor 90 in order to drive plunger 95. The plunger 95 (see Figure 9) will go up or down as needed to maintain the level of the working fluid.

The plunger maintains the working fluid level at a
30 substantially constant level in space. This is advantageous for it keeps the laser beam in focus. If the level were allowed to change, as would be the case for certain resin dispensing systems which dispose fresh resin into the vat at each cycle of part building, the laser
35 would have to be refocused for the new level.

Referring now to Figure 12, the current outputs 205 and 207 of the photocells 140 are delivered to current



to voltage converter 200 which converts the output of each photocell to a voltage between 0 and -2.5 volts. The two voltage outputs 215 and 217 of the current to voltage converter 200 (each photocell 140 has its own output) are
5 supplied to subtractor 220, where the voltage outputs are subtracted. With the addition of a reference voltage (not shown) the difference between voltage outputs 215 and 217 is a signal 225 which ranges between 0 and +5 volts. When the fluid is at its desired level, signal 225 is at +2.5
10 volts.

Signal 225 is sent to analog/digital converter 230 where the signal is converted to digital signal 235, which then goes to computer 240. Computer 240 compares signal 235 to the predetermined digital signal for the desired
15 fluid level and activates stepper motor controller 245. Stepper motor controller 245 in turn activates stepping motor 90 (a Minarik Electric Co. LAS 3802-001 stepper motor in the preferred embodiment) which moves plunger 95 up and down to displace fluid in order to return the fluid
20 level to the desired value.

The computer is programmed to measure fluid level shortly after a first dipping operation, in which the part is dipped by moving the elevator deeper into the fluid, and before the elevator is raised back up to "draw" the
25 next layer onto the part. The level of the working fluid is measured and controlled only at this specific time in the building process. The computer compares the signal 233 to the reference value at this specific time only and generates the signal 242 to the stepper motor controller
30 245 that determines how long and in which direction stepper motor controller 245 will activate stepper motor 90.

In an additional embodiment of the recoating apparatus of the subject invention, the ability to vary
35 several parameters associated with the blade recoating process is provided, which parameters include the blade gap, which is the distance between the doctor blade and

the surface of the resin bath in the vat, and the blade clearance, which is the distance between the blade and the top of the part. Typically, the blade clearance will be but may not be the same as the layer thickness of the next layer to be formed.

The optimal size of the blade gap depends on a balancing of several considerations. A large blade gap is problematic since it may lead to creases in the surface of the resin bath which will take time to level out. This is so because the blade gap determines the extent to which the top of the part must be raised above the resin surface for sweeping, and also determines the extent to which the top of the part must thereafter be lowered before curing of the next layer can begin. For a $\frac{3.175 \text{ mm}}{125 \text{ mil}}$ blade gap, for example, and a desired blade clearance of $\frac{0.508 \text{ mm}}{20 \text{ mils}}$, the top of the part must be raised $\frac{2.667 \text{ mm}}{105 \text{ mils}}$ above the resin surface before sweeping can begin, and then must be lowered $\frac{3.175 \text{ mm}}{125 \text{ mils}}$ before curing can begin so the top of the part will be $\frac{0.508 \text{ mm}}{20 \text{ mils}}$ below the resin surface. The greater the movement of the top of the part, the more disruption that will be caused at the resin surface by the movement of the platform and supports, and the rest of the part, into and out of the liquid resin. This disruption is what is referred to above as a crease. These creases will typically form at the interface between the resin and the part.

A small blade gap is also problematic since the smaller the blade gap, the more resin the doctor blade typically must push out on a given sweep. For a 0 ~~mil~~ mm blade gap, for example, where the doctor blade is kept right at the surface of the bath, although the crease problem referred to above may be reduced, the doctor blade may be required to sweep resin off the entire vat surface. This may create a small tidal wave of resin, which may spill over the side of the vat, and which may "crash" and form bubbles on the resin surface.



It has been found that a blade gap of ^{0.635 mm}(25 mils) provides a good compromise between the two problems referred to above. Typically, the blade gap will be set once before a part is built, and thereafter remain
 5 constant throughout part building.

Another parameter which is advantageous to vary is the blade clearance. Unlike the blade gap, however, it is desirable to be able to vary the blade clearance throughout part building instead of just once before part
 10 building.

A variable blade clearance is advantageous, because it makes staged recoating possible. Staged recoating is where multiple sweeps of the blade are used for recoating a given layer, with a different blade clearance and
 15 possibly blade velocity at each sweep. Assuming a layer thickness of ^{0.508 mm}(20 mils) for the next layer, for example, in a staged recoating process, the blade clearance for the first sweep might be ^{1.524 mm}(60 mils), for the ^{1.016 mm}second ^{0.508 mm}(40 mils), and for the third, ^{0.508 mm}(20 mils). As a result, at each sweep, a
 20 smaller amount of resin will be swept away than if a single sweep were used to recoat, and a smaller bulge of resin will build up in front of the blade than if a single sweep were used to recoat. A large bulge building up in front of the blade is problematic when a trapped volume of
 25 resin is encountered by the blade. When a trapped volume is encountered, because of the force of gravity, a large bulge of resin may flow underneath the blade, and disrupt the desired layer thickness of the smooth layer forming in the wake of the blade. If the bulge were not allowed to
 30 build up in the first instance, then this problem could be made less severe. This problem can be illustrated with FIG. 13, which shows blade 300 in the middle of a sweep. Part 304 is lowered beneath the blade by distance 303, which is the blade clearance. Smooth resin surface 301 is
 35 formed in the wake of the blade, while a bulge of excess resin, identified by reference numeral 302, is formed in front of the blade. When the blade encounters a trapped






volume of resin, identified with reference numeral 305, if bulge 302 is large enough, resin from the bulge may flow underneath the blade as indicated to disrupt the formation of smooth surface 301. This effect is less pronounced where the blade is travelling over a flat, horizontal surface of a part, since there is less room for the resin to flow underneath the blade.

Another parameter which can be varied is the speed of the blade, especially during staged sweeping, where a different speed can be specified for each sweep. It is advantageous to be able to tailor the blade speed to part geometry. When the blade is passing over a large, horizontal flat area of a part, if the blade is travelling too fast, too much resin may be swept away because of drag, which will induce resin below the blade to move at a particular velocity. If the blade is moving at 12.7 cm/sec (5 in/sec), for example, 0.025 in (1 mil) resin below the blade may be induced to move at 10.46 cm/sec (4 in/sec), and resin below that may be induced to move at 7.62 cm/sec (3 in/sec). In some instances, drag may be so severe over flat areas, that all liquid resin is swept away by the blade. Therefore, over large flat areas, it may be desirable to slow the blade speed down so that the above problem does not occur.

On the other hand, over trapped volumes, if the blade is moved too slow, this may give the resin in the bulge more time to flow underneath the blade. Therefore, over trapped volumes, it may be desirable to increase the speed of the blade so that resin does not have time to flow underneath. The speed cannot be increased too much, however, since if it is increased too much, a wave of resin may be formed in front of the blade, which could crash and form bubbles.

Unfortunately, it is difficult to vary the speed of the blade dynamically depending on part geometry throughout part building. However, when a variable speed is provided for each sweep of staged recoating, the speed of the blade at each sweep and the number of sweeps can be



chosen to minimize the above problems for a typical part. For example, it may be desirable for certain parts, where large flat areas and trapped volumes will be encountered, to use a large number of sweeps per layer, in the range of 5-10, with a relatively slow blade speed at each sweep. Because of the large number of sweeps, only a small amount of resin will be pushed away at each sweep, so that a bulge will not be able to build up and flow underneath the blade when a trapped volume is encountered. On the other hand, because of the slow blade speed, the problem of pushing away too much resin off of a large, flat, horizontal part surface will be minimized. This is because the blade will not be able to generate enough drag to sweep away all the resin. Moreover, the slow blade speed will not be a problem over trapped volumes since a large bulge will not be allowed to build up, so there will be little or no problem of resin flowing underneath the blade even with the slow blade speed.

It is also advantageous to be able to vary the extent to which the part is overdipped into the resin before sweeping begins. As described earlier, the part is typically immersed beneath the surface of the resin by more than the desired layer thickness of the next layer. For example, in a commercial embodiment of a SLA known as the SLA-250 manufactured by 3D Systems, the assignee of the subject invention, preferred layer thicknesses are $\frac{1}{2}$ mm. or lower. In the SLA-250, the part is typically overdipped into the resin by 8 mm, which is many times a typical layer thickness. Therefore, it is desirable to be able to vary this parameter depending on layer thickness.

A typical recoating cycle comprises the following steps: 1) deep over-dipping of the part; 2) detecting and adjusting resin surface level; 3) up dipping; 4) sweeping; and 5) delaying so surface settles out. Overdipping by more than a layer thickness not only ensures that a bulge of resin will form on top of the part which can be smoothed out during sweeping, but it also ensures that



surface disruptions which could interfere with resin level detection in step 2) level out faster. If the part were immersed close to the surface, any surface disruption which could form above the part would take longer to level out. This is because the "channel" between the top of the part and the resin surface would be smaller, and would restrict the movement of resin needed to smooth out disruptions. Therefore, because of overdipping by more than a layer thickness, level detection is correspondingly made more accurate. Moreover, if overdipping were limited to one layer thickness, then thin layer thicknesses of $\frac{1}{4}$ mm (approximately 20 mils) or less would be less desirable. But, these layer thicknesses may be necessary to build certain parts with high resolution. Therefore, deep over-dipping also makes thin layers in this range easier to use.

In sum, in this embodiment, the ability to vary the blade gap, blade clearance, depth of overdipping, and blade speed, and the ability to use staged recoating, provide means to better tailor blade recoating to specific part geometries, so that specific problems associated with these geometries can be overcome.

In an additional embodiment, the blade design can be varied to make it even more efficient. In the SLA-250, the cross-section of the doctor blade is a square having a width of $\frac{3.17 \text{ mm}}{(1/8 \text{ inch})}$. In addition, the blade is supported at only one end with a support rail, which guides the movement of the blade so that the blade and its support resemble a cantilever. This may cause a problem known as flutter and twist, whereby the unsupported end of the blade twists and flutters, thereby leading to errors in the recoating process, such as nonuniform layer thickness. The extent to which the unsupported end will twist and flutter is proportional to the square of the blade length. An additional problem that may occur is the setting of the blade gap with this blade. This process involves many steps, each prone to error, and is also time-consuming.



Moreover, it requires turning screws which can exert torque on, and therefore deflect the blade.

In a more recent commercial embodiment of a stereolithographic system known as the SLA-500, also developed by the 3D Systems, the blade has been redesigned from that used in the SLA-250.

First, to enable blade gap setting to be more easily accomplished, micrometer screws are provided at each end of the blade, which allow the height of each end of the blade above the resin surface to be independently adjusted to the known value within a tolerance of $\frac{1}{4}$ mil without exerting torque on the blade.

In addition, threaded, retractable needles are provided, one at each end of the blade, each of which extends a known distance from the bottom of the blade, which distance is equal to the expected blade gap. At present, the needles extend ^{0.635 mm} (25 mils) beyond the bottom of the blade. If a different blade gap were desired, needles which extended a different amount could be used.

The needles are illustrated in FIGs. 14 and 15. FIG. 14 shows blade 400 with needles 401 and 402 provided on either end. FIG. 15 shows a closeup of one of the needles which is mounted in the blade. As shown, the needle has an extended portion 403, which extends a distance 404 beyond the bottom 408 of the blade. In the SLA-500, the distance is ^{0.635 mm} (25 mils) ^{0.642 mm} $\pm$ (5 mils). As shown, the needle has a threaded portion 405, which is preferably a micrometer thread, ^{23.62 turns/cm} having (60 turns/inch).

The needle mount in the blade is identified with reference numeral 409. As shown, the mount has a threaded portion 406, into which the threaded portion of the needle can be threaded, and stops 407, for controlling the extent to which the needle can protrude beyond the bottom of the blade.

To set the blade gap, the needles are mounted by screwing them into the blade until they protrude the appropriate amount, and then the micrometer screw at one

end of the blade is turned until the needle at that end touches the resin surface. This can easily be determined visually since the tip of the needle will form a large easily-observable meniscus with the resin surface when it comes within $(\frac{0.00635 - 0.0127}{1/4-1/2} \text{ mil})$ of it. Thus, the needle can be placed at the surface within a tolerance of $(\frac{0.00635 - 0.0127}{1/4-1/2} \text{ mil})$. Then, the micrometer screw at the other end of the blade is adjusted until the needle at that end touches the resin surface. Then, the blade is raised, and then lowered to see if both the needles touch the surface at the same time. If not, further iterations of the above cycle are made until they do. When they do, the blade gap is deemed set, and then the needles are unscrewed so they no longer protrude. They will remain in the mounts, however, so that the blade mass stays the same.

Other means for attaching the needles to the blade are possible, including the use of detent pins and release buttons similar to those used with a ratchet set.

To reduce twist and flutter of the blade, a second rail support is added so that each end of the rail is supported by such a rail. This will reduce or eliminate twist and flutter at the unsupported end of the blade.

Because of the double rail support, the blade can be made thicker for increased strength, and also to reduce flutter in the middle of the blade. A thicker blade may not be possible with just one support since the blade would sag more. At present, SLA-500 blades are available at widths of $(\frac{0.00317}{1/8} \text{ in})$, $(\frac{0.0048}{3/16} \text{ in})$, and $(\frac{0.00635}{1/4} \text{ in})$.

Finally, as shown in FIG. 16, the blade cross section can be changed so it is no longer rectangular. First, the bottom of the blade can be constructed so that the non-horizontal edges of the blade near the bottom form angles, identified with reference numerals 506 and 507, known as the angles of attack and separation, respectively, with the resin surface. The angle of attack is the angle in the direction of blade movement while the angle of separation is the angle at the other end. These angles



are added to better improve resin flow underneath the blade. Without these angles, turbulence could be generated underneath the blade, which could create bubbles. These bubbles are problematic since they may travel along with the blade underneath it and be left at the surface of the part after the blade has travelled over it. As a result, they may turn up as an imperfection in the part. By angling the edges of the blade, the pressure gradients are reduced underneath the blade, leading to less fluid separation and therefore less turbulence and less bubble formation. It has been found that, depending on part geometry, these angles can range between about 5 and 8 degrees, and in addition, the angle of attack can differ from the angle of separation. For the SLA-500, an angle of attack of 6 degrees is used.

The blade in FIG. 16 is shown as bisymmetric so that it can sweep in either direction. Alternatively, two asymmetric blades could be used alternatively to sweep in either direction with angles of attack in the direction of movement. Other blade configurations are possible.

FIG. 17 shows the blade of FIG. 16 where each vertex point is rounded. This may further reduce turbulence. FIG. 18 shows a version where the entire bottom is rounded. FIG. 19 shows a version where the bottom is a sharp vertex.

The levelling apparatus of the SLA-500 will now be described. This apparatus overcomes a problem which may occur with the bi-cell detector apparatus described earlier. As discussed earlier, the bi-cell apparatus may be sensitive to bubbles. To overcome this problem in that apparatus, a side tank is added in which bubbles are not formed, and the resin level is detected in the side vat. However, when a layer of resin is supported on a heavy immiscible fluid as described in U.S. Patent Application No. 365,444, the resin level in the side tank may not be an accurate determinate of the resin level in the main vat, as is assumed. This is because during part building,

This Sheet Has Been Replaced





resin in the main vat may be used up disproportionately compared with the side tank. Because of this disproportionality, the liquid in the side tank, when viewed as a whole, may not be as dense as that in the main vat. This may cause the resin level in the side tank to falsely read too high.

To overcome this problem, an apparatus including a float is employed in the SLA-500 to detect the resin level in the main vat instead of the bi-cell apparatus described earlier. The float has the advantage that it is relatively insensitive to bubbles, and so can be used to detect the level of the resin in the main vat as opposed to a side tank. This is because a bubble which attaches to the side of the float will not change its mass, and hence the level at which it floats. Therefore, a side tank is not needed, and the float will accurately detect the resin level even if a layer of resin were floated on a heavy, immiscible fluid.

The float can take many shapes. For the SLA-500, the float is presently in the shape of a small can, having a volume of about 50 cc or more. In addition, the float is advantageously teflon coated, so that any resin that gets on the top, or wets the sides of the float, will rapidly drip or slide off, and not substantially change the mass of the float for an appreciable period of time.

If a bubble were able to lodge itself underneath the float, this could cause an erroneous level measurement since it could change the extent to which the float is submerged. In this instance, to combat this problem, other float designs are possible, as shown in FIG. 20, which would not enable bubbles to lodge underneath the float.

The float apparatus presently used in the SLA-500 is illustrated in FIG. 21. As illustrated, the apparatus comprises float 602, supporting beam 603, bearing 604, and optical detection circuitry 605. As shown, the supporting beam is coupled to the float, which floats on resin



surface 601 placed in vat 600. The beam is also vertically rotatable around bearing 604. In the SLA-500, bearing 604 is advantageously a class 9 bearing.

The optical detection circuitry 605 is shown in detail in FIG. 22. As illustrated, the circuitry comprises member 6051 which is coupled to beam 603, light-emitting diodes ("LEDs") 6052 and 6053, which emit light beams 6056 and 6057, respectively, and optical detectors 6054 and 6055, which detect the uninterrupted presence of light beams 6056 and 6057, respectively. The optical detectors are electronically coupled to a plunger or other means (not shown) described earlier for raising or lowering the resin level in response to electrical signals from the optical detectors.

Any change in the level of the fluid will cause a corresponding vertical displacement of the float. This, in turn, will cause beam 603 to rotate around bearing 604, which will cause member 6051 to displace vertically by a distance which is a magnification of the fluid displacement.

As long as the member 6051, as shown, is situated between and does not block either of the two light beams, 6056 and 6057, the uninterrupted presence of which is detected by optical detectors 6054 and 6055, respectively, the resin level is assumed to be at the correct height. Only when member 6051 is deflected sufficiently to block the passage of one of the light beams to its corresponding optical detector, which will be detected by the failure of the optical detector to pick up any light from its corresponding LED, will it be assumed that the resin is at an incorrect level. In this instance, a plunger or other means electrically coupled to the optical detectors will be either raised or lowered in order to position the resin level, and hence float, at the correct height. If beam 6056 is blocked by the member, which will be detected by optical detector 6054, it will be assumed that the resin level is too low, in which case a plunger or the like



could be lowered until the resin level is raised to the correct height. If beam 6057 is blocked by the member, which will be detected by optical detector 6055, it will be assumed that the resin level is too high, in which case
5 a plunger or the like could be raised until the resin level is lowered to the correct height. Note that both of beams 6056 and 6057 cannot simultaneously be blocked by member 6051. Therefore, there will rarely, if ever, be an ambiguity with this apparatus, in the instance where the
10 resin level is at an incorrect height, regarding whether the proper response thereto is to raise or lower the resin level.

The recoating software used in the SLA-250 will now be described. A specification for the software in the
15 form of a flowchart is illustrated in FIG. 23. Before utilizing the software, a user must first specify certain parameters that will be used to control the movement of the platform. These parameters are ZA, ZV, ZW, and ZD. As described in more detail in U.S. Patent Application
20 S.N. 331,644, the platform is under the control of a computer known as the PROCESS computer. ZA is the amount the PROCESS computer will allow the platform to accelerate or deaccelerate, ZV is the maximum velocity the platform will be allowed to achieve, and ZD is the depth the
25 platform is caused to overdip into the liquid resin before sweeping. As discussed earlier, ZD is typically much greater than a layer thickness. ZW is the settling delay, which is the amount of time the PROCESS computer is directed to wait after the platform has been lowered after
30 sweeping to place the upper surface of the resin layer on top of the part at the same level as the resin in the vat. The PROCESS computer will wait the amount of time specified by ZW before curing the resin on top of the part.

35 Besides these parameters, the user may specify other variables for each layer or range of layers including SN, which is the number of sweeps per layer, and GV, which

stands for global velocity, and indicates that all sweeps are to be made at the specified velocity. The user also may specify V1-V7, which are individual velocities associated with sweeps 1-7, respectively. By setting
5 these values, the user indicates he or she wishes velocity to vary by sweep.

The process begins in step 700, when layer N is drawn. Next, in step 701, the platform is lowered beneath the resin surface by 2D at a speed determined by 2A and
10 ZV. In step 703, a post-dip delay is implemented to allow settling of the resin since the platform has just been moved.

In step 704, a reading from the bi-cell detector is taken and corrected for a bias introduced by the circuitry
15 (identified as BCVAL-BIAS). The reading is then compared with an upper limit, identified as UPLIM, and a lower limit, identified as LOWLIM. If between these two values, the resin level is assumed to be at the correct height.

Assuming the level is at the correct height, in step
20 705, a flag is checked to see if set. The flag is set in response to a key pushed by the user, which indicates that the user manually has added or taken away resin from the vat. Assuming the flag is not set, in step 708, a check is made to determine that SN, the number of sweeps for
25 layer N+1, is greater than 0, and that the platform is still in a safe position so that the blade will not strike it while sweeping. The upper bound for the platform position is identified by the mnemonic NOSWEEP.

Assuming these conditions are met, in step 709, an
30 internal counter, SWEEP, is first initialized to 0, and then incremented. In step 712, a check is made to determine whether the blade is at the front or back of the vat. Assuming the front for the moment, in step 713, the blade is swept to the back of the vat (which is a distance
35 specified by SWEEPDIST) at a velocity which may depend on the current value of SWEEP.

This Sheet Has Been Replaced



When the blade has reached the rear of the vat, it will in the usual instance trigger a switch identified with the mnemonic LIMIT SWITCH. Assuming the limit switch has been activated, in step 727, a check is made to
 5 determine whether all the sweeps specified by SN have been performed for the layer. Assuming they have not, a jump is made back to step 709, and the above cycle repeated.

Turning back to step 714, in the case where the limit switch has not been activated, the blade is slowly moved
 10 towards the rear at the velocity of ^(12.7 mm/sec) (0.5 in/sec), and assuming the limit switch is activated within 2 seconds, a jump is made to step 722. Assuming it is not so activated, the process is aborted in step 721.

Turning back to step 712, assuming the blade is at
 15 the back of the vat, in step 717, the blade is swept towards the front at a velocity which may be a function of the current sweep number, and in step 718, a check is made to see if the limit switch has been activated. Assuming it has, a jump is made to step 722. If it has not, in
 20 step 719, the blade is slowly moved towards the front at a velocity of ^(12.7 mm/sec) (0.5 in/sec), and if the limit switch is activated within 2 sec., a jump is made to step 722. If it is not, the process is aborted in step 721.

Turning back to step 704, which is right after the
 25 platform (and part) have been overdipped below the resin surface, if the resin level is not at the appropriate height, a check is made in step 723 to see if it is too high or too low. If BCVAL-BIAS is greater than UPLIM, the resin level is too low, and the plunger must then be
 30 lowered. In step 724, a check is made to see if the plunger is already at the bottom of the vat, and assuming it is not, in steps 725 and 726, the plunger is lowered, and the plunger position, identified with the mnemonic PLUNGPOS, is updated. In step 727, a delay is instituted
 35 to allow the resin to settle, and a jump is made to step 704 to check the resin level again. The above cycle then repeats.





Turning back to step 724, assuming the plunger is at the bottom of the vat, the only way to raise the level is to add resin to the vat. In step 732, the level is checked again, and assuming it is still too low, in steps 5 733-734, the user is asked to press a key indicating he or she will manually add resin. Until the key is pressed, the process will loop. When the key is pressed, a flag is set (the same flag which is checked in step 705). While the user presumably adds resin to the vat, in step 739, 10 the process will loop until the resin level is at the current level. When it is, in step 740, a message is sent to the user indicating that enough resin has been added, and a jump is made to step 704.

Turning back to step 705, after the resin has been 15 added so that the resin level is at the correct height, the flag must be reset. This condition is detected in steps 705 and 706, and in step 707, the flag is reset.

Turning back to step 723, in the case where BCVAL-BIAS is less than LOWLIM, indicating that the resin level 20 is too high, the plunger must be raised. A check is made in step 728 to see if the plunger is already at its highest possible position, indicated by 0. Assuming it is not, in steps 729-730, the plunger is raised, and the plunger position, identified as PLUNGPOS, is updated. 25 Then, in step 731, a settling delay is instituted, and a jump is made back to step 704.

Turning back to step 728, assuming the plunger is at its highest position already, and cannot be raised anymore, the user must be notified to remove some resin in 30 the vat. In step 741, a check is made to determine that the resin level is still too high, and in steps 742-743, the user is sent a message, asking him or her to remove resin, and is asked to press a key acknowledging the message. Until the key is pressed, the process will loop. 35 When the key is pressed, in step 744, a flag is set, and in step 745, while the user is removing resin, the resin level is checked until it is at the appropriate height.

Until it is, the process will loop. When the level is at the correct height, in step 746, the user is notified to stop removing resin, and a jump made back to step 704. In steps 705-707, as discussed earlier, the flag is reset.

5 Note that levelling need not be performed at each layer, but only when the level may have changed because of any of the following: 1) thermal expansion; 2) shrinkage; and 3) changing displacement caused by platform supports. If neither of these are present, levelling need not be
10 conducted for a layer.

Turning to step 749, when all the sweeps for layer N+1 have been performed, a settling delay equal to ZW will be instituted, and in steps 750-751, the vectors for layer N+1 are computed, and the layer drawn using these vectors
15 in step 751. More detail on computing vectors and drawing layers is provided in U.S. Patent Application S.N. 331,644.

The above cycle is then repeated for all the rest of the layers of the part.

20 A listing of recoating software, version 3.60, used in the SLA-250, will now be provided. The software comprises the following modules, written in TURBO PASCAL, each of which is listed in turn:

	<u>Module</u>	<u>Description</u>
25	UTLSWEEP.PAS	Controls sweeping during part building; used in conjunction with BUILD
30	SINSTEP.PAS	Allows sine wave stepping of the platform during recoating
35	MACHINE.PRM	includes sweeping input/default parameters

This Sheet Has Been Replaced





AUTOLEVEL.PAS

performs leveling in
between the drawing of
layers

UTLADJUST.PAS

used to set resin level
before building a part

5

RECOATER.PAS

uses above programs to
perform recoating
action external to
BUILD

10 As described in more detail in U.S. Patent
Application S.N. 331,644, BUILD is the program which
orchestrates the building of a part. As indicated above,
the programs will, in the usual instance, be used in
conjunction with BUILD. Together, these programs will
15 provide functionabilty substantially similar to that
described above with respect to FIG. 23. RECOATER.PAS,
however, provides a means to perform recoating independent
of BUILD. The software listings follow:

unit UTLSWEEP;

20 {\$D+ \$L+}

{=====

3D Systems Stereolithography System Software

=====

25 UTLSWEEP.INC

SLA Recoater blade and plunger utility include file.

11/15/88 GOF File created.

11/28/88 GOF Updated for production SLA250 board.

30 11/30/88 GOF Add BldSweep.inc, solidify interfaces with
Richard. Its his fault!

01/03/89 GOF Comment out all if keypressed from sweeper
code.

01/13/89 GOF Put MonitorLaserBeamDrift as a part of PD,
35 postdipdelay.

01/18/89 GOF Integrate with Jon's SLA 500 version.



01/24/89 JFT If requested speed is > MaxSafeSineSpeed then we use the old square-wave steps to move the recoater, but if it's <= it then we use sine-wave stepping from SINSTEP.PAS unit, which we now USE here. Both
5 methods changed to correct speed parameters to correct velocity.

01/31/89 JFT Pass ZAccel & ZVeloc as parameters to ZFreeMove & ZMoveGivenDistance.

01/27/89 GOF Add PD2, the second post dip delay for set
10 plunger proc.

01/31/89 GOF Add routine to read and write Machine.prm (MaxBladeMoves)

02/01/89 GOF Add PD2, DrainAccel, and DrainVeloc to sweep.prm.

15 02/07/89 GOF Add XP support. (extra Platform) Also change Veloc to Floatt.

02/24/89 GOF Add exit to SetPlunger if its OK the first ReadBiCell.

02/27/89 GOF Minor cleanup and comments.

20 03/07/89 JFT On PlungerUp full stroke, add better assurance of getting to top. Echo stall message if we don't reach it.

03/17/89 JFT It's only fitting that I'm writing this on a green display. To accomodate the SLA-500,
25 MaxPlungeMoves has become greater than maxInt. So, variables in this unit that take assignment from MaxPlungeMoves are transformed to longint.

04/10/89 JFT Change Velocity to Period.

05/22/89 JFT Change blade malfunction alert to allow
30 user to reposition blade.

07/05/89 JFT Single Coil Holding Torque.

09/20/89 JFT/RAG Added Sweeper Calibration procedure and support for NCR.

-----}
35 {*****}
interface

uses CRT,DOS,UTILITY1,UTLZSTAGE,SINSTEP,BUILDVAR;



```

{*****}
{ math coprocessor support }

5   ($IFOPT N+)
    ($DEFINE COP)
    ($ELSE)
    ($UNDEF COP)
    ($ENDIF)
10  type
    ($IFDEF COP)
    FloatType = Single;
    ($ELSE)
    FloatType = Real;
15  ($ENDIF)

    ($I product.inc)

const
20  { MaxPlungeMoves = 3000; } { for the silver screw } { Now
    in product.inc. }
    { MaxPlungeMoves = 2800;   for the gold screw   }

    defaultPeriod      = 3; { seconds per sweep }
25  minplungemoves     = 1;

    minPeriod          = 0.1;
    maxPeriod          = 10;

30  Bits: array[0..3] of Byte = ($09,$0A,$06,$05);

var
    { global variables)
    NoSweep             : boolean;
35
    PlungerPos          : longint; { Made longint
    from integer for 500. }

```

```

MachineType           : string;
MaxBladeMoves         : integer;
DefaultPlungerStepsPerMil : real;

```

5

```
{ file contents }
```

```

NumSweeps           : integer;
Period             : array[1..7] of FloatType;
BladeGap           : array[1..7] of integer;
10 Bias            : integer;
PlungeMotorDelay   : integer;
PlungStart         : FloatType; { not used }
UpLim              : integer;
LowLim             : integer;
15 BladeGapL0      : FloatType;
PostDipDelay       : integer;
NumChecks          : integer;
PD2                : integer;
XP                 : FloatType;
20 SHOWSWEEP       : boolean;
ProcessSpeedM      : Real ;

(*****)
procedure ReadSWEEPxPRMfile;
25 procedure ReadMACHINExPRMfile;
   procedure WriteMACHINExPRMfile;
   procedure SweeperBack(period : real; StopCode : integer);
   procedure SweeperForward(period:  real;  StopCode :
   integer);
30 procedure MoveBlade(period: real; StopCode:integer);
   procedure PlungerHoldingTorque; {Use after any plunger
   move of 1}
   procedure PlungerDown(numMoves : longint; var StopCode :
   integer);
35 procedure PlungerUp(numMoves : longint; var StopCode :
   integer);

```

This Sheet Has Been Replaced



```

procedure    InitSweeperandPlunger(option:integer;var
StopCode : integer);
procedure    InitSweeper(option:integer;var    StopCode    :
integer);
5  procedure ReadBiCell(recurs:char;var FinalLevel:integer);
    procedure WhichBladeLimit(var LimitSwitch: integer);
        { procedure AddRemoveResin(var FinalLevel: integer); }
    procedure    SetPlunger(numSetPlungers:integer;var
FinalLevel:integer );
10 procedure    DoSweep(DipDepth,LayerDepth:real;
RelaxationTime:integer);
    procedure expSweeperBack(speed:real);
    procedure expSweeperForward(speed:real);
    procedure expMoveBlade(period:real);
15 procedure SweepCal;

    {*****}
    implementation

20 const
    LnSteps:    array[1..60]    of    Integer    =
    (400,200,100,060,50,45,40,35,30,25,20,18,16,14,12,10,10,
    8,8,8,8,6,6,6,5,5,5,4,4,4,4,4,3,3,3,2,2,2,2,2,1,1,1,1,1,
    1,1,1,1,1,1,1,0,0,0,0,0,0,0,0,0);

25
    SwepCoil = $309;
    SweepLim = $308;

    defaultBladeGap          = 100; { percent..}
30    defaultBias            = 0;
    defaultPlungeMotorDelay  = 8;
    defaultPlungStart        = 3.5; { inches - not used
now )
    defaultUpLim             = 5;
35    defaultLowLim          = -5;
    defaultBladeGapL0        = 0.125; { inches between
liquid and blade }

```

This Sheet Has Been Replaced



```

    defaultPostDipDelay      = 3;      ( seconds )
    defaultNumChecks         = -1;     ( automatic mode )
    defaultPD2               = 2;
    defaultDA                = '0.8';
5    defaultDV               = '0.8';
    defaultXP                = '0.0';

    SweepDist                = 12.1;

10  var
    StepIter : integer;
    SweepStep : integer;
    PlungeStep : integer;
    delaytime : integer;
15  junk1,junksc : integer;
    junkKey   : char;

    (*****)
    procedure SweepDefaults;
20  var
    i, code : integer;
    begin
    NumSweeps .      := 1;
    for i := 1 to 7 do begin
25      Period[i]    := defaultPeriod;
        BladeGap[i]  := defaultBladeGap;
    end;
    Bias            := defaultBias;
    PlungeMotorDelay := defaultPlungeMotorDelay;
30  PlungStart      := defaultPlungStart;
    UpLim           := Bias + defaultUpLim;
    LowLim          := Bias + defaultLowLim;
    BladeGapL0      := defaultBladeGapL0 * 25.4; ( convert
to mm )
35  PostDipDelay    := defaultPostDipDelay;
    NumChecks       := defaultNumChecks; ( automatic mode
)

```

This Sheet Has Been Replaced



```

        PD2                := defaultPD2;
        DrainAccel         := defaultDA;
        DrainVeloc         := defaultDV;
        XP                 := RealVal(defaultXP,code);
5      ShowSweep           := false;
    end;
    {*****}
    procedure ReadSWEEPxPRMfile;
    const
10      anyfile             = $3F;
    var
        SweepFile : Text;
        Line       : String;
        i,jj,kk,index : integer;
15      DirInfo        : searchRec;

    begin
        If ShowSweep then writeln ('    Reading machine.prm
file. ');
20      FindFirst('\3dsys\Machine.PRM',anyfile,DirInfo);
        if DosError <> 0 then begin
            window(1,1,80,25);
            ClrScr;
            gotoxy(1,21);
25      writeln;
            writeln('    ERROR: Machine.PRM not found.
');
            UserWait;
            Halt(1);
30      end;
        {-----}
        assign(SweepFile,'\3dsys\Machine.prm');
        reset(SweepFile);
        i := 0;
35      repeat
            readln(sweepFile,line)
        until line = 'SWEEP.PRM';

```

This Sheet Has Been Replaced



```

while (Not Eof(SweepFile)) and (i <= 27) do begin
  readln(SweepFile,line);
  if line[1] <> '!' then inc(i);
  if i = 1 then begin
5      N u m S w e e p s      : =
      IntVal(copy(line,1,pos('!',line)-1),jj);
      end;
      if (i >= 2) and (i <= 15) then begin
        if (i mod 2) = 0
10      t h e n   P e r i o d [ i   d i v
        2]:=RealVal(copy(line,1,pos('!',line)-1),jj)
        e l s e   B l a d e G a p [ i   d i v
        2]:=round(RealVal(copy(line,1,pos('!',line)-1),jj));
        {} { BladeGap[i div 2]:=(1/1000) * (25.4) *
15 BladeGap[i div 2]; }
        { covert mils to mm }
        if (BladeGap[i div 2] <= 0)
        then BladeGap[i div 2] := 0;
        if (BladeGap[i div 2] > 999)
20      then BladeGap[i div 2] := 999;
        end;
        case i of
          1 6      :      B i a s      : =
          IntVal(copy(line,1,pos('!',line)-1),jj);
25      1 7      :      P l u n g e M o t o r D e l a y      :=
          IntVal(copy(line,1,pos('!',line)-1),jj);
          1 8      :      P l u n g S t a r t      : =
          RealVal(copy(line,1,pos('!',line)-1),jj);
          1 9      :      U p L i m      : =
30      IntVal(copy(line,1,pos('!',line)-1),jj);
          2 0      :      L o w L i m      : =
          IntVal(copy(line,1,pos('!',line)-1),jj);
          2 1      :      B l a d e G a p L 0      : =
          (25.4)*RealVal(copy(line,1,pos('!',line)-1),jj);
35      { convert inches to mm }
          (){
          22      :      p o s t D i p D e l a y      :=
          IntVal(copy(line,1,pos('!',line)-1),jj); }

```



```

                2 2      :      N u m C h e c k s      : =
IntVal(copy(line,1,pos('!',line)-1),jj);
{}(                24      :      PD2                : =
IntVal(copy(line,1,pos('!',line)-1),jj); )
5          23 : DrainAccel:= copy(line,1,pos(' ',line)-1);
          24 : DrainVeloc:= copy(line,1,pos(' ',line)-1);
          25 :      XP                : =
RealVal(copy(line,1,pos('!',line)-1),jj);
          26 : ShowSweep := ( upcase(line[1]) = 'S' );
10      end;
      end;
      Close(SweepFile);
      for i := 1 to 7 do begin
          if (Period[i] > maxSweepPeriod) then Period[i] :=
15  maxSweepPeriod;
          if (Period[i] < minSweepPeriod) then Period[i] :=
minSweepPeriod;
          end;
          UpLim                := Bias + UpLim;
20      LowLim                := Bias + LowLim;
          if showsweep then begin
              writeln('Here are the gap percentages--');
              for i := 1 to 7 do writeln('Gap',i,' is
',BladeGap[i]);
25      end;
          ZSafeSweep := ZBladeLevel + 0.060 (warp tolerance + 10
mils) + XP;
          end;

30  {*****}
      procedure ReadMACHINExPRMfile;
      const
          anyfile      = $3F;
      var
35      SweepFile : Text;
          Line : String;
          i,jj,kk,index : integer;

```

This Sheet Has Been Replaced



```

DirInfo      : searchRec;

begin
    If ShowSweep then writeln ('    Reading MACHINE.PRM
5   file. ');
    FindFirst('\3dsys\Machine.PRM',anyfile,DirInfo);
    if DosError <> 0 then begin
        window(1,1,80,25);
        ClrScr;
10        gotoxy(1,21);
        writeln;
        writeln('    ERROR: Machine.prm not found.
        ');

        UserWait;
15        Halt(1);

        end;
    (-----)
        assign(SweepFile,'\3dsys\Machine.prm');
        reset(SweepFile);
20        i := 0;
        repeat
            readln(SweepFile,line)
        until line = 'MACHINE.PRM';
        while (Not Eof(SweepFile)) and (i < 3) do begin
25            readln(SweepFile,line);
            if line[1] <> '!' then inc(i);
            case i of
                1 : begin
                    MachineType := copy(line,1,7);
30                    ProcessSpeedM := RealVal(copy(line, 8, 8),
                    jj) ;

                    end ;
                    2 :      M a x B l a d e M o v e s      :=
                    IntVal(copy(line,1,pos('!',line)-1),jj);
35                    3 :      DefaultPlungerStepsPerMil      :=
                    RealVal(copy(line,1,pos('!',line)-1),jj);
                    end;

```



```

        end;
        close(sweepFile);
    end;

5  {*****}
    procedure WriteMACHINExPRMfile;
    const
        ParamFileName = '\3DSYS\MACHINE.XYZ';
        NewName        = '\3DSYS\MACHINE.PRM';
10
    var
        IOerr,i,m,n,valcode : integer;
        j : longint;
        r : real;
15    ParamFileLine, AppendText : str80;

        ParamFile,NewFile: text;
        DirInfo          : SearchRec;
        InputLine        : string;
20
    begin
        OpenParamFile := ParamFileName;

        assign(ParamFile,OpenParamFile);
25    rewrite(ParamFile);
        assign(NewFile,NewName);
        reset(NewFile);
        while not eof(NewFile) do begin
            readln(NewFile,InputLine);
30        writeln(ParamFile,InputLine);
        end;
        rewrite(NewFile);

        IOerr := IOresult;
35    if IOerr <> 0 then begin
        OpenParamFile := ParamFileName;
        assign(ParamFile,OpenParamFile);

```

. This Sheet Has Been Replaced




```

    reset(ParamFile);
    IOerr := IOresult;
    if IOerr <> 0 then OpenParamFile := ' '
end; {IO error}
5   if IOerr = 0 then begin
        i := 0;
        reset(ParamFile);
        repeat
            readln(paramFile,paramFileLine);
10          writeln(newFile,paramFileLine);
        until paramFileLine = 'MACHINE.PRM';
        readln(paramFile,paramFileLine);
        while (paramFileLine[1] = ' ') or (paramFileLine[1]
= '!!') do
15          begin
                writeln(newFile,paramFileLine);
                readln(paramFile,paramFileLine);
            end;
            writeln(newFile,paramFileLine);    ( This is the
20 machine model #. )
            Str(MaxBladeMoves,paramFileLine);
            writeln(newFile,paramFileLine+'      ! Maximum blade
steps to cross vat');
            readln(paramFile);    ( We just wrote a new val here
25 so throw old away. )
            while not eof(paramFile) do
                begin
                    readln(paramFile,paramFileLine);
                    writeln(newFile,paramFileLine);
30                end;
            end;
            close(NewFile);
            close(ParamFile);
        end;
35
{*****}

```

This Sheet Has Been Replaced





48

```

procedure RotateStep(DirStep: Integer;var InputByte:
Integer);
begin
    StepIter := ((StepIter + DirStep) + 4) mod 4;
5   InputByte := Bits[StepIter];
end;

(*****)
procedure BenDelay(del:integer);
10  var
    x :integer;
    i :integer;
    j :integer;
begin
15  X := 0;
    j := 0;
    repeat
        INC(X);
        for i := 1 to 10 do inc(j); { 100 us }
20  until X>= del;
end;

(*****)
function SweeperParameter(period : real): real;
25 { Feed this the desired period and it will return the
    appropriate parameter }
    { to sweep at that period. You then feed that # to the
    appropriate }
    { sweeper moving procedure.
30      }
var
    RoundPeriod : integer;
    sweeperParam : real;
begin
35  RoundPeriod := round(period);
    if RoundPeriod < minSweepPeriod then RoundPeriod :=
minSweepPeriod;

```



```

    if RoundPeriod > maxSweepPeriod then RoundPeriod :=
maxSweepPeriod;

    (* check for the machine type so the appropriate *)
5    (* Parameter Value for the blade sweep is assigned *)
    if ((ProcessSpeedM * 10) < 1) then
        (* WYSE 286 values *)
        case RoundPeriod of
            1 : sweeperParam := period1Param;
10    SquareMoves start here. )
            2 : sweeperParam := period2Param;
            3 : sweeperParam := period3Param;
            4 : sweeperParam := period4Param;
            5 : sweeperParam := period5Param;
15            6 : sweeperParam := period6Param;
            7 : sweeperParam := period7Param;      ( SineMoves
start here. )
            8 : sweeperParam := period8Param;
            9 : sweeperParam := period9Param;
20            10 : sweeperParam := period10Param;
            11 : sweeperParam := period11Param;
            12 : sweeperParam := period12Param;
            13 : sweeperParam := period13Param;
            14 : sweeperParam := period14Param;
25            15 : sweeperParam := period15Param;
            16 : sweeperParam := period16Param;
            else
                begin
                    if (RoundPeriod > 16) and (RoundPeriod < 21)
30                    then sweeperParam := period16Param -
((RoundPeriod - 16) * ((period16Param-period21Param)/4));
                    if (RoundPeriod > 20) and (RoundPeriod < 31)
                    then sweeperParam := period21Param -
((RoundPeriod - 20) * ((period21Param-period30Param)/10));

35                    end;
                end
    end

```

```

else (* NCR 386 VALUES *)
  (* all NCR 386 values are sine moves *)
  case RoundPeriod of
    1 : sweeperParam := 1.2 ;      2 : sweeperParam :=
5  1.2 ;
    3 : sweeperParam := 1.2 ;      4 : sweeperParam :=
    0.8 ;
    5 : sweeperParam := 0.6 ;      6 : sweeperParam :=
    0.5 ;
10   7 : sweeperParam := 0.4 ;      8 : sweeperParam :=
    0.35 ;
    9 : sweeperParam := 0.31 ;    10 : sweeperParam :=
    0.26 ;
    11 : sweeperParam := 0.245 ;  12 : sweeperParam :=
15   0.22 ;
    13 : sweeperParam := 0.205 ;  14 : sweeperParam :=
    0.19 ;
    15 : sweeperParam := 0.18 ;   16 : sweeperParam :=
    0.16 ;
20   17 : sweeperParam := 0.152 ;  18 : sweeperParam
    :=0.1375;
    19 : sweeperParam := 0.135 ;  20 : sweeperParam :=
    0.13 ;
    21 : sweeperParam := 0.12 ;   22 : sweeperParam
25   :=0.115 ;
    23 : sweeperParam := 0.11 ;   24 : sweeperParam
    :=0.105 ;
    25 : sweeperParam := 0.1 ;     26 : sweeperParam
    :=0.097 ;
30   27 : sweeperParam := 0.0935 ; 28 : sweeperParam :=
    0.09 ;
    29 : sweeperParam := 0.087 ;  30 : sweeperParam
    :=0.085 ;
    end (* case NCR 386 *) ;

```

35

```

  SweeperParameter := sweeperParam;
end;

```

This Sheet Has Been Replaced





51

```

{*****}
function SweeperSqrVelocity(vel:real):real;
{ Converts a velocity in inches per second to the sweepers
private units.  Smaller trueVels correspond to greater
5 velocities. }
{ This function is no longer used. }

var
    trueVel : real;
10 begin
    if vel <= 1 then trueVel := 76
    else if vel <= 2 then trueVel := (vel - 1) * (36-76)
    + 76
    else if vel <= 3 then trueVel := (vel - 2) * (23-36)
15 + 36
    else if vel <= 4 then trueVel := (vel - 3) * (17-23)
    + 23
    else if vel <= 5 then trueVel := (vel - 4) * (12-17)
    + 17
20 else if vel <= 6 then trueVel := (vel - 5) * (10-12)
    + 12
    else if vel <= 7 then trueVel := (vel - 6) * (9-10)
    + 10
    else if vel <= 8 then trueVel := (vel - 7) * (7-9)
25 + 9
    else if vel <= 9 then trueVel := (vel - 8) * (6-7)
    + 7
    else if vel <= 10 then trueVel := (vel - 9) * (6-7)
    + 7
30 else trueVel := 5;
    SweeperSqrVelocity := trueVel;
end;

35 {*****}
procedure SweeperBack(period : real; StopCode : integer);
{ StopCode 0 = normal return ( could be the limit )

```



```

1 = abnormal - limit hit before completed move
( ZStage )
2 = abnormal - keypressed
3 = stall }

5 var
    i : integer;
    key : char;
    speed : real;
begin
10  speed := SweeperParameter(period); (speed holds a raw
    parameter now)
    if period < MinSafeSinePeriod then begin
        delaytime := trunc(speed);
        if (ZStagePos < ZSafeSweep) then exit;
15  port[SweepLim] := $FF;
        i := 0;
        if ShowSweep then writeln('  SWEEPER BACK  ');
        repeat
            if (port[SweepLim] and $40) <> $40 then begin
20  port[SweepCoil] := $00;
                BladePos := MaxBladeMoves;
                StopCode := 0;
                exit; { hit limit switch }
            end;
25  inc(BladePos);
            if i <= 59 then inc(i)                { ramp up
        }
            else if BladePos > (MaxBladeMoves - 60) { ramp
down }
30  then i := MaxBladeMoves - BladePos + 1;

        rotatestep(1, Sweepstep);
        port[SweepCoil] := ((port[SweepCoil] and $F3) or)
(sweepstep and $0F);
35  BenDelay(delaytime + LnSteps[i]);
        until ((keypressed) or ) (BladePos >= MaxBladeMoves);
        port[SweepCoil] := $00;

```

```

{   if keypressed then begin
        key := Readkey;
        StopCode := 2;
    end; }
5   if BladePos >= MaxBladeMoves then begin
        if ShowSweep then writeln(' *** ERROR : STALL in
Sweeper Back ');
        delay(1000);
        beep;
10        BladePos := MaxBladeMoves;
        StopCode := 3;
        end;
    end
    else sinemove(MaxBladeMoves,speed,'r','r',stopcode);
15 end;

{*****}
procedure SweeperForward(period : real; StopCode :
integer);
20 var
    i : integer;
    key : char;
    speed : real;
begin
25   speed := SweeperParameter(period); {speed holds a raw
parameter now}
    if period < MinSafeSinePeriod then begin
        delaytime := trunc(speed);
        if (ZStagePos < ZSafeSweep) then exit;
30   port[SweepLim] := $FF;
        i := 0;
        if ShowSweep then writeln('  SWEEPER FORWARD  ');
        repeat
            if (port[SweepLim] and $20) <> $20 then begin
35             port[SweepCoil] := $00;
                BladePos := 0;
                StopCode := 0;

```

This Sheet Has Been Replaced



```

        exit; ( home limit switch )
    end;
    dec(BladePos);
    if i <= 59 then inc(i)                ( ramp up
5  )

    else if BladePos < 60 ( ramp down )
        then i := BladePos + 1;
        rotatestep(-1,sweepstep);
        port[Sweepcoil] := ((port[Sweepcoil] and $F3) or
10  )(sweepstep and $0F);
        BenDelay(delaytime + LnSteps[i]);
        until {(keypressed) or } (BladePos <= 0);
        port[SweepCoil] := $00;
        ( if keypressed then begin
15         key := Readkey;
            StopCode := 2;
        end; )
        if BladePos <= 0 then begin
            if ShowSweep then writeln(' *** ERROR : STALL in
20  Sweeper Forward ');
            BladePos := 0;
            StopCode := 3;
            beep;
            delay(1000);
25         end;

        end

    else sinemove(MaxBladeMoves,speed,'r','l',stopcode); { We
should never reach }
30         ( this point.
        )
    end;

    {*****}
35  procedure MoveBlade(period : real; StopCode:integer);
    var
        RoundPeriod : integer;

```

This Sheet Has Been Replaced



```

    sweeperParam : real;
begin
    { Determine machine type. }
    if ( ProcessSpeedM * 10 ) >= 1 then
5      { NCR 920 } {Too cool! JFT}
      begin
        if BladePos <> 0 then expsinemove( MaxBladeMoves ,
        SweeperParameter( period ) , 'r' )
          else expsinemove( MaxBladeMoves ,
10  SweeperParameter( period ) , 'l' );
        end else begin
          { Wyse 286 }
          if period >= MinSafeSinePeriod
            then if BladePos <> 0 then
15  expsinemove(MaxBladeMoves,SweeperParameter(period),'r')
              else
                expsinemove(MaxBladeMoves,SweeperParameter(period),'l')
              else if BladePos <> 0 then
                sweeperforward(period,StopCode)
20  else sweeperback(period,StopCode);
            end;
          end;
        end;

    {*****}
25  procedure PlungerHoldingTorque;
    begin
      if StepIter >= $09
      then port[SweptCoil] := ( $08 * 16 and $F0 )
      else port[SweptCoil] := ( $04 * 16 and $F0 );
30  end;

    {*****}
    procedure PlungerDown(numMoves : longint; var StopCode :
    integer);
    {*** numMoves of 0 means go to Plunger limit ***}
35  var
      i,j,k : integer;

```



```

    m : longint;  {} { Changed from integer to accomodate
SLA-500. }
begin
    if PlungerPos >= MaxPlungeMoves then exit;
5      if numMoves <> 1 then
Read3DStateFile(ZStagePos,PlungerPos,JunkSC);
        if ShowSweep then writeln('    MOVING PLUNGER DOWN -
setting level. ');
        if numMoves = 0 then m := MaxPlungeMoves else m :=
10 numMoves;
        k := 1;
        port[SweepCoil] := ( plungeStep * 16 and $F0 );
        repeat
            inc(k);
15          for j := 1 to minplungemoves do begin
                rotatestep(1,plungestep);
                port[Sweepcoil] := ((port[Sweepcoil] and $F0) or)
(plungestep*16 and $F0);
                delay(PlungeMotorDelay);
20          end;
            inc(PlungerPos);
            until (k >= m) or (PlungerPos >= MaxPlungeMoves);
            if numMoves <> 1 then PlungerHoldingTorque;
            {          if numMoves <> 1 then          }
25 Update3DStateFile(ZStagePos,PlungerPos,JunkSC);
        end;

    {*****}
    procedure PlungerUp(numMoves : longint; var StopCode :
30 integer);
    {*** numMoves of 0 means go to Plunger limit ***}
    var
        i,j,k : integer;
        m : longint;
35 HitLimit : boolean;
    begin
        HitLimit := false;

```

This Sheet Has Been Replaced



```

    PlungerStalled := false;
    { If moving up full stroke, set the plunger position to
twice
    MaxPlungeMoves give greater assurance that the
5 plunger reaches the top. }
    StopCode := 1; { Default to stall, set to 0 when we
hit switch. }
    if PlungerPos <= 0 then exit;
        i f      n u m M o v e s      < > 1      t h e n
10 Read3DStateFile(ZStagePos,PlungerPos,JunkSC);
    if numMoves = 0 then PlungerPos := 2 * MaxPlungeMoves;
    if ShowSweep then writeln('    MOVING PLUNGER UP    -
setting level. ');
    if numMoves = 0 then m := 2 * MaxPlungeMoves else m :=
15 numMoves;
    k := 1;
    port[SweepCoil] := ( plungeStep * 16 and $F0 );
    repeat
        inc(k);
20     for j := 1 to minplungemoves do begin
            rotatestep(-1,plungestep);
            port[Sweepcoil] := ((port[Sweepcoil] and $F0)
or )(plungestep*16 and $F0);
            delay(PlungeMotorDelay);
25     end;
        dec(PlungerPos);
        if (port[SweepLim] and $80) <> $80 then begin
            port[SweepCoil] := $00;
            PlungerPos := 0;
30     StopCode := 0;
            HitLimit := true;
            { Update3DStateFile OK for numMoves = 1 }
            Update3DStateFile(ZStagePos,PlungerPos,JunkSC);
            exit; { plunger top limit switch }
35     end;
    until (k >= m) or ( PlungerPos <= 0);
    if numMoves <> 1 then PlungerHoldingTorque;

```

This Sheet Has Been Replaced



```

    { If this was a full-stroke move, check to see if we
    hit the limit switch.  If we didn't, then display that
    situation according to OpMode. }

```

```

    if numMoves = 0 then begin
5      if not HitLimit then PlungerStalled := true;
      end;
    {          if    numMoves    <>    1    then    }
    Update3DStateFile(ZStagePos,PlungerPos,JunkSC);
    end;

```

10

```

    {*****}

```

```

    procedure ReadBiCell(recurs:char;var FinalLevel:integer);

```

```

    (**    recurs = R = recursive readings to check validity

```

```

        N = non-recursive reading

```

15

```

        S = average of 5 simple straight bi-cell
    values with no validity checks **)

```

```

    const

```

```

        LevelReading = 128;

```

```

    var

```

20

```

        b,i,j,count,k,newlevel,sum,stopcode : integer;

```

```

        junkstr,sign : string;

```

```

    begin

```

```

        count := 1;

```

```

        if Recurs = 'S' then count := 5;

```

25

```

        sum := 0;

```

```

        for k := 1 to count do begin

```

```

            port[780] := 12;      { addr ADC port = 780 has 16
channels, use 5 }

```

```

            for i := 1 to 100 do inc(j); { 10 us }

```

30

```

            i := 0;

```

```

            repeat

```

```

                inc(i);

```

```

                b := port[$310];

```

```

                newLevel := port[$30C];

```

35

```

            until (b<128) or (i>2000); (re-repeat this loop)

```

```

            NewLevel := NewLevel - LevelReading;

```

This Sheet Has Been Replaced



```


FinalLevel := NewLevel;
sum := sum + FinalLevel;
if ShowSweep then begin
5   {}      {writeln('      NewLevel =',NewLevel,'
      ');}
      clrscr;
      if NewLevel > 0 then sign := '-' else sign := '+';
      junkstr := concat('New level' =
10  ',sign,intstr(abs(NewLevel)));
      centertext(junkstr,1);
      delay(100);
      end;
      end; { for 1 to count }
      if (ShowSweep) and ( count > 1) then begin
15      if sum > 0 then FinalLevel := trunc((sum /
count)+0.5)
          else FinalLevel := trunc((sum /
count)-0.5);
      {}      { writeln('      AveLevel =',FinalLevel,'      ');}
20      if NewLevel > 0 then sign := '-' else sign := '+';
      junkstr := concat('New level' =
      ',sign,intstr(abs(NewLevel)));
      centertext(junkstr,1);
      delay(200);
25      end;
      if (Recurs = 'S') then exit;
      if (NewLevel = BIAS) and (Recurs = 'R') then begin
      { test for laser blocked or off bi-cell }
      PlungerUp(20,StopCode);
30      ReadBiCell('N',NewLevel);
      if NewLevel = BIAS then begin
      PlungerDown(40,StopCode);
      ReadBiCell('N',NewLevel);
      if NewLevel = BIAS then begin
35      centertext('ERROR : Laser Beam is blocked or
off Bi-Cell.',1);
      UserWait;

```

This Sheet Has Been Replaced



This Sheet Has Been Replaced



```

        Halt(1);
        end;
        PlungerUp(40,StopCode);
        end;
5      PlungerDown(20,StopCode);
        end; ( NewLevel = BIAS )
        end; ( ReadBiCell )

(*****)

10  procedure WhichBladeLimit(var LimitSwitch: integer);
    ( 1 = front, 2 = back, 3 = neither )
    begin
        if (port[SweepLim] and $20) <> $20 then begin
            port[SwepCoil] := $00;
15      LimitSwitch:= 1;
            BladePos := 0;
            exit; ( home limit switch )
        end;
        if (port[SweepLim] and $40) <> $40 then begin
20      port[SwepCoil] := $00;
            LimitSwitch:= 2;
            BladePos := MaxBladeMoves;
            exit; ( back limit switch )
        end;
25      LimitSwitch := 3;
    end;
    (*****)
    procedure InitSweeperandPlunger(option:integer;
                                     var StopCode : integer);
30  var
        wastekey : char;
        kk : integer;
    begin
35      port[$30B] := $98; ( init 8255 )
        port[$30B] := $98; (control port)

```

```

port[Sweepcoil] := 0;      (8255 port C)
port[Sweepplim] := 0;      (8255 port B)
delay(1);

5   WhichBladeLimit(kk); { this sets BladePos }
    if kk = 3 then begin
        beep;
        writeln;
        Centerln(' CAUTION:   Sweeper blade not in home
10  position. ');
        Centerln(' You may manually reposition the blade at
        front of vat. ');
        userwait;
        delay(1);
15    {}{}kk:=-1234;
        WhichBladeLimit(kk);
        {}{}Window(1,1,80,25);
        {}{}Writeln(kk);
        if kk = 3 then begin
20        gotoxy(1,1);
            DrawBox(3,7,73,14,2);
            repeat delay(100) until keypressed;
            junkkey := readkey;
            CursorOn;
25        Halt(1);
            end;
        end;
        PlungerPos := MaxPlungeMoves +150;    { Pad it so we
        KNOW it goes to limit )
30    PlungerUp(0,StopCode);
        PlungerDown((MaxPlungeMoves div 2),StopCode);
        PlungerPos := MaxPlungeMoves div 2;
        if ShowSweep then begin
            writeln('  SWEEPER, PLUNGER, AND ZSTAGE INITIALIZED
35  ');
            delay(800);
        end;

```

This Sheet Has Been Replaced



```

    if keypressed then wastekey := ReadKey;
end;
```

```

{*****}
```

```

5  procedure InitSweeper(option:integer;
                                var StopCode : integer);
    var
        wastekey : char;
        kk : integer;
10  begin

        port[$30B] := $98;    { init 8255 }
        port[$30B] := $98;    { control port }
        port[Sweepcoil] := 0;    { 8255 port C }
15  port[SweepLim] := 0;    { 8255 port B }
        delay(1);

        WhichBladeLimit(kk); { this sets BladePos }
        if kk = 3 then begin
20          beep;
            writeln;
            Centerln(' Sweeper blade not in home position,
program aborting. ');
            Centerln(' You may manually reposition the blade at
25 front of vat. ');
            userwait;
            if (port[SweepLim] and $20) <> $20 then begin
                port[SweepLim] := $00;
            end else begin
30          gotoxy(1,1);
            DrawBox(3,7,73,14,2);
            repeat delay(100) until keypressed;
            junkkey := readkey;
            CursorOn;
35          Halt(1);
        end;
```

This Sheet Has Been Replaced



```

        end;
    end;
    {*****}
    procedure LiquidStableDelay;
5   { Take bicell readings until the difference between
      readings is within epsilon a specified number of times in
      a row. }
    const
        NumOf0DeltaReadsNeeded      = 5;
10   deltaEpsilon                  = 3;
    var
        level,oldlevel              : integer;
        numOf0DeltaReads            : integer;
    begin
15   numOf0DeltaReads := 0;
        ReadBiCell('S',level);
        ReadBiCell('S',oldlevel);
        while (abs(level - oldlevel) > deltaEpsilon) and
            (NumOf0DeltaReads < NumOf0DeltaReadsNeeded) do
20   begin
            ReadBiCell('S',level);
            ReadBiCell('S',oldlevel);
            if abs(level - oldlevel) <= deltaEpsilon then
                inc(NumOf0DeltaReads);
25   end;
        end;
    {*****}

    procedure SetPlunger(numSetPlungers:integer;var
        FinalLevel:integer );
30   var
        level,oldlevel, timesthru,stopcode : integer;
        OKfirstTry              : boolean;
        zPos                    : real;
        pPos                    : longint;
35   junksc                    : integer;
    begin { SetPlunger }

```

This Sheet Has Been Replaced





```

(* {*****})
  if PMWriteFlag then begin
    Read3DStateFile(zPos,pPos,junksc);
    ReadBiCell('N',level);
5    Append(PMWriteFile);
    Writeln(PMWriteFile,zPos:2:6,' : ', pPos:1,' : ',
level:1, ' SetPlunger commences...');
    Close(PMWriteFile);
  end;
10  {*****} *)
    OKfirstTry := false;
    TimesThru := 0;
    if ShowSweep then begin
      if NumSetPlungers = -1 then writeln('AUTOMATIC
15  MODE')
        else writeln('Number of Level
Checks=',numSetPlungers);
      end;
      {} ReadBiCell('N',level);
20  {} if (level < Uplim) and (level > lowlim) then begin
        if ShowSweep then writeln('Bi-cell level OK first
time through SetPlunger.');
```

```

(* {*****})
  if PMWriteFlag then begin
25    Read3DStateFile(zPos,pPos,junksc);
    ReadBiCell('N',level);
    Append(PMWriteFile);
    Writeln(PMWriteFile,zPos:2:6,' : ', pPos:1,' : ',
level:1, ' SetPlunger completed.');
```

```

30    Close(PMWriteFile);
    end;
    {*****} *)
    exit;
    end;
35    if NumSetPlungers = -1 then NumSetPlungers := 25;
    repeat
      if ShowSweep then writeln('READING BI-CELL');
```



65

```
ReadBiCell('N',level);
if (NumSetPlungers = 25) and (TimesThru>=1) and
    (Level<=UpLim) and (Level>=LowLim) then
OKfirstTry:= true;
5
(* if TimesThru = 0 then begin
  { do a validity test here -- }
  oldlevel := level;
  PlungerUp(20,StopCode);
10 ReadBiCell('N',level);
  if level = oldlevel then begin
    PlungerDown(40,StopCode);
    ReadBiCell('N',level);
    if ( level = oldlevel ) and ( level = bias ) then
15 begin
      writeln;
      writeln('ERROR : Laser Beam is not within a
usable bi-cell range. ');
      writeln;
20 UserWait;
      { AddRemoveResin(level); } Halt(1);
      end;
    end else PlungerDown(20,StopCode);
  end; ( TimesThru = 0 ) *)
25
  if level > UpLim then begin
    repeat
      PlungerDown(1,StopCode);
      ReadBiCell('N',level);
30 until level < UpLim;
    end;
    if level < LowLim then begin
      repeat
        PlungerUp(1,StopCode);
35 ReadBiCell('N',level);
        until level > LowLim;
      end;
```



```

      { the state file is not updated in Plunger moves of
1 case... }
      Update3DStateFile(ZStagePos,PlungerPos,StopCode);
      inc(TimesThru);
5      LiquidStableDelay;
      (* {} delay(PD2 * 1000); *)
      { if not((TimesThru > NumSetPlungers) or OKfirstTry)
        then delay(PD2*1000); }
      until (TimesThru > NumSetPlungers) or OKfirstTry;
10     if ShowSweep then writeln ('          FINAL LEVEL
      =',FinalLevel);
      (* {*****}
        if PMWriteFlag then begin
          Read3DStateFile(zPos,pPos,junksc);
15          ReadBiCell('N',level);
          Append(PMWriteFile);
          Writeln(PMWriteFile,zPos:2:6,' : ', pPos:1,' : ',
            level:1, ' SetPlunger completed.');
```

Close(PMWriteFile);

```

20     end;
      {*****} *)
      PlungerHoldingTorque;
      end; { SetPlunger }

25 {*****}
      p      r      o      c      e      d      u      r      e
      OneSweep(index:integer;DipDepth,LayerDepth:real);
      var
        stopcode : integer;
30      currentZPos : real;
        junkPlungerPos : longint;
      begin
        Read3DStateFile(currentZPos, junkPlungerPos, stopcode);

        (*if currentZPos > 0 then DipDepth := 8 else DipDepth
35 := 6;*)
        if index = 1
```




```

    then begin
        if ShowSweep then writeln('    ZMove =', (-(-DipDepth
- BladeGapL0
                    + (LayerDepth * BladeGap[index]/100))
5 /25.4):7:3);
        ZMoveGivenDistance(ZAccel,ZVeloc,-(-DipDepth -
BladeGapL0 +
                    (LayerDepth * BladeGap[index]/100))/25.4
(conv. to inches))
10    end else begin
        if ShowSweep then writeln('    ZMove
= ', (-((LayerDepth * BladeGap[index]/100)-
                    (LayerDepth *
BladeGap[index-1]/100))/25.4):7:3);
15    ZMoveGivenDistance(ZAccel,ZVeloc,-((LayerDepth *
BladeGap[index]/100)-
                    (LayerDepth *
BladeGap[index-1]/100))/25.4);
        end;
20    MoveBlade(Period[index],StopCode);
    end;

    (*****)
    procedure DoSweep(DipDepth,LayerDepth:real;
25 RelaxationTime:integer);
    var
        level,oldlevel,isweep,StopCode : integer;
        currentZPos : real;
        junkPlungerPos : longint;
30    begin
        Read3DStateFile(currentZPos, junkPlungerPos, stopcode);

        (*if currentZPos > 0 then DipDepth := 8 else DipDepth
:= 6;*)
        { ZW=RelaxationTime in seconds // ZD=DipDepth in mm
35    ZV=ZtableVeloc // ZA := ZtableAccel // Next Layer
    Thickness = LayerDepth )

```




```

if ShowSweep then begin
    writeln('    Layer Thickness(mm)=' , LayerDepth:5:3,
5  (mils)=' , (LayerDepth*1000/25.4):5:3);
    writeln('    ZMove =' , (-DipDepth/25.4):7:3, ' inches
    ');
    writeln('                =' , -DipDepth:7:3, ' mm ');
    end;
10  { Move down ZD, DipDepth. }
    ZMoveGivenDistance(ZAccel, ZVeloc, -DipDepth/25.4);
    { wait PD }
    Delay(3500);
    LiquidStableDelay;
15  (* delay(postDipDelay*1000); *)
    if (numchecks <> 0) and (not demoFlag) then
        SetPlunger(numChecks, level);

    if showsweep then begin
20      writeln('ZstagePos=' , ZstagePos:7:2);
        writeln('BladeGapL0/25.4=' , (BladeGapL0/25.4):7:2);
        writeln('DipDepth (mils)=' , (DipDepth/25.4):7:3);
        writeln('LayerDepth (mils)=' , (LayerDepth/25.4):7:3);

        writeln('1-2-3+4=' , ( ZStagePos - (BladeGapL0/25.4)
25  - (DipDepth/25.4)
        + (LayerDepth/25.4) ):7:3);
        writeln('ZSafeSweep=' , ZSafeSweep:7:3);
        userwait;
    end;
30
    { no sweep case }
    { Note this criteria does not involve BladeGap[i]. }
    if (numSweeps <= 0) or (( ZStagePos - (BladeGapL0/25.4)
    - (DipDepth/25.4)
35  + (LayerDepth/25.4) ) < ZSafeSweep) then begin
        if ShowSweep then writeln('*** Unsafe to sweep.');
```



```

    { Move elevator up to the 'draw next layer' position.
  }
    if ShowSweep then writeln('          ZMove
=','(-(LayerDepth-DipDepth)/25.4):7:3);
5
  ZMoveGivenDistance(ZAccel,ZVeloc,-(LayerDepth-DipDepth)/
25.4);
    delay(5);
    Delay(RelaxationTime(ZW));
10    exit;
    end;

    for isweep := 1 to numSweeps do begin
      OneSweep(isweep,DipDepth,LayerDepth);
15    end;
    (Now bring the system to pre-sweep plus part layer
    thickness.)
    if ShowSweep then writeln('          ZMove
=','(-(BladeGapL0-(LayerDepth * BladeGap[numSweeps]/100)+
20 LayerDepth)/25.4):7:3);
    if not HopNguyen then begin
      i f d e m o F l a g t h e n
      ZMoveGivenDistance(ZAccel,ZVeloc,-(BladeGapL0-
        (LayerDepth * BladeGap[numSweeps]/100)
25 )/25.4)
        e l s e
      ZMoveGivenDistance(ZAccel,ZVeloc,-(BladeGapL0-(LayerDepth
      *
        BladeGap[numSweeps]/100)
30 +LayerDepth)/25.4);
    end;
    delay(10);
    end;

35 {*****}

{*****}

```



```
function expSweeperSqrVelocity(vel:real):real;
{ Converts a velocity in inches per second to the sweepers
private units.  Smaller trueVels correspond to greater
velocities.
}
5
var
    trueVel : real;
begin
    if vel <= 1 then trueVel := 76
10    else if vel <= 2 then trueVel := (vel - 1) * (36-76)
    + 76
    else if vel <= 3 then trueVel := (vel - 2) * (23-36)
    + 36
    else if vel <= 4 then trueVel := (vel - 3) * (17-23)
15    + 23
    else if vel <= 5 then trueVel := (vel - 4) * (12-17)
    + 17
    else if vel <= 6 then trueVel := (vel - 5) * (10-12)
    + 12
20    else if vel <= 7 then trueVel := (vel - 6) * (9-10)
    + 10
    else if vel <= 8 then trueVel := (vel - 7) * (7-9)
    + 11
    else if vel <= 9 then trueVel := (vel - 8) * (6-7)
25    + 9
    else if vel <= 10 then trueVel := (vel - 9) * (6-7)
    + 9
    else trueVel := 5;
    expSweeperSqrVelocity := trueVel;
30 end;

procedure expSweeperBack;
{ StopCode 0 = normal return ( could be the limit )
    1 = abnormal - limit hit before completed move
35 { ZStage )
    2 = abnormal - keypressed
    3 = stall }
```



```
var
  i : integer;
  key : char;
  (){ speed : real; }
5  begin
    delaytime := trunc(speed);
    if (ZStagePos < ZSafeSweep) then exit;
    port[SweepLim] := $FF;
    i := 0;
10  if ShowSweep then writeln('  SWEEPER BACK  ');
    repeat
      if (port[SweepLim] and $40) <> $40 then begin
        port[SweepCoil] := $00;
        BladePos := MaxBladeMoves;
15      exit; { hit limit switch }
      end;
      inc(BladePos);
      if i <= 59 then inc(i) { ramp up
    }
20  else if BladePos > (MaxBladeMoves - 60) { ramp
    down }
      then i := MaxBladeMoves - BladePos + 1;

      rotatestep(1, Sweepstep);
25  port[SweepCoil] := ((port[SweepCoil] and $F3) or)
    (sweepstep and $0F);
      BenDelay(delaytime + LnSteps[i]);
      until ((keypressed) or ) (BladePos >= MaxBladeMoves);
      port[SweepCoil] := $00;
30  { if keypressed then begin
      key := Readkey;
      end; }
      if BladePos >= MaxBladeMoves then begin
        if ShowSweep then writeln(' *** ERROR : STALL in
35  Sweeper Back ');
        delay(1000);
        beep;
```



```

        BladePos := MaxBladeMoves;
    end;
end;

5  (*****}
    procedure expSweeperForward;
    var
        i : integer;
        key : char;
10  (){  speed : real; }
    begin
        delaytime := trunc(speed);
        if (ZStagePos < ZSafeSweep) then exit;
        port[SweepLim] := $FF;
15  i := 0;
        if ShowSweep then writeln('  SWEEPER FORWARD  ');
        repeat
            if (port[SweepLim] and $20) <> $20 then begin
                port[SwepCoil] := $00;
20  BladePos := 0;
                exit; { home limit switch }
            end;
            dec(BladePos);
            if i <= 59 then inc(i) { ramp up }
25  else if BladePos < 60 { ramp down }
                then i := BladePos + 1;

            rotatestep(-1,sweepstep);
            port[Swepcoil] := ((port[Swepcoil] and $F3) or
30  )(sweepstep and $0F);
            BenDelay(delaytime + LnSteps[i]);
            until ((keypressed) or ) (BladePos <= 0);
            port[SwepCoil] := $00;
            { if keypressed then begin
35  key := Readkey;
            end; }
            if BladePos <= 0 then begin

```

```

        if ShowSweep then writeln(' *** ERROR : STALL in
Sweeper Forward ');

```

```

        BladePos := 0;

```

```

        beep;

```

```

5      delay(1000);

```

```

        end;

```

```

    end;

```

```

    procedure expMoveBlade(period:real);

```

```

    var

```

```

10      SineMoveParam : real;

```

```

    begin

```

```

    {}{ if period < 2 then begin

```

```

        if BladePos <> 0 then expsweeperforward

```

```

            else expsweeperback;

```

```

15      end else begin

```

```

        case period of

```

```

            2 : SineMoveParam := 10.5;

```

```

            3 : SineMoveParam := 6.8;

```

```

            4 : SineMoveParam := 6.2;

```

```

20          5 : SineMoveParam := 6.1;

```

```

            6 : SineMoveParam := 4;

```

```

            7 : SineMoveParam := 3;

```

```

            8 : SineMoveParam := 2.98;

```

```

            9 : SineMoveParam := 2.97;

```

```

25          10: SineMoveParam := 2.95;

```

```

        end;

```

```

            if BladePos <> 0 then
expsinemove(MaxBladeMoves,SineMoveParam,'r')

```

```

            else

```

```

30      expsinemove(MaxBladeMoves,SineMoveParam,'l');

```

```

        end; )

```

```

        sinemoveparam := period;

```

```

    {}{ if BladePos <> 0 then
expsinemove(MaxBladeMoves,SineMoveParam,'r')

```

```

35      else

```

```

        expsinemove(MaxBladeMoves,SineMoveParam,'l');)

```

```

        if BladePos <> 0 then expsweeperforward(period)

```

This Sheet Has Been Replaced





```
else expsweeperback(period);
```

```
end;
```

```
5
```

```
{*****}
```

```
procedure SweepCal;
```

```
var
```

```
    resp : integer;
```

```
10    theDelay : integer;
```

```
    realDelay : real;
```

```
    hour1, hour2,
```

```
    min1, min2,
```

```
15    sec1, sec2,
```

```
    sec1100, sec2100 : WORD ;
```

```
begin
```

```
    repeat
```

```
20        write( '1) for square, 2) for sine ?' );
```

```
        readln( resp );
```

```
        if resp = 1 then begin
```

```
            write( 'Raw delay ? ' );
```

```
            readln( theDelay );
```

```
25            GetTime(hour1, min1, sec1, sec1100) ;
```

```
                if BladePos <> 0 then
```

```
                    sweeperforward(theDelay, StopCode)
```

```
                        else
```

```
                    sweeperback(theDelay, StopCode);
```

```
30            end else if resp = 2 then begin
```

```
                write( 'Raw delay ? ' );
```

```
                readln( realDelay );
```

```
                GetTime(hour1, min1, sec1, sec1100) ;
```

```
                    if BladePos <> 0 then
```

```
35    expsinmove(MaxBladeMoves, realDelay, 'r')
```

```
                        else
```

```
                    expsinmove(MaxBladeMoves, realDelay, 'l')
```



```

        end;
        GetTime(hour2, min2, sec2, sec2100) ;
        writeln('Start: ', hour1, ':', min1, ':', sec1, ':',
5  sec1100:2) ;
        writeln('Start: ', hour2, ':', min2, ':', sec2, ':',
        sec2100:2) ;
        until false; {forever}
    end;
10  (*****)
    begin
        { blade must be at the front, already checked in
        utlzstage init }
        SweepDefaults;
15  ReadSWEEPxPRMfile;
        ReadMACHINExPRMfile;
        BladePos := 0;
        StepIter := 0;
        NoSweep := false;
20  ZClearBuffer;
        Read3DStateFile(ZStagePos,PlungerPos,junkSC);
    end.
    unit SINSTEP;
    {=====
25  3D Systems Stereolithography System Software
    =====}

    01/24/89 JFT Creation.

30  -----}
    {*****}
    interface
    uses CRT,DOS,UTLZSTAGE,UTILITY1;

35  const
        MaxSafeSineSpeed = 1;
    var

```



```
BladePos          : integer;

procedure sinemove(steps: integer; SweepPeriod: real;
device,dir : char; stopcode:integer);
5 procedure expsinemove(steps:integer; rawParam: real; dir
: char);
  (*****)
  implementation

10 const
    JB          = $300; {plunger, recoater address}
    JBC          = $308; {8255: 4 MSB: plunger}
    CoilDataPort = $309; {      4 LSB: recoater}
    MaxBladeMoves = 1255; { pre - microstepping }
15    SwepCoil = $309;
    SweepLim = $308;

function SweeperVelocity(InchesPerSec:real):real;
20 { No longer used--JFT, 4/3/89 }
  { Used by SineMove to correct the velocity parameter to
  correct speed. }
  var
    vel : real;
25 begin
    if InchesPerSec < 0.1 then vel := (InchesPerSec /
0.1) * 0.11
    else if InchesPerSec <= 0.2 then vel :=
((InchesPerSec - 0.1) / 0.1) * (0.2375-0.11) + 0.11
30    else if InchesPerSec <= 0.5 then vel :=
((InchesPerSec - 0.2) / 0.1) * (0.68-0.2375) + 0.2375
    else if InchesPerSec <= 1.0 then vel :=
((InchesPerSec - 0.5) / 0.3) * (1.55-0.68) + 0.68;
    SweeperVelocity := vel;
35 end;
```



{ } {sinemove: microstepping of recoater and plunger: see description of parameter at begin of file. Last test results: better performance with CoProc N+, Ramp seemed to be to slow for higher velocities (>10), so AccelRampMax :=
5 2 without further tests ! Test for this procedure:
MICRO1.PAS (see conditional defines)}

{ No longer used. Expsinemove is used instead--JFT,
4/3/89 }

10 procedure sinemove(steps: integer; SweepPeriod: real;
device,dir : char; stopcode:integer);

const

15 DAngleArray : array[0..7] of integer =

(10,10,10,15,15,15,30,30);

AccelRampMax : integer = 2;

RampLength : integer = 4;

20 type

LookUpTable = array [0..45] of real;

var

25 stepcount : integer;

X1,X2 : real;

Fld,AccelValue : integer;

DIndex, DAngle : integer;

SinOfAngle,CosOfAngle : integer;

30 QuarterPi,PeriodPoint : integer;

FldTimes : LookUpTable;

BitFactor : integer;

X0Bit,X1Bit,X2Bit : integer;

CoilABit1,CoilABit2 : integer;

35 CoilBBit1,CoilBBit2 : integer;

SingleBit,FLdCount : integer;

j,double,accelcount : integer;



```
single,null           : integer;
output                : integer;
rep                   : integer;
whichLim              : integer;
5    veloc             : real;

begin
    if (ZStagePos < ZSafeSweep) then exit;
    port[SweepLim] := $FF;
10    veloc := SweeperVelocity(12.1/SweepPeriod);

    if device = 'p' then BitFactor := 1
    else BitFactor := 16;
    CoilABit1 := 32 div BitFactor;
15    {20H, 2}
        CoilABit2 := 16 div BitFactor;
    {10H, 1}
        CoilBBit1 := 128 div BitFactor;
    {80H, 8}
20    CoilBBit2 := 64 div BitFactor;
    {40H, 4}

    {Fld}
    Fld := round(100/veloc+0.5);
25

    {Dangle}
    DIndex := round(veloc+0.5)-1;
    if DIndex < 0 then DIndex := 0;
    if DIndex > 7 then DIndex := 7;
30    for j := 0 to DIndex do Dangle := DAngleArray[j];

    { Set QuarterPi to one-fourth period. }
    QuarterPi := 90 div DAngle;

35    { Build a table of values for the five-fourths period
    interval. }
    { The extra quarter lets us look up cosines easily. }
```



```
for j:= 0 to (5 * QuarterPi) do
    FldTimes[j]:=sin(pi / 180 * DAngle * j) * Fld;

5   for stepcount := 1 to steps do begin

        if (port[SweepLim] and $20) <> $20 then
            begin
                if upcase(dir)='R' then
10                begin
                    port[SwepCoil] := $00;
                    bladePos:=0;
                    StopCode    := 0;
                    exit;
15                end;
            end else if (port[SweepLim] and $40) <> $40 then
                begin
                    if upcase(dir)='L' then
                        begin
20                port[SwepCoil] := $00;
                    bladePos:=MaxBladeMoves;
                    StopCode    := 0;
                    exit;
                        end;
25                end;

                if (stepcount <= RampLength) then begin
                    A c c e l V a l u e      : =
                    AccelRampMax*round(veloc/3)*(RampLength-stepcount+1)
30                div RampLength;              {accel}
                    if AccelValue < 1 then AccelValue := 1;
                end;

                if ((steps-stepcount+1) <= RampLength) then begin
35                A c c e l V a l u e      : =
                    AccelRampMax*round(veloc/3)*(RampLength-(steps-stepcount))
```



```
div RampLength;
  if AccelValue < 1 then AccelValue := 1;
end else if (stepcount > RampLength) then
  AccelValue := 1;

5
  { Point SinOfAngle at lo or hi end of table,
depending on step }
  { direction. CosOfAngle is one-quarter pi ahead of
this. }
10  if upcase(dir) = 'L'
    then SinOfAngle := 0
    else SinOfAngle := 360 div DAngle;
    CosOfAngle := SinOfAngle + QuarterPi;

15  for PeriodPoint := 0 to (4 * QuarterPi) do begin

    X1 := FldTimes[SinOfAngle];
    if X1 > 0 then X1bit := CoilABit1      (32 20H)
    else if X1 < 0 then X1bit := CoilABit2 (16 10H)
20  else X1bit := 0;

    X2 := FldTimes[CosOfAngle];
    if X2 > 0 then X2bit := CoilBBit1      (128 80H)
    else if X2 < 0 then X2bit := CoilBBit2 (64 40H)
25  else X2bit := 0;
    X0Bit := 0;

    if abs(X1) < abs(X2) then begin
      double := abs(round(X1 +0.5));
30  SingleBit := X2bit;
    end;
    if abs(X2) <= abs(X1) then begin
      double := abs(round(X2 +0.5));
      SingleBit := X1bit;
35  end;
    single := abs(round(abs(X1)-abs(X2)+0.5));
    null := Fld-double-single;
```

```

for accelcount := 1 to AccelValue do begin

    if upcase(dir) = 'L' then begin          (left)
5
        if double > 0 then begin
            for j := 0 to double do port[CoilDataPort] :=
X1bit+X2bit;
        end;
10        if single > 0 then begin
            for j := 0 to single do port[CoilDataPort] :=
SingleBit;
        end;
        if null > 0 then begin
15        for j := 0 to null do port[CoilDataPort] :=
X0Bit;
        end;

            (end dir ="l")

20        end else begin {dir "r"}
            (right)

                if null > 0 then begin
                    for j := 0 to null do port[CoilDataPort] :=
25 X0Bit;
                end;
                if single > 0 then begin
                    for j := 0 to single do port[CoilDataPort] :=
SingleBit;
30                end;
                if double > 0 then begin
                    for j := 0 to double do port[CoilDataPort] :=
X1bit+X2bit;
                end;
35        end;          (dir "r")

    end;          (accelcount)

```



```

      { Update lookup table pointers. }
      if upcase(dir) = 'R' then begin
        SinOfAngle := SinOfAngle-1;
5      end else begin
        SinOfAngle := SinOfAngle+1;
        end;
        CosOfAngle := SinOfAngle + QuarterPi;

10      end;                                (for SinOfAngle...)

      end;                                (steps)

      port[CoilDataPort] := $FF;
15      if BladePos <= 0 then begin
      {}      { if ShowSweep then writeln(' *** ERROR : STALL in
      Sweeper SineMove Forward ');}
        BladePos := 0;
        StopCode := 3;
20      beep;
        delay(1000);
      end;
    end;

25  {*****}

  procedure expsinmove(steps:integer; rawParam: real; dir
    : char);

30  const
    DAngleArray          : array[0..7] of integer =

      (10,10,10,15,15,15,30,30);
      AccelRampMax        : integer = 2;
35  RampLength           : integer = 4;

  type
    LookUpTable = array [0..45] of real;

```

This Sheet Has Been Replaced



var

```

    stepcount           : integer;
5    X1,X2              : real;
    Fld,AccelValue      : integer;
    DIndex, DAngle      : integer;
    SinOfAngle,CosOfAngle : integer;
    QuarterPi,PeriodPoint : integer;
10   FldTimes           : LookUpTable;
    BitFactor           : integer;
    X0Bit,X1Bit,X2Bit   : integer;
    CoilABit1,CoilABit2 : integer;
    CoilBBit1,CoilBBit2 : integer;
15   SingleBit,FLdCount : integer;
    j,double,accelcount : integer;
    single,null         : integer;
    output              : integer;
    rep                 : integer;
20   whichLim           : integer;
    veloc               : real;

```

begin

```

    if (ZStagePos < ZSafeSweep) then exit;
25   port[SweepLim] := $FF;
    veloc := rawParam;

    BitFactor := 16;
    CoilABit1 := 32 div BitFactor;      {20H, 2}
30   CoilABit2 := 16 div BitFactor;     {10H, 1}
    CoilBBit1 := 128 div BitFactor;     {80H, 8}
    CoilBBit2 := 64 div BitFactor;      {40H, 4}

```

```

    {Fld}
35   Fld := round(100/veloc+0.5);

```

{Dangle}

This Sheet Has Been Replaced



```

DIndex := round(veloc+0.5)-1;
if DIndex < 0 then DIndex := 0;
if DIndex > 7 then DIndex := 7;
for j := 0 to DIndex do DAngle := DAngleArray[j];
5
  { Set QuarterPi to one-fourth period. }
  QuarterPi := 90 div DAngle;

  { Build a table of values for the five-fourths period
10 interval. }
  { The extra quarter lets us look up cosines easily.
    }
  for j:= 0 to (5 * QuarterPi) do
    FldTimes[j]:=sin(pi / 180 * DAngle * j) * Fld;
15

  for stepcount := 1 to steps do begin

    if (port[SweepLim] and $20) <> $20 then
20      begin
        if upcase(dir)='R' then
          begin
            port[SwepCoil] := $00;
            bladePos:=0;
25            exit;
          end;
        end else if (port[SweepLim] and $40) <> $40 then
          begin
            if upcase(dir)='L' then
30              begin
                port[SwepCoil] := $00;
                bladePos:=MaxBladeMoves;
                exit;
              end;
            end;
35          end;

    if (stepcount <= RampLength) then begin

```

This Sheet Has Been Replaced



```

                                A c c e l V a l u e      : =
AccelRampMax*round(veloc/3)*(RampLength-stepcount+1)
    div RampLength;                                {accel}
    if AccelValue < 1 then AccelValue := 1;
5      end;

    if ((steps-stepcount+1) <= RampLength) then begin
                                A c c e l V a l u e      : =
AccelRampMax*round(veloc/3)*(RampLength-(steps-stepcount))

10      div RampLength;
        if AccelValue < 1 then AccelValue := 1;
    end else if (stepcount > RampLength) then
        AccelValue := 1;

15      { Point SinOfAngle at lo or hi end of table,
        depending on step }
        { direction. CosOfAngle is one-quarter pi ahead of
        this.      }
        if upcase(dir) = 'L'
20      then SinOfAngle := 0
        else SinOfAngle := 360 div DAngle;
        CosOfAngle := SinOfAngle + QuarterPi;

        for PeriodPoint := 0 to (4 * QuarterPi) do begin
25
            X1 := FldTimes[SinOfAngle];
            if X1 > 0 then X1bit := CoilABit1           {32 20H}
            else if X1 < 0 then X1bit := CoilABit2       {16 10H}
            else X1bit := 0;

30
            X2 := FldTimes[CosOfAngle];
            if X2 > 0 then X2bit := CoilBBit1           {128 80H}
            else if X2 < 0 then X2bit := CoilBBit2       {64 40H}
            else X2bit := 0;

35      X0Bit := 0;

```

This Sheet Has Been Replaced





```

    if abs(X1) < abs(X2) then begin
        double := abs(round(X1 +0.5));
        SingleBit := X2bit;
    end;
5    if abs(X2) <= abs(X1) then begin
        double := abs(round(X2 +0.5));
        SingleBit := X1bit;
    end;
    single := abs(round(abs(X1)-abs(X2)+0.5));
10    null := Fld-double-single;

    for accelcount := 1 to AccelValue do begin

        if upcase(dir) = 'L' then begin            (left)
15
            if double > 0 then begin
                for j := 0 to double do port[CoilDataPort] :=
X1bit+X2bit;
            end;
20            if single > 0 then begin
                for j := 0 to single do port[CoilDataPort] :=
SingleBit;
            end;
            if null > 0 then begin
25                for j := 0 to null do port[CoilDataPort] :=
X0Bit;
            end;

                                {end dir ="l"}

30        end else begin {dir "r"}
            {right}

            if null > 0 then begin
                for j := 0 to null do port[CoilDataPort] :=
35 X0Bit;
            end;
            if single > 0 then begin

```



```

    for j := 0 to single do port[CoilDataPort] :=
SingleBit;
    end;
    if double > 0 then begin
5      for j := 0 to double do port[CoilDataPort] :=
X1bit+X2bit;
        end;
        end;          (dir "r")

10      end;          {accelcount}

      ( Update lookup table pointers. )
      if upcase(dir) = 'R' then begin
        SinOfAngle := SinOfAngle-1;
15      end else begin
        SinOfAngle := SinOfAngle+1;
        end;
        CosOfAngle := SinOfAngle + QuarterPi;

20      end;          {for SinOfAngle...}

      end;          {steps}

      port[CoilDataPort] := $FF;
25      if BladePos <= 0 then begin
      ( )      ( if ShowSweep then writeln(' *** ERROR : STALL in
Sweeper SineMove Forward ');)
        BladePos := 0;
        beep;
30        delay(1000);
        end;
      end;

      ( *****)

35      end.^Z

```



```

!*****
!
!  Build Parameter File
!  Version 3.60
5  !
!  *****
!  Part Name:                Date:
!  Important Data:
!  last altered:
10 !  *****
!  place options together inside of quotes; use "" if no
options
!
""
15 !
!  General Parameters
!
800          Elevator board base address
100          elevator pitch
20 3.556      XY-only scale factor; Use 3.556 for Inches
and S1ize res=1000
!!1, 0.0
!!A0, 0.0
17000        X-coordinate offsets
25 17000      Y-coordinate offsets
5000         Max number of bytes per block in Laser Queue
26000,26000  Minimum X and Y of vat area (for graphics
viewport)
39000,39000  Maximum X and Y of vat area
30 !
#TOP,"DC+"    ! Drift Correction on
!
!
#BTM,"ZW 30;          ! Z-axis wait time in
35 seconds
                ZD 8;                ! Z-axis dip depth in mm

```



```

                ZV 0.2;                                ! Z-axis velocity
parameter
                ZA 0.2"                                ! Z-axis acceleration
parameter
5  !*****
MACHINE.PRM
! MACHINE.PRM machine parameter file 05/18/89
!
SLA-250      ! machine type
10 620        ! maximum blade steps to cross vat
0.03         ! plunger steps per mil of elevator movement

BEAM.PRM
! PROFILE Parameters Table
15 ! Version 3.60
!
5000,32767   beam rest position
!
! Beam Profile Data
20 !
3            number of profile sensors
3            second sensor channel #
63104,55452  sensor #1 changed 3-24-89 MJH
0.045        1/2 mil hole multiplier to get mW
25 0.0116    1 mil
0.00592      2 mils changed 3-24-89 MJH
0.00072      4 mils
1            first sensor channel #
4752,6543    sensor #2 changed 3-24-89 MJH
30 0.040     1/2 mil hole multiplier to get mW
0.0102       1 mil
0.00776      2 mils changed 3-24-89 MJH
0.00063      4 mils
5
35 32767,32767 position of 2 mil hole (#3)
0.040        1/2 mil hole multiplier to get mW
0.0010       1 mil


```



```

0.00605      2 mils
0.00063      4 mils
!
!  Temperature Data
5  !
    4          thermometer channel #
    13         # points in thermistor calibration table
    19900,10   temperature calibration table...
    15720,15   format is resistance (Ohms), temperature
10 (C)
    12490,20
    10000,25
    8057,30
    6531,35
15 5327,40
    4370,45
    3604,50
    2986,55
    2486,60
20 2081,65
    1749,70
    !
    !  Fast, Medium & Slow Calibration Delay Values
    !
25 !  line format is Spiral time (ms), between points (secs,
    1/10 sec res),
    !  between rows (secs)
    !
    20,0,0      Fast: 20 ms, turnaround as quickly as
30 possible
    50,0.5,5    Medium: 50 ms, 1/2 sec, 5 secs
    100,20,120  Slow: 100 ms, 20 secs, 2 minutes
    !
    !  Slew Rate Limit Parameters
35 !
    1000        maximum step in either axis
    2           delay between step points in milliseconds

```



!*****

POWER.PRM

! POWER V3.60 Parameters File

!

5 LASERPOWERTYPE=TOGGLE LEVEL or UNKNOWN

!*****

SWEEP.PRM

! SWEEP.PRM 05/18/89

!

10 1 ! NS numsweeps
10 ! P1 sweep velocity
100 ! G1 blade gap as a percent of next layer
thickness (ignore if NS=1)
10 ! P2
15 100 ! G2
10 ! P3
100 ! G3
10 ! P4
100 ! G4
20 10 ! P5
100 ! G5
10 ! P6
100 ! G6
10 ! P7
25 100 ! G7
0 ! BI bias when He laser is blocked
9 ! MD plunge Motor Delay : delay between plunger
motor pulses (ms)
3.0 ! PS PlungStart : inches plunger moves down to
30 its start position
4 ! UL UPLIM : bi-cell activate level
-4 ! LL LOWLIM: bi-cell activate level
0.125 ! BG BladeGapL0 - distance between liquid and
recoater blade (inches)
35 -1 ! NC Number of checks for leveling (0 -> 5 or
-1 for auto mode ***)
0.3 ! DA Draining elevator acceleration

```

0.5      !   DV Draining elevator velocity
0                !           XP   eXtra   Platform
height(mils).ZSafeSweep=ZBladeLevel+60mil+XP
noshow    !   Show or No-Show sweep info ( S or N in the
5 first column )
!*****
ZSTAGE.PRM
!   ZSTAGE Parameters File
!   Version 3.60
10 !
""      command line options: /NEGZ, /S, /M
800      elevator control board I/O address
.5      acceleration parameter
1        velocity parameter
15 2000000 big distance (max movement for up or down)
100000   # of microsteps per inch
2000     timeout value
10000    ZBladeLevel
10000    ZLiquidLevel
20 10000  ZUnloadLevel
^Z

```

This Sheet Has Been Replaced





```
program AutoLevel;
uses crt,utility1,utlsweep,windows;
var
    junksc          : integer;
5   DisplayWind     : wind;
    ExitSave        : pointer;
    Done            : boolean;
    HoldKey         : char;
    theLevel        : integer;
10
    {$F+}procedure ExitAutoLevel;{$F-}
begin
    CursorOn;
    DefaultWindow;
15   ClrScr;
    ExitProc := ExitSave;
end;

procedure DrawMainScreen;
20 begin
    clrscr;
    centertext('This is the Surface Position Repeatability
    POD',1);
    centertext('Auto-Levelling Program V1.1',2);
25   centertext('Press L to Level, X to exit.',4);
end;

procedure DoAutoLevel;
begin
30   centertext('Auto-Levelling in progress...',6);
    SetPlunger(-1,theLevel);
    centertext('Levelled at ',6);
    write(PlungerPos);
    writeln(' ');
35   userwait;
    DrawMainScreen;
end;
```

```

begin
  { Initialize program. }
  ExitSave := ExitProc;
5   ExitProc := @ExitAutoLevel;
  CursorOff;
  Done := false;

  { Initialize screen. }
10  clrscr;
  DefineWindow(DisplayWind,5,5,75,20,2);
  FrameWindow(DisplayWind);
  ActivateWindow(DisplayWind);
  DrawMainScreen;

15  { Read keys. }
  { "X" key exits. }
  { "L" key autolevels. }
  repeat
20    repeat
      delay(100);
      until keypressed;
      HoldKey := upcase(ReadKey);
      if HoldKey = 'X' then Done := true;
25    if HoldKey = 'L' then DoAutoLevel;
  until Done;
end.^Z

```

This Sheet Has Been Replaced



```

{ 02/01/89 JFT Made into a unit from Wayne Vinson's code.
  02/27/89 JFT Modified "Too High" or "Too Low" sections
to read until a peak is reached, then read until the
abs(level) is less than a threshold value. The user is
5 adding or removing resin during this time.
  03/01/89 JFT Above fix only works well for resin
removal. Go to modified older method with epsilon of 5.
Change user messages.
  05/04/89 JFT Fixed (?) the bug that caused repeated
10 adjustments when the bicell was bullseyed. Changed user
messages and sounds. Removed need to press key when
adjustment complete.
  05/25/89 JFT Use procedure HandleKeyboardRequest in
adjust resin level loops so that the user may abort
15 w/ctrl-c or break.
  06/16/89 JFT Lengthen move done by plunger from 40 to 60
when checking to see if we're on the bicell. Also use
upLim and lowLim instead of twice upLim and twice lowLim.
  08/03/89 JFT In CheckLevel, if 2nd or 3rd readings are
20 0 then call it off the bicell.
  {
  {*****}
unit UtlAdjust;
  { $ M 16384,0,0}
  {$D+;I+}
25 {*****}
  interface
  uses Crt,Dos,Utility1,UtlSweep,UtlZStage,Windows;

  procedure AddRemoveResin(var FinalLevel: integer);
30 p r o c e d u r e
  procReadBiCell(displaydelay:integer;echo:boolean);
  procedure LongReadBiCell(displaydelay:integer);
  procedure procPlungerUp(echo:boolean);
  procedure procPlungerDown(echo:boolean);
35
  {*****}
  implementation

```



```

const
    epsilon = 2;  { +/- bias variation used in add/remove
resin }
5
var
    opt,stopc : integer;
    velocity2 : real;
    key, junkkey : char;
10    level      : integer;
    delaytime   : integer;
    onbicell,leveladjusted : boolean;
    tempstring  : string;
    AlertWind,DataWind : wind;
15 {*****}
    p      r      o      c      e      d      u      r      e
    procReadBiCell(displaydelay:integer;echo:boolean);
        {If echo is true then write levels to screen}
    var
20        junkStr:string;
        sign   :string;
    begin
        ReadBiCell('N',level);
        if echo then begin
25            if level < 0 then sign := '+' else sign := '-';
        {Reverse signs for display}
            if level = 0 then sign := '';           {0 gets no
sign}
            junkStr := concat('The liquid level is
30 ',sign,IntStr(abs(level)));
            centerText(junkStr,1);
            end;
            delay(displaydelay);
        end;
35 {*****}
    procedure LongReadBiCell(displaydelay:integer);
    begin

```





```
        repeat
            procReadBiCell(displaydelay,false); {don't echo to
levels to screen)
            until keypressed;
5         key := Readkey;
        end;
        {*****}
        procedure procPlungerUp(echo:boolean);
        begin
10         leveladjusted := false;
            repeat
                PlungerUp(10,stopc);
                procReadBiCell(1,echo);
                until keypressed;
15         junkkey := upcase(Readkey);
        end;
        {*****}
        procedure procPlungerDown(echo:boolean);
        begin
20         leveladjusted := false;
            repeat
                PlungerDown(10,stopc);
                procReadBiCell(1,echo);
                until keypressed;
25         junkkey := upcase(Readkey);
        end;
        {*****}
        procedure DoBeep(freq,time : integer);
        begin
30         sound(freq);
            delay(time);
            nosound;
        end;
        {*****}
35 procedure DoFinalAdjustment;
    var
        i,level,tempint,returncode : integer;
```

```

wasteKey                : char;
begin
  ActivateWindow(AlertWind);
  clrscr;
5    if onbicell then begin { otherwise setplunger gets
    pissed }
      centertext('Performing automated fine adjustment
of resin level.',2);
      centertext('Please stand by.',5);
10   ActivateWindow(DataWind);
      clrscr;
      ReadBiCell('N',level);
      (){
        tempint := 8;} { do course adjustment first
      }
15   tempint := 32; { do course adjustment first }
      repeat
        HandleKeyboardRequest( wasteKey );
        if (level > uplim) then begin
          repeat
20             for i := 1 to tempint do begin
                PlungerDown(1,ReturnCode);
                delay(400 div tempint);
            end; { of i }
            ReadBiCell('N',level);
25             until level < UpLim;
          end;
          if (level < lowlim) then begin
            repeat
              for i := 1 to tempint do begin
30                 PlungerUp(1,returnCode);
                delay(400 div tempint);
            end; { i }
            ReadBiCell('N',level);
            until level > LowLim;
35             end;
          clrscr;

```

This Sheet Has Been Replaced



```

        centertext('Pausing to allow resin to
settle.',1);
        delay(5000);    { allow settling time }
        ClrScr;         { Pause completed }
5         tempint := 1; { now do finer adjustment }
        ReadBicell('S',level);
        until (level < uplim) and (level > lowlim);
        ActivateWindow(AlertWind);
        clrscr;
10        centertext('Resin level now adjusted for part
building.',4);
        leveladjusted := true;
        delay(2500);
        beep;
15        end; { if onbicell }
        end; { of dofinaldjustment }
        {*****}
        procedure CheckLevel;
        { reads and evaluates if on or off bicell
20        and sets boolean bicell accordingly }
        var
            returncode,firstlevel,secondlevel,thirdlevel,tempint
: integer;
        begin
25        ActivateWindow(AlertWind);
            ClrScr;
            onbicell := false;
            Centertext('Checking resin level.',1);
            Centertext('Please stand by.',5);
30        firstlevel := 0;
            secondlevel := 0;
            thirdlevel := 0;
            ActivateWindow(DataWind);
            clrscr;
35        ReadBicell('S',firstlevel);
            if (firstlevel > 2*uplim) or (firstlevel < 2*lowlim)
then onbicell := true

```



```

else begin { first gave bias type reading .. could
still be dead on }
    PlungerUp(60,returncode);
    { This delay added to thwart the recurrent
5 adjustment bug. }
    Delay(3000);
    ReadBicell('S',secondlevel);
    PlungerDown(120,returncode);
    { This delay added to thwart the recurrent
10 adjustment bug. }
    Delay(3000);
    ReadBicell('S',thirdlevel);
    PlungerUp(60,returncode);
    { both 2nd and 3rd must not give bias reading
15 to be on bicell }
    (*
        i f   n o t   ( s e c o n d l e v e l
in[bias-epsilon..bias+epsilon]) and
        not (thirdlevel in[bias-epsilon..bias+epsilon])
20 then OnBicell := true;
    *)
    (*
        i f ((secondlevel > uplim) or (secondlevel <
lowlim)) and
25 ((thirdlevel > uplim) or (thirdlevel <
lowlim)) then
        OnBicell := true;
    *)
    i f ( ( s e c o n d L e v e l > b i a s + e p s i l o n ) o r (
30 t h i r d L e v e l < b i a s - e p s i l o n ) )
        then OnBicell := true;
    { The following was added to accomodate SLAs with
biases outside of the range -1..+1. When off the bicell,
those SLAs showed as on the bicell. This should catch
35 that case. --JFT }
    i f ( s e c o n d L e v e l = b i a s ) o r ( t h i r d L e v e l = b i a s
) then OnBicell := false;

```



```

        ActivateWindow(AlertWind);
    end; { else }
end; { of checklevel }
{*****}
5  procedure CenterPlunger;
    var
        returncode,midplunge,plungemove : integer;
    begin
        midplunge := maxplungemoves div 2;
10     plungemove := abs(midplunge - plungerpos);
        { always put plunger in mid position before
starting part }
        { for now always go all the way to top }
        plungerup(0,returncode);
15     plungerdown(maxplungemoves div 2,stopc);
        update3dstatefile(zstagepos,plungerpos,returncode);
        { if tracking shows no problem then activate
following instead }
        (      if      plungerpos      <      midplunge      then
20     plungerdown(plungemove,stopc);
            if      plungerpos      >      midplunge      then
plungerup(plungemove,stopc);)
        FrameWindow(DataWind);
        ActivateWindow(DataWind);
25     clrscr;
        centertext('Pausing to allow resin to settle.',1);
        delay(10000); { wait 10 sec for level to stabilize
after
                        fast plunge move )
30     ActivateWindow(AlertWind);
        end; { centerplunger }
        {*****}
        procedure AddRemoveResin(var FinalLevel: integer);
            const
35         CoarseAdjustLim = 10;
            var

```



```

        tempint,oldlevel,plungemove,option,returncode      :
integer;
        key,wastekey : char;
        tempreal : real;
5       PeakReached : boolean;
        MaxReading : integer;
begin
        DefineWindow(AlertWind,10,7,70,18,2);
        DefineWindow(DataWind,10,23,70,25,1);
10      DefaultWindow;
        ClrScr;
        writeln;
        centerln(Product+' Resin Level Adjustment Utility');

        writeln;
15      centerln('Copyright (C) 1989 by 3D Systems, Inc. ');
        centerln('3D Systems StereoLithography System');
        FrameWindow(AlertWind);
        { FrameWindow(DataWind);      }
        { DataWind is framed in CenterPlunger }
20      ActivateWindow(AlertWind);

        { first see if already did level check }
        {  showsweep := true; }
        if not leveladjusted then begin
25          centertext('Initializing      resin      adjustment
apparatus.',2);
          centertext('Please stand by.',5);
          CenterPlunger;
          CheckLevel;
30          Delay(300);
          if OnBicell then begin
              ActivateWindow(AlertWind);
              ClrScr;
              centertext('The resin level is currently
35 in',2);

```

This Sheet Has Been Replaced



```

        centertext('an acceptable range for part
building.',3);
        centertext('Manual adjustment will be
unnecessary.',5);
5        DoFinalAdjustment;
        Update3DStateFile(ZStagePos,PlungerPos,stopc);

        exit;
    end; { if OnBicell }
    ActivateWindow(AlertWind);
10    ClrScr;
    for tempint := 1 to 3 do begin
        beep;
        delay(100);
    end; { of tempint }
15    centertext('The resin level is not in an
acceptable',2);
        centertext('range for part building.',3);
        centertext('A MANUAL adjustment will be
necessary:',5);
20    centertext('Look at the white leveling pointer at
the',7);
        centertext('rear of the vat.',8);
        centertext('Is resin touching the pointer?',9);
        While keypressed do wastekey := readkey; { catch
25 all previous keys }
        Wastekey := Readkey; { get new key }

        { LEVEL TOO HIGH }

30    If Upcase(Wastekey) = 'Y' then begin ( level too
high )

        ClrScr;
        centertext('The resin level is too high.',1);
        centertext('Please remove resin until the beep
35 sounds.',5);

```

This Sheet Has Been Replaced



```

        centertext('Stop removing resin when you hear
the beep.',6);
        PeakReached := false;
        MaxReading := 0;
5      Repeat
          HandleKeyboardRequest( wasteKey );
          ActivateWindow(DataWind);
          readbicell('N',level); { need quick read
here }
10      { delay(10); }
          ActivateWindow(AlertWind);
          if abs(level) > MaxReading then MaxReading
:= abs(level);
          if (abs(level) < MaxReading) and
15 (MaxReading > 50)
            then PeakReached := true;
          {}(
            Until (level < bias-epsilon) or (level >
bias+epsilon);)
          {}(
            Until PeakReached and (abs(level) <
20 CoarseAdjustLim); )
          Until abs(level) > uplim+1{( bias ) +
epsilon);
          { bicell values negative at bicell top }
          centertext('Press any key to continue...',8);
25      Repeat
          DoBeep(100,1000);
          { delay(50); }
          Until keypressed;
          wastekey := readkey;
30      clrscr;
          centertext('User finished removing resin.',5);

          CheckLevel; { to check for too much liquid
removed }

          if not onbicell then begin
35      ClrScr;

```

This Sheet Has Been Replaced



```

                                centertext('Resin level not in acceptable
range.',5);
                                DoBeep(100,1000);
                                delay(2000);
5                                addremoveresin(stopc);
                                end; { if not onbicell }
                                DoFinalAdjustment;
                                Update3DStateFile(ZStagePos,PlungerPos,stopc);

                                exit;
10                                end; { if level too high }

                                { LEVEL TOO LOW }

                                ClrScr;
15                                centertext('The resin level is too low.',1);
                                centertext('Please add resin SLOWLY until the
beep sounds.',5);
                                centertext('Stop adding resin when you hear the
beep.',6);
20                                PeakReached := false;
                                MaxReading := 0;
                                Repeat
                                    HandleKeyboardRequest( wasteKey );
                                    ActivateWindow(DataWind);
25                                readbicell('N',level); { need quick read
here }

                                    { delay(10); }
                                    ActivateWindow(AlertWind);
                                    if abs(level) > MaxReading then MaxReading
30                                := abs(level);
                                    if (abs(level) < MaxReading) and
(MaxReading > 50)
                                        then PeakReached := true;
                                    (){
                                        Until (level < bias-epsilon) or (level >
35                                bias+epsilon);)

```



```

    ){
        Until PeakReached and (abs(level) <
CoarseAdjustLim); }
        Until abs(level) > uplim+1(( bias ) +
epsilon);
5         centertext('Press any key to continue...',8);
        repeat
            DoBeep(100,1000);
            delay(50);
        until keypressed;
10         wastekey := readkey;
        clrscr;
        centertext('User finished adding resin.',5);
        CheckLevel; { to be sure before attempting
finaladjustment }
15         if not onbicell then begin
            CenterText('Resin level not in acceptable
range.',5);
            DoBeep(100,1000);
            delay(2000);
20             addremoveresin(stopc);
        end; { if not onbicell }
        DoFinalAdjustment;
        Update3DStateFile(ZStagePos,PlungerPos,stopc);
        exit;
25     end; { if not leveladjusted }
        clrscr;
        centertext('Resin level is now adjusted for part
building.',4);
        delay(2500);
30         beep;
    end; { addremoveresin }
    {*****}
begin
    leveladjusted := false;
35 end.
^Z

```

This Sheet Has Been Replaced



```

=====
3D Systems StereoLithography System Software
=====

```

```

5 RECOATER.PAS
  SLA-250 Recoater wiper and plunger Control Program

```

```

-----
Recent History:

```

```

10   9/12/88   Ver 3.30   first released for breadboard
    testing
      10/17/88       Ver   3.301   modified   to   be
utility/initialization for final SLA250
      11/15/88   Ver 3.31   copied from Recoat1 - use common
15 utl*.inc files
      01/11/89   Ver 3.32   remove sweeper forward back --> use
move move sweeper
      01/25/89   Ver 3.33   JFT removed sweeper velocity
biasing --> pass desired velocity in in/sec to MoveBlade,
20 SweeperForward or SweeperBack. Checks constant SIMULATION
to see if we want to run this as a simulation (no
communication with SLA) (useful for running on
workstations not attached to SLAs).
      01/30/89 JFT merged with Wayne's updated AddRemoveResin
25 procedures.
      02/01/89 USES Windows. Move AddRemoveResin to unit
UtlAdjus. USES UtlAdjus.
      02/16/89 Adjust Start Position sets new ZPlungeSetPos
and sends the elevator to that position.
30   03/07/89 JFT      Added exit proc to forward sweeper.

      03/09/89 JFT      Recalibrated sweep periods to
account for final compiler options.
      03/10/89 JFT      Fixed UtlAdjust so that it may be
broken out of.

```

This Sheet Has Been Replaced



03/28/89 JFT V3.42 Change sweep period now
bullet-proofed to input.

03/30/89 JFT V3.43 Write parameters to machine.prm
instead of zstage.prm.

5 05/25/89 JFT V3.61 Allow user to break out of adjust
resin level loops.

06/07/89 JFT V3.61B Make stirring easier to break out
of.

10 06/15/89 JFT V3.61C Better stirring utility
(multi-speed).

06/16/89 JFT V3.61D Better bicell check (see
UtlAdjust.pas).

06/16/89 JFT V3.61E Fix stir utility by using the
indexer's MA (Mode Alternate) command.

15 07/05/89 JFT V3.61F Single Coil Holding Torque.

07/21/89 JFT V3.62 Changed version #.

07/24/89 JFT V3.63 Fixed adjust resin level (?).

-----}

{ \$ M 16384,0,0}

20 { \$ D-;I+}

{R+}

uses Crt, Dos, Utility1, UtlSweep,
UtlZStage, windows, UtlAdjust, Indexer;
(\$I product.inc)

25

const

VersionId = '3.63';

Indent = 19;

epsilon = 1; { +/- bias variation used in add/remove

30 resin }

Simulation = false; { Is this a simulation (no SLA)?

}

var

35 opt, stopc : integer;

SweepPeriod : real;

key, junkkey : char;

This Sheet Has Been Replaced



```

level      : integer;
delaytime  : integer;
onbicell,leveladjusted : boolean;
tempstring : string;
5   TopWind,BottomWind,IntroWind : wind;
    SaveExit : pointer;

(*****)
(
10  Procedure CenterText(tempstring : string;RowNumber :
integer);
    begin
        gotoxy(1,rownumber);
        ClrEol;
15   if length(tempString) >= (lo(WindMax)-lo(WindMin))
        then gotoxy(1,rownumber)
                                e       l       s       e
        gotoxy(((lo(WindMax)-lo(WindMin)-length(tempstring)) div
20   write(tempstring);
        end; )
        2),rownumber);

(*****)
procedure ExitRecoater;
25  begin
        SweeperForward(3,stopc);
        CursorOn;
        ExitProc := SaveExit;
        Halt(0);
30  end;

(*****)
procedure DisplayLevel;
var
    junkStr : string;
35   sign : string[1];
begin
    procReadBiCell(500,true);

```

This Sheet Has Been Replaced




```

end;

procedure DefaultWindow2;
begin
5   DefaultWindow;
    window(1,1,80,22);
end;

procedure ShowPowerMenu;
10  var
    i : integer;
    junkStr : string;
begin
    DefaultWindow2;
15  ClrScr;
    FrameWindow(BottomWind);
    { ActivateWindow(BottomWind);
      DisplayLevel;}
    DefaultWindow2;
20  centertext(Product+'    Recoater    Utility    Control
Program',1);
    writeln;
    centertext('Version  '+VersionId+'    Software    Release
'+Rel_3D,2);
25  centertext('Copyright (C) 1989 by 3D Systems, Inc.',3);
    centertext('3D    Systems    Laser    StereoLithography
System',4);
    if Simulation then centertext('SIMULATION    IN
PROGRESS',5);
30  for i:=1 to 5 do writeln;
    FrameWindow(TopWind);
    ActivateWindow(TopWind);
    ClrScr;
    writeln('    1. Adjust Resin Level Utility ');
35  writeln('    2. Sweep ');
    writeln('    3. Change Sweep Period');
    writeln('    4. Lower Liquid');

```



111

```
writeln('    5. Raise Liquid');
writeln('    6. Adjust Building Start Position');
writeln('    7. Stir Liquid');
write  ('    X. Exit');
5   DefaultWindow2;
    centertext('Please make a selection.',18);
    writeln;
end;

10  procedure WriteZStartLevel(NewStartZLevel:real);
    const
        ParamFileName = '\3DSYS\MACHINE.XYZ';
        NewName        = '\3DSYS\MACHINE.PRM';

15  var
        IOerr,i,m,n,valcode : integer;
        j : longint;
        r : real;
        ParamFileLine, AppendText : str80;

20
        ParamFile,NewFile: text;
        InchDistanceStr  : str80;
        DirInfo          : SearchRec;
        InputLine        : string;

25  begin
        OpenParamFile := ParamFileName;

        assign(ParamFile,OpenParamFile);
        rewrite(ParamFile);
30  assign(NewFile,NewName);
        reset(NewFile);
        while not eof(NewFile) do begin
            readln(NewFile,InputLine);
            writeln(ParamFile,InputLine);
35  end;
        rewrite(NewFile);
```

```

IOerr := IOresult;
if IOerr <> 0 then begin
    OpenParamFile := ParamFileName;
    assign(ParamFile,OpenParamFile);
5    reset(ParamFile);
    IOerr := IOresult;
    if IOerr <> 0 then OpenParamFile := ' '
end; {IO error}
if IOerr = 0 then begin
10    i := 0;
    reset(ParamFile);
    repeat
        readln(paramFile,paramFileLine);
        writeln(newFile,paramFileLine);
15    until paramFileLine = 'ZSTAGE.PRM';
    while (not eof(ParamFile)) and (i <= 9) do begin
        for j:=1 to 255 do ParamFileLine[i]:=' ';
        readln(ParamFile,ParamFileLine);
        if i < 7 then writeln(NewFile,ParamFileLine)
20        else begin
            if i = 7 then appendText := '
ZLiquidLevel';
                                i f i = 7 t h e n
writeln(NewFile,NewStartZLevel:12:10,appendText)
25        else writeln(NewFile,ParamFileLine);
            end;
            if (ParamFileLine[1] <> ' ') and
(ParmFileLine[1] <> '!') and
(ParmFileLine[1] <> '"') then inc(i);
30    end;
    while not eof(paramFile) do
        begin
            readln(paramFile,paramFileLine);
            writeln(newFile,paramFileLine);
35    end;
end;
end;

```

This Sheet Has Been Replaced


```

      ZPlungeSetPos := NewStartZLevel + 0.315;  { 8mm lower
than Start. }
      close(NewFile);
      close(ParamFile);
5  end;

procedure ZSurfacePosition(var ZValue : real);
const
      ZVSlow = '0.100000';  { Slow speed for setting levels
10 )
var
      key : char;
      dumbkey,OK : boolean;
      StopCode : integer;
15      ZVSetZ : str10;
begin
      dumbkey := false;
      ActivateWindow(TopWind);
      clrscr;
20      Centertext('Use      up      and      down      arrows      for
positioning','1);
      Centertext('space to halt','2);
      Centertext(' S to shift to slow speed','3);
      Centertext(' and X when at the desired level.','4);
25      ZVSetZ := ZVeloc;
      repeat
          OK := false;
          repeat
              key := 'z';
30              HandleKeyboardRequest(key);
              key := upcase(key);
              if dumbkey then key:= ' ';
              dumbkey:=false;
              if key in [#72,#80,' ','S','X'] then OK := true;
35 ( up and down arrows )
          until OK;
          case key of

```

This Sheet Has Been Replaced



```

#72 : begin
            if not NegZStage then
ZFreeMove(ZAccel,ZVSetZ,'UP ') else

5  ZFreeMove(ZAccel,ZVSetZ,'DOWN');
        dumbkey := true;
        end;
#80 : begin
            if not NegZStage then
10 ZFreeMove(ZAccel,ZVSetZ,'DOWN') else

        ZFreeMove(ZAccel,ZVSetZ,'UP ');
        dumbkey := true;
        end;
15     'S': begin
            ZVSetZ := ZVSlow;    ( change to slow
speed )

            Centertext('Shifted to slow speed',6);
            Centertext(' for final positioning.',7);
20         end;
        'X': begin
            {}
            ZValue := -abs(ZStagePos);
            exit;
        end;
25     end;
        until false;
    end;

procedure AdjustBuildStart;
30 var
    instring      : string;
    valcode       : integer;
    junkStr       : string;
    NewStart      : real;
35    Temp        : real;
begin
    StopKey := true;

```

This Sheet Has Been Replaced



```

Temp := ZLiquidLevel;
ActivateWindow(BottomWind);
clrscr;
Centertext('Moving elevator to current start
5 position...',1);
GotoZPos(1);
Centertext('Position the elevator at the desired start
position.',1);
ZSurfacePosition(ZLiquidLevel);
10 clrscr;
ActivateWindow(BottomWind);
clrscr;
junkStr := concat('A new build starting level has been
entered. ');
15 centertext(junkStr,1);
ActivateWindow(TopWind);
clrscr;
centertext('Accept this new level ?',2);
repeat
20 delay(100)
until Keypressed;
if temp <> ZLiquidLevel then begin
    if upcase(readkey) = 'Y' then
WriteZStartLevel(ZLiquidLevel)
25 else ZLiquidLevel := temp;
end;
StopKey := false;
GoToZPos(2); { Go to Check Resin Level position. }
(){ ZReadParms;}
30 end;

procedure SetNewDelay;
var
    instring      : string;
35 valcode       : integer;
    junkStr       : string;
    tempReal      : real;

```

This Sheet Has Been Replaced

```
begin
  ActivateWindow(BottomWind);
  junkStr := concat('Enter  sweeper  period  [now
',RealStr(SweepPeriod,2), ' s]: ');
5   centertext(junkStr,1);
   cursoron;
   readln(instring);
   if instring <> '' then begin
     tempReal := RealVal(instring,valcode);
10    if (tempReal > maxSweepPeriod) then tempReal :=
maxSweepPeriod;
     if (tempReal < minSweepPeriod) then tempReal :=
minSweepPeriod;
     end;
15   cursoroff;
     if (valcode = 0) and (instring<>'') then SweepPeriod :=
tempReal;
     junkStr := concat('Sweeper period  now  set  to
',RealStr(SweepPeriod,2),' seconds');
20   centertext(junkStr,1);
     delay(3000);
   end;

  procedure GetSelection1;
25  begin
    repeat
      ActivateWindow(BottomWind);
      DisplayLevel;
      ActivateWindow(TopWind);
30   HandleKeyboardRequest(key);
      key := upcase(key);
      if key in ['1'..'7','X'] then exit;
    until false;
  end;
35
  (*****
  procedure DoBeep(freq,time : integer);
```



```

begin
    sound(freq);
    delay(time);
    nosound;
5   end;

{*****}
procedure doUpLiquid;
begin
10   ActivateWindow(BottomWind);
    procPlungerDown(true);
    ActivateWindow(TopWind);
end;
{*****}
15  procedure doDownLiquid;
    begin
        ActivateWindow(BottomWind);
        procPlungerUp(true);
        ActivateWindow(TopWind);
20  end;
{*****}
    procedure Stir;
    var
        wasteKey      : char;
25   endPos           : longInt;
        endPosStr      : string;
        abortStir,stop : boolean;
        accel,veloc    : string;
    {-----}
30   procedure ElevatorCommand( theCmd : string );
        var
            response    : string;
        begin
            if theCmd <> '' then if SendCmdToIndexer(theCmd+'
35  ',zTimeOut) <> 0
                then begin
                    beep;

```



```
        end
        else if ReadResponseFromIndexer(response,zTimeout)
<> 0
        then begin
5           beep;
           end;
        end;
        {-----}
begin
10     endPos := trunc( zStepsPerInch * (-1) * ( zLiquidLevel
- 0.5 ) );
        Str( endPos , endPosStr );
        ActivateWindow(BottomWind);
        ClrScr;
15     Write(' STIR fast/medium/slow (f/m/s) : ');
        repeat delay(100) until keypressed;
        wasteKey := UpCase(ReadKey);
        abortStir := false;
        case wasteKey of
20         'S' : begin
                    accel := '0.5';
                    veloc := '1';
                    end;
                'M' : begin
25                 accel := '5';
                    veloc := '5';
                    end;
                'F' : begin
30                 accel := '10';
                    veloc := '10';
                    end;
                else abortStir := true;
        end;
        if not abortStir then begin
35         ClrScr;
            Write( ' STIRRING : press any key to abort...' );
            GoToZPos(2);
```

```

ElevatorCommand( 'E MA A' + accel + ' V' + veloc );
stop := false;
ElevatorCommand( 'D' + endPosStr + ' G' );
repeat
5       if KeyPressed then stop := true;
        delay(100);
        if KeyPressed then stop := true;
until ( stop );
ClrScr;
10      Write( ' Aborting stir operation...' );
        ElevatorCommand( 'K' );
        ZGoHome;
        GoToZPos(2);
end;
15      ClrScr;
        ActivateWindow(TopWind);
end;
(*****)

20  begin ( ReCoater )
        TextBackground(Black);
        TextColor(White);
        SaveExit := ExitProc;
        ExitProc := @ExitRecoater;
25      DefaultWindow;
        ClrScr;
        DefineWindow(TopWind,Indent-1,7,80-Indent,16,1);
        DefineWindow(BottomWind,10,23,70,25,1);
        DefineWindow(IntroWind,10,7,70,11,2);
30      if Simulation then OnBicell := false;
        Read3DStateFile(ZStagePos,PlungerPos,stopc);
        SweepPeriod := DefaultPeriod;
        LevelAdjusted := false;
        delaytime := trunc(SweepPeriod);
35      CursorOff;
        FrameWindow(IntroWind);
        ActivateWindow(IntroWind);

```

This Sheet Has Been Replaced





```
ClrScr;
CenterText('Elevator moving to check resin level
position...',2);
if not Simulation then GoToZPos(2);
5 key := ' ';
DefaultWindow;
clrscr;
repeat
ShowPowerMenu;
10 ActivateWindow(BottomWind);
ActivateWindow(TopWind);
GetSelection1;
case key of
'1': AddRemoveResin(stopc);
15 '2': MoveBlade(SweepPeriod,stopc);
'3': SetNewDelay;
'4': doDownLiquid;
'5': doUpLiquid;
'6': AdjustBuildStart;
20 '7': Stir;
'X': Halt(0);
end;
key := ' ';
until false;
25 CursorOn;
( We exit through abort... we never reach here. )
end.
```

While the invention as described herein has been directed to specific embodiments, various modifications thereto can be employed. For example, while excess polymerizable liquid has been described herein as being struck off by a doctor blade, other means for such removal can obviously be employed, such as rakes and the like. As another example, a radiation source and sensor have been described herein as means to detect the level of the upper surface of the bath of polymerizable fluid, whereas a wide

variety of mechanical, electronic, pneumatic, and other devices can be used to detect this level. For example, an apparatus using a float has been described. Other modifications and improvements can be used without
5 departing from the scope of the invention. Accordingly, it is not intended that the invention be limited, except by the appended claims.

This Sheet Has Been Replaced





3D Systems, Inc.

May 22, 1995
D17337EPT1 SU/Hs/bs

5 1. A stereolithography system for forming a three-dimensional object
(40) comprising:

 a) an object support means (12):

 b) means (10, 11, 13, 14) to apply a thin layer (34) of
polymerizable liquid to a surface (15) of the object support means (12);

10 c) means (26, 27, 30-33; 300; 400; 505) to strike off excess
polymerizable liquid (302) from the applied layer (34) to provide a
smoothed layer of polymerizable liquid of desired thickness; and

 d) means (24) to apply a curing media in a predetermined
pattern to the smoothed layer of polymerizable liquid.

15

 2. The stereolithography system of claim 1 including a tank (10)
adapted to contain a bath (11) of polymerizable liquid therein.

 3. The stereolithography system of claims 1 or 2 including means
20 (13, 14) to raise and lower the object support means (12) within the
tank (10).

 4. The stereolithography system of anyone of the preceding claims
wherein the strike-off means (26, 27, 30-33; 300; 400; 505) is a doctor
25 blade (26; 300; 400; 505).

 5. The stereolithography system of claim 4 wherein means (27, 30-
33) are provided to move the doctor blade (26; 300; 400, 505) in a
horizontal plane.

30





6. The stereolithography system of any of claims 3-5 wherein the means (13, 14) to raise and lower the object support means (12) includes means (13) to lower the object support means (12) within a bath (11) of polymerizable liquid to form a thin layer (34) of said polymerizable liquid on a surface (15) provided on the object support means (12).

7. The stereolithography system of claim 6 wherein the means (13, 14) to raise and lower the object support means (12) includes means (13) to raise the layer (34) of polymerizable liquid on the surface (15) of the object support means (12) above the upper surface (20) of the bath (11).

8. The stereolithography system of claim 7 wherein the means (13, 14) to raise and lower the object support means (12) includes means (13) to lower the smoothed layer (34) of polymerizable liquid on the surface (15) of the object support means (12) in the bath (11) with the upper surface (36) of said layer being level with the upper surface (20) of the bath (11) within the tank (10).

9. The stereolithography system of any of the preceding claims including means (17, 18, 21, 22, 23, 95, 100, 130, 140) to control the level of the bath (11) in the tank (10).

10. The stereolithography system of claim 9 wherein the means (17, 18, 21, 22, 23, 95, 100, 130, 140) to control the level of bath (11) in the tank (10) includes a piston (17; 95) disposed within the bath (11) which can be raised or lowered therein.





11. The stereolithography system of claim 10 including means (21, 22, 130, 140) to sense the level of polymerizable liquid in the tank (10) and means (17, 18, 23) to adjust the vertical position of the piston (17; 95) within the bath (11) in response to the level (70, 80, 82, 84) sensed.

5

12. The stereolithography system of claim 11 including means (21, 22, 100, 130) to generate a signal representing the bath level (70, 80, 82, 84) sensed and means (25) to compare said level signal with a reference signal representing the desired bath level and further means (18) to
10 adjust the vertical position of the piston (17) in response to the difference between the sensed signal and the reference signal.

13. The stereolithography system of any of the preceding claims including a laser (24) to generate ultraviolet light to cure the
15 polymerizable liquid.

14. The stereolithographic system of claim 13 wherein the laser (24) is a HeCd laser.

20 15. The stereolithography system of claim 13 including a computer control system (25) to control the movement and output of the laser (24).

16. The stereolithography system of claim 15 further including a
25 computer control system (25) to control the movement of the object support means (12).

17. A method of forming a three-dimensional object by stereolithography comprising:





(a) applying a layer (34) of polymerizable liquid onto a surface (15) provided on an object support means (12);

(b) levelling the layer (34) of polymerizable liquid on said surface (15) to a desired thickness by striking off any excess polymerizable liquid (302) from the applied layer (34); and

(c) applying a curing media in a preselected pattern onto the levelled layer (34) of polymerizable liquid to sufficiently cure the layer (34) so that it supports one or more subsequent layers (38) of polymerizable liquid.

10

18. The method of claim (17) wherein the curing media is radiation selected from the group consisting of ultraviolet radiation, infrared radiation, visible light, electron beams, x-rays, and gamma rays.

15 19. The method of claim (18) wherein the polymerizable liquid is curable with ultraviolet radiation and the curing media is ultraviolet radiation.

20 20. The method of any of the preceding claims 17-19 wherein the layer (34) of polymerizable liquid is applied to a surface (15) on the object support means (12) by submerging the surface (15) into a bath (11) of polymerizable liquid.

25 21. The method of any of the preceding claims 17-20 wherein the applied layer (34) of polymerizable liquid is raised out of the bath (11) and excess polymerizable liquid is struck off therefrom by means of a horizontally moving doctor blade (26; 300; 400; 505) to form a smoothed layer (34) of polymerizable liquid of the desired thickness on said surface (15).

30





22. The method of claim 17 wherein the object support means (12) is lowered into the bath (11) after the layer (34) of polymerizable liquid is smoothed so that the upper surface (36) of the smoothed layer (34) of polymerizable liquid is level with the upper surface (20) of the bath
5 (11).

23. The method of claim 22 wherein after the upper surface (36) of the smoothed layer (34) of the polymerizable liquid is disposed at the same level of the bath (11), the layer is subjected to curing media.
10


24. The method of claim 23 wherein after the smoothed layer (34) is subjected to curing media, the object support means (12) is further lowered into the bath (11) of polymerizable liquid so that a subsequent layer (38) of polymerizable liquid can flow onto the previously cured
15 layer (34).

25. The method of any of the preceding claims 17-24 wherein a plurality of thin layers (34, 38) of polymerizable liquid are applied, leveled, and cured to form a three-dimensional object (40).
20

26. The method of any of the preceding claims 17-25 wherein the curing media is ultraviolet radiation emitted from an HeCd laser at a wavelength approximately 300 to 350 nanometers and from about 10 to about 30 milliwatts of power.
25

27. The method of claim 21 wherein the horizontal speed of the doctor blade (26; 300; 400; 505) ranges from about 0.25 to about 10 inches per second.





28. The method of any of the preceding claims 17-27 wherein the thickness of the layer (34) of polymerizable liquid which is polymerized by the application thereto of curing media ranges from about 0.005 to about 4.04 inch.

5

29. A method for applying a substantially smooth layer (38) of polymerizable liquid of a predetermined thickness over a part layer (34) in a stereolithography system, comprising the steps of:

dipping said part layer (34) into a body (11) of said liquid by more
10 than said predetermined thickness, and then raising said part layer (34) thereby applying a layer (38) of said liquid over said part layer (34);
and

sweeping a doctor blade (26; 300; 400; 505) one or more times over
said liquid layer (38), with a clearance between the blade and part layer,
15 striking off excess liquid at each sweep, such that on the last sweep, the clearance between the blade (26; 300; 400; 505) and the part layer (34) is substantially equal to the predetermined thickness, thereby forming
said substantially smooth layer (38).

20 30. The method of claim 39 wherein the clearance between the blade (26; 300; 400; 505) and the part layer (34) gets progressively smaller at each sweep.

31. The method of claim 30 wherein the velocity of the blade (26;
25 300; 400; 505) can vary at each sweep.

32. A stereolithography apparatus for forming a second part layer (38) having a predetermined thickness on top of a first part layer (34) comprising:





means (13, 14) for dipping the first layer (34) into a substantially constant volume (11) of polymerizable liquid by more than the predetermined thickness;

means (13, 14) for raising said first layer (34) so that a layer (38) of polymerized liquid is on the first layer (34);

a doctor blade (26; 300; 400; 505) for smoothing the liquid layer (38) by sweeping off excess liquid (302) until the liquid layer (38) is at said predetermined thickness; and

means (24) for forming the second layer (38) by subjecting the smoothed liquid layer to synergistic stimulation.

33. The apparatus of claim 32 further comprising:

a vat (10; 600) for containing the substantially constant volume (11) of polymerizable liquid, said volume (11) having a level (20);


means (21; 22; 130; 140) for detecting the level (20) of the polymerizable liquid in the vat (10) and comparing said detected level (20) to a predetermined level; and

a plunger (17; 96) responsive to said detecting means (21; 22; 130; 140) for raising or lowering into said liquid in said vat (11) until the liquid level (20) is substantially at said predetermined level.

34. The apparatus of claim 33 further comprising a side tank (40) coupled to the vat (10; 600), such that liquid can flow between the vat (11; 600) and side tank (40), ensuring that the liquid level in the side tank (40) is representative of the liquid level (20) in the vat (10; 600), wherein the level detecting means (21, 22, 130, 140) is a bi-cell detector which detects the level of the liquid in the side tank (40).

35. The apparatus of claim 33 wherein the level detecting means (21; 22; 130; 140) comprises:





a float (602) which floats in said liquid in said vat (10; 600);
a beam (60) having a first end coupled to said float (602), and a
second end, which beam is rotatably coupled to a fixed point (604)
between the ends such that a vertical displacement of the float (602)
5 will result in a magnified vertical displacement of the beam second end;
and
means (6052-6055) for detecting whether the second end is outside
a predetermined displacement range indicating that the liquid level is not
substantially at said predetermined level.

10

36. The apparatus of claim 32 wherein the doctor blade (26; 300;
400; 505) has a cross-section and the cross-section has a non-horizontal
edge at the bottom of the blade in the direction of blade movement
which makes an angle (α_1 , α_2) with the horizontal.

15

37. The apparatus of claim 36 wherein said angle (α_1 , α_2) is within
a range of about 5-8 degrees.

38. A method for setting the gap between a doctor blade (26; 300;
20 400; 505), having two ends and a bottom, and a mass, and the surface
of a polymerizable liquid in a stereolithography system to a predeter-
mined value, comprising the steps of:

releasably attaching two retractable needles (401, 402) to the bottom
of the blade (400) at each end such that each needle extends beyond
25 the bottom substantially by said predetermined value;

lowering one end of the blade (400) by adjusting a first non-torque
inducing screw means (405, 406) until the needle (401, 402) at that end
touches the liquid surface;



* C L H S *

lowering the other end of the blade (400) by adjusting a second non-torque inducing screw means (405, 406) until the needle (401, 402) at that end touches the liquid surface;

raising and then lowering the blade (400) and possibly readjusting
s said non-torque inducing screw means (405, 406) to ensure that both needles (401, 402) touch the liquid surface at about the same time; and

retracting said needles (401, 402) without significantly changing the mass of the blade (400).

10 39. The method of claim 38 wherein said non-torque inducing screw means (405, 406) are micrometer screws.

This Sheet Has Been Replaced

