



162162

ABSTRACT OF THE DISCLOSURE

METHOD FOR INJECTING RESIN IN A MOULD CONTAINING A
FIBROUS PREFORM

To produce a large-size item using the RTM technique, only two reservoirs (16a, 16b) are used which are alternately connected to the mould (10). When one of the reservoirs is empty, it is replaced by another reservoir full of resin while the resin contained in the other reservoir is injected into mould (10). Therefore continuous injection is made into mould (10) of a quantity of resin that is greater than the accumulated capacity of the first and second reservoirs (16a, 16b).

Single figure.



G00002